



1

2

3

4

Document Number: DSP1022

Date: 2015-05-22

Version: 1.0.2

5

CPU Profile

6

Supersedes: 1.0.1

7

Document Class: Normative

8

Document Status: Published

9

Document Language: en-US

10 Copyright Notice

11 Copyright © 2008–2015 Distributed Management Task Force, Inc. (DMTF). All rights reserved.

12 DMTF is a not-for-profit association of industry members dedicated to promoting enterprise and systems
13 management and interoperability. Members and non-members may reproduce DMTF specifications and
14 documents, provided that correct attribution is given. As DMTF specifications may be revised from time to
15 time, the particular version and release date should always be noted.

16 Implementation of certain elements of this standard or proposed standard may be subject to third party
17 patent rights, including provisional patent rights (herein "patent rights"). DMTF makes no representations
18 to users of the standard as to the existence of such rights, and is not responsible to recognize, disclose,
19 or identify any or all such third party patent right, owners or claimants, nor for any incomplete or
20 inaccurate identification or disclosure of such rights, owners or claimants. DMTF shall have no liability to
21 any party, in any manner or circumstance, under any legal theory whatsoever, for failure to recognize,
22 disclose, or identify any such third party patent rights, or for such party's reliance on the standard or
23 incorporation thereof in its product, protocols or testing procedures. DMTF shall have no liability to any
24 party implementing such standard, whether such implementation is foreseeable or not, nor to any patent
25 owner or claimant, and shall have no liability or responsibility for costs or losses incurred if a standard is
26 withdrawn or modified after publication, and shall be indemnified and held harmless by any party
27 implementing the standard from any and all claims of infringement by a patent owner for such
28 implementations.

29 For information about patents held by third-parties which have notified the DMTF that, in their opinion,
30 such patent may relate to or impact implementations of DMTF standards, visit
31 <http://www.dmtf.org/about/policies/disclosures.php>.

32 This document's normative language is English. Translation into other languages is permitted.

CONTENTS

34	Foreword	6
35	Introduction.....	7
36	1 Scope	9
37	2 Normative references	9
38	3 Terms and definitions	9
39	4 Symbols and abbreviated terms.....	10
40	5 Synopsis	10
41	6 Description	11
42	7 Implementation.....	12
43	7.1 CIM_Processor	12
44	7.2 Processor capabilities	12
45	7.3 Processor state management.....	13
46	7.4 CIM_Processor.RequestedState	14
47	7.5 Modeling the current enabled state of the processor	14
48	7.6 Modeling individual processor cores.....	15
49	7.7 Modeling individual hardware threads	18
50	7.8 Modeling cache memory.....	20
51	7.9 Modeling physical aspects of processor and cache memory	22
52	8 Methods.....	22
53	8.1 CIM_Processor.RequestStateChange()	22
54	8.2 CIM_ProcessorCore.RequestStateChange()	23
55	8.3 CIM_HardwareThread.RequestStateChange()	24
56	8.4 CIM_Memory.RequestStateChange()	25
57	8.5 Profile conventions for operations	25
58	8.6 CIM_AssociatedCacheMemory	26
59	8.7 CIM_ConcreteComponent — References CIM_HardwareThread and CIM_Processor	26
60	8.8 CIM_ConcreteComponent — References CIM_ProcessorCore and CIM_Processor	26
61	8.9 CIM_ElementCapabilities — References CIM_HardwareThread and CIM_EnabledLogicalElementCapabilities.....	27
62	8.10 CIM_ElementCapabilities — References CIM_Memory and CIM_EnabledLogicalElementCapabilities.....	27
63	8.11 CIM_ElementCapabilities — References CIM_Processor and CIM_ProcessorCapabilities	27
64	8.12 CIM_ElementCapabilities — References CIM_ProcessorCore and CIM_EnabledLogicalElementCapabilities.....	28
65	8.13 CIM_EnabledLogicalElementCapabilities.....	28
66	8.14 CIM_HardwareThread	28
67	8.15 CIM_Memory	29
68	8.16 CIM_Processor	29
69	8.17 CIM_ProcessorCapabilities	29
70	8.18 CIM_ProcessorCore	30
71	8.19 CIM_SystemDevice	30
72	9 Use cases.....	31
73	9.1 Object diagrams.....	31
74	9.2 Change the enabled state of the memory to the desired state.....	37
75	9.3 Change the enabled state of the CPU to the desired state	37
76	9.4 Change the enabled state of the CPU's core to the desired state	37
77	9.5 Change the enabled state of the CPU's hardware thread to the desired state	37
78	9.6 Retrieve all the processor cores for the CPU	38
79	9.7 Retrieve all the hardware threads for the CPU	38
80	9.8 Retrieve CPU's cache memory information for the CPU.....	38

85	10	CIM Elements	38
86	10.1	CIM_AssociatedCacheMemory	40
87	10.2	CIM_ConcreteComponent — References CIM_HardwareThread and CIM_ProcessorCore	40
89	10.3	CIM_ConcreteComponent — References CIM_ProcessorCore and CIM_Processor	41
90	10.4	CIM_ElementCapabilities — References CIM_HardwareThread and CIM_EnabledLogicalElementCapabilities	41
92	10.5	CIM_ElementCapabilities — References CIM_Memory and CIM_EnabledLogicalElementCapabilities	41
94	10.6	CIM_ElementCapabilities — References CIM_Processor and CIM_ProcessorCapabilities	42
96	10.7	CIM_ElementCapabilities — References CIM_ProcessorCore and CIM_EnabledLogicalElementCapabilities	42
98	10.8	CIM_EnabledLogicalElementCapabilities	43
99	10.9	CIM_HardwareThread	43
100	10.10	CIM_Memory	43
101	10.11	CIM_Processor	44
102	10.12	CIM_ProcessorCapabilities	44
103	10.13	CIM_ProcessorCore	45
104	10.14	CIM_RegisteredProfile	45
105	10.15	CIM_SystemDevice	45
106		ANNEX A (informative) Change log	47
107			

108 Figures

109	Figure 1 – CPU Profile: Class Diagram	12
110	Figure 2 – Registered Profile	31
111	Figure 3 – Multi-core CPU	32
112	Figure 4 – Detailed multi-core CPU	33
113	Figure 5 – Multi-core CPU with a disabled core	34
114	Figure 6 – Single Core, Multi-Hardware Thread CPU	35
115	Figure 7 – Processor with Off-Chip Cache	36
116		

117 Tables

118	Table 1 – Related Profiles	10
119	Table 2 – CIM_ProcessorCapabilities Properties mapping to SMBIOS equivalence	13
120	Table 3 – CIM_Processor.CPUStatus Value Descriptions	15
121	Table 4 – Mapping for CPUStatus Property and EnabledState Property Values	15
122	Table 5 – CIM_ProcessorCore.CoreEnabledState Value Descriptions	17
123	Table 6 – Mapping for the CoreEnabledState property and EnabledState property values	18
124	Table 7 – CIM_HardwareThread.EnabledState Value Descriptions	20
125	Table 8 – CIM_Memory.EnabledState value descriptions	22
126	Table 9 – CIM_Processor.RequestStateChange() method: Return code values	23
127	Table 10 – CIM_Processor.RequestStateChange() method: Parameters	23
128	Table 11 – CIM_ProcessorCore.RequestStateChange() method: Return code values	23
129	Table 12 – CIM_ProcessorCore.RequestStateChange() method: Parameters	24
130	Table 13 – CIM_HardwareThread.RequestStateChange() method: Return code values	24

131 Table 14 – CIM_HardwareThread.RequestStateChange() method: Parameters..... 24

132 Table 15 – CIM_Memory.RequestStateChange() method: Return code values 25

133 Table 16 – CIM_Memory.RequestStateChange() method: Parameters..... 25

134 Table 17 – Operations: CIM_AssociatedCacheMemory..... 26

135 Table 18 – Operations: CIM_ConcreteComponent 26

136 Table 19 – Operations: CIM_ConcreteComponent 27

137 Table 20 – Operations: CIM_ElementCapabilities 27

138 Table 21 – Operations: CIM_ElementCapabilities 27

139 Table 22 – Operations: CIM_ElementCapabilities 28

140 Table 23 – Operations: CIM_ElementCapabilities 28

141 Table 24 – Operations: CIM_HardwareThread..... 28

142 Table 25 – Operations: CIM_Memory..... 29

143 Table 26 – Operations: CIM_Processor..... 29

144 Table 27 – Operations: CIM_ProcessorCore..... 30

145 Table 28 – Operations: CIM_SystemDevice..... 30

146 Table 29 – CIM Elements: CPU Profile..... 38

147 Table 30 – Class: CIM_AssociatedCacheMemory 40

148 Table 31 – Class: CIM_ConcreteComponent — References CIM_HardwareThread and
149 CIM_ProcessorCore..... 40

150 Table 32 – Class: CIM_ConcreteComponent — References CIM_ProcessorCore and CIM_Processor .. 41

151 Table 33 – Class: CIM_ElementCapabilities — References CIM_HardwareThread and
152 CIM_EnabledLogicalElementCapabilities 41

153 Table 34 – Class: CIM_ElementCapabilities — References CIM_Memory and
154 CIM_EnabledLogicalElementCapabilities 42

155 Table 35 – Class: CIM_ElementCapabilities — References CIM_Processor and
156 CIM_ProcessorCapabilities..... 42

157 Table 36 – Class: CIM_ElementCapabilities — References CIM_ProcessorCore and
158 CIM_EnabledLogicalElementCapabilities 42

159 Table 37 – Class: CIM_EnabledLogicalElementCapabilities..... 43

160 Table 38 – Class: CIM_HardwareThread 43

161 Table 39 – Class: CIM_Memory 43

162 Table 40 – Class: CIM_Processor 44

163 Table 41 – Class: CIM_ProcessorCapabilities..... 44

164 Table 42 – Class: CIM_ProcessorCore 45

165 Table 43 – Class: CIM_RegisteredProfile..... 45

166 Table 44 – Class: CIM_SystemDevice 46

167

168

Foreword

169 The *CPU Profile* (DSP1022) was prepared by the Physical Platform Profiles Working Group of the DMTF.

170 DMTF is a not-for-profit association of industry members dedicated to promoting enterprise and systems
171 management and interoperability. For information about the DMTF, see <http://www.dmtf.org>.

172 **Acknowledgments**

173 The DMTF acknowledges the following individuals for their contributions to this document:

174 Editors:

- 175 • Jon Hass – Dell
- 176 • Jeff Hilland – Hewlett-Packard Company
- 177 • John Leung - Intel
- 178 • Khachatur Papanyan – Dell

179 Contributors:

- 180 • Jeff Lynch – IBM
- 181 • Aaron Merkin – IBM
- 182 • Christina Shaw – Hewlett-Packard Company
- 183 • Perry Vincent – Intel

184

Introduction

185 The information in this specification should be sufficient for a provider or consumer of this data to identify
186 unambiguously the classes, properties, methods, and values that shall be instantiated and manipulated to
187 represent and manage the processor components of systems and subsystems modeled using the DMTF
188 Common Information Model (CIM) core and extended model definitions.

189 The target audience for this specification is implementers who are writing CIM-based providers or
190 consumers of management interfaces that represent the component described in this document.

191

192

CPU Profile

193 1 Scope

194 The *CPU Profile* extends the management capability of referencing profiles by adding the capability to
195 represent CPUs or processors in a managed system. CPU cache memory and associations with CPU
196 physical aspects, as well as profile implementation version information, are modeled in this profile.

197 2 Normative references

198 The following referenced documents are indispensable for the application of this document. For dated or
199 versioned references, only the edition cited (including any corrigenda or DMTF update versions) applies.
200 For references without a date or version, the latest published edition of the referenced document
201 (including any corrigenda or DMTF update versions) applies.

202 DMTF DSP0004, *CIM Infrastructure Specification 2.5*,
203 http://www.dmtf.org/standards/published_documents/DSP0004_2.5.pdf

204 DMTF DSP0134, *System Management BIOS (SMBIOS) Reference Specification 2.6*,
205 http://www.dmtf.org/standards/published_documents/DSP0134_2.6.pdf

206 DMTF DSP0200, *CIM Operations over HTTP 1.3*,
207 http://www.dmtf.org/standards/published_documents/DSP0200_1.3.pdf

208 DMTF DSP1001, *Management Profile Specification Usage Guide 1.0*,
209 http://www.dmtf.org/standards/published_documents/DSP1001_1.0.pdf

210 DMTF DSP1011, *Physical Asset Profile 1.0*,
211 http://www.dmtf.org/standards/published_documents/DSP1011_1.0.pdf

212 DMTF DSP1033, *Profile Registration Profile 1.0*,
213 http://www.dmtf.org/standards/published_documents/DSP1033_1.0.pdf

214 IETF RFC5234, *Augmented BNF for Syntax Specifications: ABNF*, January 2008,
215 <http://www.rfc-editor.org/rfc/rfc5234.txt>

216 ISO/IEC Directives, Part 2, [Rules for the structure and drafting of International Standards](#)

217 3 Terms and definitions

218 In this document, some terms have a specific meaning beyond the normal English meaning. Those terms
219 are defined in this clause.

220 The terms "shall" ("required"), "shall not," "should" ("recommended"), "should not" ("not recommended"),
221 "may," "need not" ("not required"), "can" and "cannot" in this document are to be interpreted as described
222 in [ISO/IEC Directives, Part 2](#), Annex H. The terms in parenthesis are alternatives for the preceding term,
223 for use in exceptional cases when the preceding term cannot be used for linguistic reasons. Note that
224 [ISO/IEC Directives, Part 2](#), Annex H specifies additional alternatives. Occurrences of such additional
225 alternatives shall be interpreted in their normal English meaning.

226 The terms "clause," "subclause," "paragraph," and "annex" in this document are to be interpreted as
227 described in [ISO/IEC Directives, Part 2](#), Clause 5.

228 The terms "normative" and "informative" in this document are to be interpreted as described in [ISO/IEC](#)
 229 [Directives, Part 2](#), Clause 3. In this document, clauses, subclauses, or annexes labeled "(informative)" do
 230 not contain normative content. Notes and examples are always informative elements.

231 For the purposes of this document, the following terms and definitions apply. The terms defined in
 232 [DSP0004](#), [DSP0200](#), [DSP1001](#), and [DSP1033](#) also apply to this document.

233 3.1

234 Cache Memory

235 indicates the instance of CIM_Memory that represents the cache memory for the processor

236 3.2

237 Host Processor

238 indicates the instance of CIM_Processor that represents the processor that hosts the processor core

239 3.3

240 Threading Processor Core

241 indicates the instance of CIM_ProcessorCore that represents the processor core that enables the
 242 hardware threading

243 4 Symbols and abbreviated terms

244 4.1

245 CPU

246 central processing unit

247 5 Synopsis

248 **Profile Name:** *CPU*

249 **Version:** 1.0.2

250 **Organization:** DMTF

251 **CIM Schema Version:** 2.19

252 **Central Class:** CIM_Processor

253 **Scoping Class:** CIM_ComputerSystem

254 The *CPU Profile* is a component profile that extends the management capability of referencing profiles by
 255 adding the capability to represent CPUs or processors in a managed system.

256

Table 1 – Related Profiles

Profile Name	Organization	Version	Requirement	Description
Physical Asset	DMTF	1.0	Optional	See 7.9.
Profile Registration	DMTF	1.0	Mandatory	

257 6 Description

258 The *CPU Profile* describes CPU or processor devices and associated cache memory used in managed
259 systems.

260 The profile could manage the following capabilities of a typical computer system:

- 261 • A computer system can have one or more processors, which may be individually enabled or
262 disabled.
- 263 • A processor can contain one or more processor cores, which may be individually enabled or
264 disabled.
- 265 • A processor core can contain one or more hardware threads, which may be individually enabled or
266 disabled

267 Figure 1 represents the class schema for the *CPU Profile*. For simplicity, the prefix CIM_ has been
268 removed from the names of the classes.


269 The CIM_Processor class represents a group of processor cores; the CIM_ProcessorCapabilities class
270 describes the capabilities of the processor. The CIM_Processor may be associated to one or more of
271 instances of CIM_ProcessorCore, through the CIM_ConcreteComponent association.

272 The CIM_ProcessorCore class represents a processing execution unit. The CIM_ProcessorCore may be
273 associated to one or more instances of CIM_HardwareThread, through the CIM_ConcreteComponent
274 association.

275 The CIM_HardwareThread class represents a hardware thread, a mechanism by which a processing
276 execute unit is made to appear as multiple processing units (each called a virtual core).

277 The CIM_Memory class represents cache memory. CIM_Memory may be associated to either
278 CIM_Processor or CIM_ProcessorCore, through the CIM_AssociatedCacheMemory association.

279 The CIM_Chip class represents the physical aspects of a processor. The CIM_PhysicalMemory
280 represents the cache memory, when the cache memory is off-chip/external.



281

282

Figure 1 – CPU Profile: Class Diagram

283 7 Implementation

284 This clause details the requirements related to the arrangement of instances and their properties for
 285 implementations of this profile. Methods are listed in clause 8 (“Methods”), and properties are listed in
 286 clause 10 (“CIM Elements”).

287 7.1 CIM_Protessor

288 Zero or more instances of CIM_Protessor shall be instantiated.

289 7.2 Processor capabilities

290 The CIM_ProtessorCapabilities class may be instantiated to represent the processor capabilities. Only
 291 one instance of CIM_ProtessorCapabilities shall be associated with a given instance of CIM_Protessor
 292 through an instance of CIM_ElementCapabilities.

293 7.2.1 Multi-Core or Multi-Thread processor capabilities

294 When modeling the capabilities of a multi-core or multi-thread processor, the CIM_ProtessorCapabilities
 295 class shall be instantiated and associated to the instance of CIM_Protessor that represents the multi-core
 296 or multi-thread processor.

297 The properties of CIM_ProcessorCapabilities described in the “CIM_ProcessorCapabilities Properties”
 298 column in Table 2 are defined in terms of the [DSP0134](#) Processor Information structure to provide
 299 meaningful context for the interpretation of the properties. The mappings specified in Table 2 shall be
 300 used. The underlying represented system does not need to support [DSP0134](#).

301 **Table 2 – CIM_ProcessorCapabilities Properties mapping to SMBIOS equivalence**

CIM_ProcessorCapabilities Properties	SMBIOS Structure Name	SMBIOS Structure Description
NumberOfProcessorCores	Core Count	Number of cores per processor socket
NumberOfHardwareThreads	Thread Count	Number of threads per processor socket

302 **7.2.2 Single-Core and Single-Thread processor capabilities**

303 When modeling the capabilities of a single-core and single-thread processor, the
 304 CIM_ProcessorCapabilities may not be instantiated.

305 When no instance of CIM_ProcessorCapabilities is associated with the instance of CIM_Processor that
 306 represents the processor, the processor is a single-core and single-thread processor.

307 When an instance of CIM_ProcessorCapabilities is associated with the instance of CIM_Processor that
 308 represents the single-core and single-thread processor, the following requirements apply:

- 309 • The CIM_ProcessorCapabilities.NumberOfProcessorCores property shall have a value of 1.
- 310 • The CIM_ProcessorCapabilities.NumberOfHardwareThreads property shall have a value of 1.

311 **7.2.3 CIM_ProcessorCapabilities.RequestedStatesSupported**

312 The RequestedStatesSupported property is an array that contains the supported requested states for the
 313 instance of CIM_Processor. This property shall be the super set of the values to be used as the
 314 RequestedState parameter in the RequestStateChange() method (see 8.1). The value of the
 315 CIM_ProcessorCapabilities.RequestedStatesSupported property shall be an empty array or contain any
 316 combination of the following values: 2 (Enabled), 3 (Disabled), or 11 (Reset).

317 **7.2.4 CIM_ProcessorCapabilities.ElementNameEditSupported**

318 The ElementNameEditSupported property shall have a value of TRUE when the implementation supports
 319 client modification of the CIM_Processor.ElementName property.

320 **7.2.5 CIM_ProcessorCapabilities.MaxElementNameLen**

321 The MaxElementNameLen property shall be implemented when the ElementNameEditSupported
 322 property has a value of TRUE.

323 **7.3 Processor state management**

324 Processor state management requires that the CIM_Processor.RequestStateChange() method be
 325 supported (see 8.1) and the value of the CIM_Processor.RequestedState property not match 12 (Not
 326 Applicable).

327 **7.3.1 Processor state management support**

328 When the instance of CIM_ProcessorCapabilities does not exist, processor state management shall not
 329 be supported.

330 When the value of the CIM_ProcessorCapabilities.RequestedStatesSupported property of the associated
331 CIM_ProcessorCapabilities instance is an empty array, processor state management shall not be
332 supported.

333 When the value of the CIM_ProcessorCapabilities.RequestedStatesSupported property of the associated
334 CIM_ProcessorCapabilities instance is not an empty array, processor state management shall be
335 supported.

336 **7.4 CIM_Processor.RequestedState**

337 The CIM_Processor.RequestedState property shall have a value of 12 (Not Applicable) or 5 (No Change),
338 or a value contained in the CIM_ProcessorCapabilities.RequestedStatesSupported property array of the
339 associated CIM_ProcessorCapabilities instance (see 7.2.2).

340 When processor state management is supported and the RequestStateChange() method is successfully
341 executed, the RequestedState property shall be set to the value of the RequestedState parameter of the
342 RequestStateChange() method. After the RequestStateChange() method has successfully executed, the
343 RequestedState and EnabledState properties shall have equal values with the exception of the
344 transitional requested state 11 (Reset). The value of the RequestedState property may also change as a
345 result of a request for a change to the processor's enabled state by a non-CIM implementation.

346 **7.4.1 RequestedState — 12 (Not Applicable) value**

347 When processor state management is not supported, the value of the CIM_Processor.RequestedState
348 property shall be 12 (Not Applicable).

349 **7.4.2 RequestedState — 5 (No Change) value**

350 When processor state management is supported, the initial value of the CIM_Processor.RequestedState
351 property shall be 5 (No Change).

352 **7.5 Modeling the current enabled state of the processor**

353 The current enabled state of the processor is described by the CIM_Processor.CPUStatus and
354 CIM_Processor.EnabledState properties. Clauses 7.5.1 and 7.5.2 detail the requirements for
355 implementing these two properties.

356 **7.5.1 CIM_Processor.CPUStatus**

357 Table 3 describes the mapping between the values of the CIM_Processor.CPUStatus property and the
 358 corresponding description of the state of the processor. The CPUStatus property shall match the values
 359 that are specified in Table 3. When the RequestStateChange() method executes but does not complete
 360 successfully, or the processor is in an indeterminate state, the CPUStatus property shall have value of 0
 361 (Unknown). The value of this property may also change as a result of a change to the processor's
 362 enabled state by a non-CIM implementation.

363 **Table 3 – CIM_Processor.CPUStatus Value Descriptions**

Value	Description	Extended Description
0	Unknown	Processor state is indeterminate, or the processor state management is not supported.
1	CPU Enabled	Processor shall be enabled.
2	CPU Disabled by User	Processor shall be disabled through client configuration, which may occur through client invocation of the RequestStateChange() method or through a non-CIM implementation such as BIOS.
3	CPU Disabled By BIOS (POST Error)	Processor shall be disabled due to a POST error.
4	CPU Is Idle, waiting to be enabled	Processor shall be enabled but idling.

364 **7.5.2 CIM_Processor.EnabledState**

365 The CIM_Processor.EnabledState property shall be implemented in addition to the
 366 CIM_Processor.CPUStatus property. When the CPUStatus property has a value that matches a value in
 367 the "CPUStatus Value" column in Table 4, the EnabledState property shall have a value that matches a
 368 value in the "EnabledState Value" column in the same row in the table.

369 **Table 4 – Mapping for CPUStatus Property and EnabledState Property Values**

CPUSatus Value	Description	EnabledState Value	Description
0	Unknown	0 or 5	Unknown or Not Applicable
1	CPU Enabled	2	Enabled
2	CPU Disabled by User	3	Disabled
3	CPU Disabled By BIOS (POST Error)	3	Disabled
4	CPU Is Idle, waiting to be enabled	2	Enabled

370 **7.6 Modeling individual processor cores**

371 Modeling the individual processor cores is optional functionality. When individual processor cores are
 372 modeled, the implementation shall instantiate an instance of CIM_ProcessorCore to represent each
 373 processor core. All the requirements in this clause and its subclauses are applicable when an
 374 implementation instantiates the CIM_ProcessorCore class.

375 Each instance of CIM_ProcessorCore shall be associated through an instance of
 376 CIM_ConcreteComponent to only one instance of CIM_Processor that represents the processor (Host
 377 Processor) that hosts the processor core.

378 The number of instances of CIM_ProcessorCore associated with the Host Processor shall be equal to the
379 value of the CIM_ProcessorCapabilities.NumberOfProcessorCores property of the instance of
380 CIM_ProcessorCapabilities that is associated with the Host Processor.

381 **7.6.1 Processor core capabilities**

382 The CIM_EnabledLogicalElementCapabilities class may be used to model the capabilities of processor
383 cores. When the CIM_EnabledLogicalElementCapabilities class is instantiated to represent the processor
384 core capabilities, the instance of CIM_EnabledLogicalElementCapabilities shall be associated with the
385 CIM_ProcessorCore instance through an instance of CIM_ElementCapabilities and used for advertising
386 the capabilities of the CIM_ProcessorCore instance.

387 There shall be at most one instance of CIM_EnabledLogicalElementCapabilities associated with a given
388 instance of CIM_ProcessorCore.

389 **7.6.1.1 CIM_EnabledLogicalElementCapabilities.RequestedStatesSupported**

390 The RequestedStatesSupported property is an array that contains the supported requested states for the
391 instance of CIM_ProcessorCore. This property shall be the super set of the values to be used as the
392 RequestedState parameter in the RequestStateChange() method (see 8.2). The value of the
393 RequestedStatesSupported property shall be an empty array or contain any combination of the following
394 values: 2 (Enabled), 3 (Disabled), or 11 (Reset).

395 **7.6.1.2 CIM_EnabledLogicalElementCapabilities.ElementNameEditSupported**

396 The ElementNameEditSupported property shall have a value of TRUE when the implementation supports
397 client modification of the CIM_ProcessorCore.ElementName property.

398 **7.6.1.3 CIM_EnabledLogicalElementCapabilities.MaxElementNameLen**

399 The MaxElementNameLen property shall be implemented when the ElementNameEditSupported
400 property has a value of TRUE.

401 **7.6.2 Processor core state management**

402 Processor core state management requires that the CIM_ProcessorCore.RequestStateChange() method
403 be supported (see 8.2) and the value of the CIM_ProcessorCore.RequestedState property not match 12
404 (Not Applicable).

405 **7.6.2.1 Processor core state management support**

406 When no CIM_EnabledLogicalElementCapabilities instance is associated with the CIM_ProcessorCore
407 instance, processor core state management shall not be supported.

408 When a CIM_EnabledLogicalElementCapabilities instance is associated with the CIM_ProcessorCore
409 instance but the value of the CIM_EnabledLogicalElementCapabilities.RequestedStatesSupported
410 property is an empty array, processor core state management shall not be supported.

411 When a CIM_EnabledLogicalElementCapabilities instance is associated with the CIM_ProcessorCore
412 instance and the value of the CIM_EnabledLogicalElementCapabilities.RequestedStatesSupported
413 property is not an empty array, processor core state management shall be supported.

414 **7.6.3 CIM_ProcessorCore.RequestedState**

415 The CIM_ProcessorCore.RequestedState property shall have a value of 12 (Not Applicable) or 5 (No
416 Change), or a value contained in the

417 CIM_EnabledLogicalElementCapabilities.RequestedStatesSupported property array of the associated
 418 CIM_EnabledLogicalElementCapabilities instance (see 7.6.1.1).

419 When processor core state management is supported and the RequestStateChange() method is
 420 successfully executed, the RequestedState property shall be set to the value of the RequestedState
 421 parameter of the RequestStateChange() method. After the RequestStateChange() method has
 422 successfully executed, the RequestedState and EnabledState properties shall have equal values with the
 423 exception of the transitional requested state 11 (Reset). The value of the RequestedState property may
 424 also change as a result of a request for a change to the processor’s enabled state by a non-CIM
 425 implementation.

426 **7.6.3.1 RequestedState — 12 (Not Applicable) value**

427 When processor core state management is not supported, the value of the
 428 CIM_ProcessorCore.RequestedState property shall be 12 (Not Applicable).

429 **7.6.3.2 RequestedState — 5 (No Change) value**

430 When processor core state management is supported, the initial value of the
 431 CIM_ProcessorCore.RequestedState property shall be 5 (No Change).

432 **7.6.4 Modeling the current enabled state of the processor core**

433 The current enabled state of the processor core is described by the
 434 CIM_ProcessorCore.CoreEnabledState and CIM_ProcessorCore.EnabledState properties. Clauses
 435 7.6.4.1 and 7.6.4.2 detail the requirements for implementing these two properties.

436 **7.6.4.1 CIM_ProcessorCore.CoreEnabledState**

437 Table 5 describes the mapping between the values of the CIM_ProcessorCore.CoreEnabledState
 438 property and the corresponding description of the state of the processor core. The CoreEnabledState
 439 property shall match the values that are specified in Table 5. When the RequestStateChange() method
 440 executes but does not complete successfully, and the processor core is in an indeterminate state, the
 441 CoreEnabledState property shall have a value of 0 (Unknown). The value of this property may also
 442 change as a result of a change to the processor’s enabled state by a non-CIM implementation.

443 **Table 5 – CIM_ProcessorCore.CoreEnabledState Value Descriptions**

Value	Description	Extended Description
0	Unknown	Processor core state is indeterminate, or the processor core state management is not supported.
2	Enabled	Processor core shall be enabled.
3	Disabled	Processor core shall be disabled.
4	Core Disabled User	Processor core shall be disabled through client configuration, which may occur through client invocation of RequestStateChange() or through a non-CIM implementation such as BIOS.
5	Core Disabled By Post Error	Processor core shall be disabled due to a POST error.

444 **7.6.4.2 CIM_ProcessorCore.EnabledState**

445 The CIM_ProcessorCore.EnabledState property shall be implemented in addition to the
 446 CIM_ProcessorCore.CoreEnabledState property. When the CoreEnabledState property value matches a
 447 value in the “CoreEnabledState Value” column in Table 6, the EnabledState property shall have the value
 448 that matches the value in the “EnabledState Value” column in the same row in the table.

449 **Table 6 – Mapping for the CoreEnabledState property and EnabledState property values**

CoreEnabledState Value	Description	EnabledState Value	Description
0	Unknown	0 or 5	Unknown or Not Applicable
2	Enabled	2	Enabled
3	Disabled	3	Disabled
4	Core Disabled User	3	Disabled
5	Core Disabled By Post Error	3	Disabled

450 **7.7 Modeling individual hardware threads**

451 Modeling the individual hardware threads is optional functionality. When hardware threads are modeled,
 452 the implementation shall model processor cores as described in 7.6 and shall instantiate an instance of
 453 CIM_HardwareThread to represent each hardware thread. All the requirements in this clause and its
 454 subclauses are applicable when an implementation instantiates the CIM_HardwareThread class.

455 The instance of CIM_HardwareThread shall be associated through an instance of
 456 CIM_ConcreteComponent to only one instance of CIM_ProcessorCore that represents the processor core
 457 that enables the hardware thread (Threading Processor Core).

458 For a given Host Processor, the number of instances of CIM_HardwareThread that are associated with
 459 Threading Processor Cores, which in turn are associated with the Host Processor, shall be equal to the
 460 value of the NumberOfHardwareThreads property of the instance of CIM_ProcessorCapabilities that is
 461 associated with the Host Processor.

462 **7.7.1 Hardware thread capabilities**

463 When the CIM_EnabledLogicalElementCapabilities class is instantiated to represent the hardware thread
 464 capabilities, the instance of CIM_EnabledLogicalElementCapabilities shall be associated with the
 465 CIM_HardwareThread instance through an instance of CIM_ElementCapabilities and used for advertising
 466 the capabilities of the CIM_HardwareThread instance.

467 At most one instance of CIM_EnabledLogicalElementCapabilities shall be associated with a given
 468 instance of CIM_HardwareThread.

469 **7.7.1.1 CIM_EnabledLogicalElementCapabilities.RequestedStatesSupported**

470 The RequestedStatesSupported property is an array that contains the supported requested states for the
 471 instance of CIM_HardwareThread. This property shall be the super set of the values to be used as the
 472 RequestedState parameter in the RequestStateChange() method (see 8.3). The value of the
 473 RequestedStatesSupported property shall be an empty array or contain any combination of the following
 474 values: 2 (Enabled), 3 (Disabled), or 11 (Reset).

475 **7.7.1.2 CIM_EnabledLogicalElementCapabilities.ElementNameEditSupported**

476 The ElementNameEditSupported property shall have a value of TRUE when the implementation supports
 477 client modification of the CIM_HardwareThread.ElementName property.

478 **7.7.1.3 CIM_EnabledLogicalElementCapabilities.MaxElementNameLen**

479 The MaxElementNameLen property shall be implemented when the ElementNameEditSupported
 480 property has a value of TRUE.

481 7.7.2 Hardware thread state management

482 Hardware thread state management requires that the `CIM_HardwareThread.RequestStateChange()`
483 method be supported (see 8.3) and the value of the `CIM_HardwareThread.RequestedState` property not
484 match 12 (Not Applicable).

485 7.7.2.1 Hardware thread state management support

486 When no `CIM_EnabledLogicalElementCapabilities` instance is associated with the `CIM_HardwareThread`
487 instance, hardware thread state management shall not be supported.

488 When a `CIM_EnabledLogicalElementCapabilities` instance is associated with the `CIM_HardwareThread`
489 instance but the value of the `CIM_EnabledLogicalElementCapabilities.RequestedStatesSupported`
490 property is an empty array, hardware thread state management shall not be supported.

491 When a `CIM_EnabledLogicalElementCapabilities` instance is associated with the `CIM_HardwareThread`
492 instance and the value of the `CIM_EnabledLogicalElementCapabilities.RequestedStatesSupported`
493 property is not an empty array, hardware thread state management shall be supported.

494 7.7.3 `CIM_HardwareThread.RequestedState`

495 The `CIM_HardwareThread.RequestedState` property shall have a value of 12 (Not Applicable) or 5 (No
496 Change), or a value contained in the
497 `CIM_EnabledLogicalElementCapabilities.RequestedStatesSupported` property array of the associated
498 `CIM_EnabledLogicalElementCapabilities` instance (see 7.7.1.1).

499 When hardware thread state management is supported and the `RequestStateChange()` method is
500 successfully executed, the `RequestedState` property shall be set to the value of the `RequestedState`
501 parameter of the `RequestStateChange()` method. After the `RequestStateChange()` method has
502 successfully executed, the `RequestedState` and `EnabledState` properties shall have equal values with the
503 exception of the transitional requested state 11 (Reset). The value of the `RequestedState` property may
504 also change as a result of a request for a change to the hardware thread's enabled state by a non-CIM
505 implementation.

506 7.7.3.1 RequestedState — 12 (Not Applicable) value

507 When hardware thread state management is not supported, the value of the
508 `CIM_HardwareThread.RequestedState` property shall be 12 (Not Applicable).

509 7.7.3.2 RequestedState — 5 (No Change) value

510 When hardware thread state management is supported, the initial value of the
511 `CIM_HardwareThread.RequestedState` property shall be 5 (No Change).

512 7.7.4 `CIM_HardwareThread.EnabledState`

513 Table 7 describes the mapping between the values of the `CIM_HardwareThread.EnabledState` property
514 and the corresponding description of the state of the hardware thread. The `EnabledState` property shall
515 match the values that are specified in Table 7. When the `RequestStateChange()` method executes but
516 does not complete successfully, and the hardware thread is in an indeterminate state, the `EnabledState`
517 property shall have a value of 5 (Not Applicable). The value of this property may also change as a result
518 of a change to the hardware thread's enabled state by a non-CIM implementation.

519

Table 7 – CIM_HardwareThread.EnabledState Value Descriptions

Value	Description	Extended Description
2	Enabled	Hardware thread shall be enabled.
3	Disabled	Hardware thread shall be disabled.
5	Not Applicable	Hardware thread state is indeterminate, or hardware thread state management is not supported.

520 7.8 Modeling cache memory

521 Modeling the cache memory of the processor is optional. The implementation may instantiate instances of
522 CIM_Memory to represent the cache memory. All the requirements in this clause and its subclauses are
523 applicable when an implementation instantiates the CIM_Memory class that represents cache memory.

524 A single instance of CIM_Memory shall exist for each discrete cache memory. When the cache memory is
525 shared, the single instance of CIM_Memory shall be associated with multiple instances of CIM_Processor
526 or CIM_ProcessorCore. When the cache memory is not shared, the instance of CIM_Memory shall be
527 associated with exactly one instance of CIM_Processor or CIM_ProcessorCore.

528 When the optional behavior described in 7.6 is implemented, each instance of CIM_Memory that
529 represents the cache memory used by the processor core shall be associated with the instance of
530 CIM_ProcessorCore that represents the processor core through an instance of
531 CIM_AssociatedCacheMemory and shall not be associated with the Host Processor of the core.

532 When the optional behavior described in 7.6 is not implemented, each instance of CIM_Memory that
533 represents the cache memory used by the processor shall be associated through an instance of the
534 CIM_AssociatedCacheMemory to the instance of CIM_Processor.

535 7.8.1 Cache memory capabilities

536 When the CIM_EnabledLogicalElementCapabilities class is instantiated to represent the cache memory
537 capabilities, the instance of CIM_EnabledLogicalElementCapabilities shall be associated with the
538 CIM_Memory instance through an instance of CIM_ElementCapabilities and used for advertising the
539 capabilities of the CIM_Memory instance.

540 At most one instance of CIM_EnabledLogicalElementCapabilities shall be associated with a given
541 instance of CIM_Memory.

542 7.8.1.1 CIM_EnabledLogicalElementCapabilities.RequestedStatesSupported

543 The RequestedStatesSupported property is an array that contains the supported requested states for the
544 instance of CIM_Memory. This property shall be the super set of the values to be used as the
545 RequestedState parameter in the RequestStateChange() method (see 8.4). The value of the
546 RequestedStatesSupported property shall be an empty array or contain any combination of the following
547 values: 2 (Enabled), 3 (Disabled), or 11 (Reset).

548 7.8.1.2 CIM_EnabledLogicalElementCapabilities.ElementNameEditSupported

549 The ElementNameEditSupported property shall have a value of TRUE when the implementation supports
550 client modification of the CIM_Memory.ElementName property.

551 7.8.1.3 CIM_EnabledLogicalElementCapabilities.MaxElementNameLen

552 The MaxElementNameLen property shall be implemented when the ElementNameEditSupported
553 property has a value of TRUE.

554 7.8.2 Cache memory state management

555 Cache memory state management requires that the `CIM_Memory.RequestStateChange()` method be
556 supported (see 8.4) and the value of the `CIM_Memory.RequestedState` property not match 12 (Not
557 Applicable).

558 7.8.2.1 Cache memory state management support

559 When no `CIM_EnabledLogicalElementCapabilities` instance is associated with the `CIM_Memory` instance,
560 cache memory state management shall not be supported.

561 When a `CIM_EnabledLogicalElementCapabilities` instance is associated with the `CIM_Memory` instance
562 but the value of the `CIM_EnabledLogicalElementCapabilities.RequestedStatesSupported` property is an
563 empty array, cache memory state management shall not be supported.

564 When a `CIM_EnabledLogicalElementCapabilities` instance is associated with the `CIM_Memory` instance
565 and the value of the `CIM_EnabledLogicalElementCapabilities.RequestedStatesSupported` property is not
566 an empty array, cache memory state management shall be supported.

567 7.8.3 CIM_Memory.RequestedState

568 The `CIM_Memory.RequestedState` property shall have a value of 12 (Not Applicable) or 5 (No Change),
569 or a value contained in the `CIM_EnabledLogicalElementCapabilities.RequestedStatesSupported` property
570 array of the associated `CIM_EnabledLogicalElementCapabilities` instance (see 7.8.1.1).

571 When cache memory state management is supported and the `RequestStateChange()` method is
572 successfully executed, the `RequestedState` property shall be set to the value of the `RequestedState`
573 parameter of the `RequestStateChange()` method. After the `RequestStateChange()` method has
574 successfully executed, the `RequestedState` and `EnabledState` properties shall have equal values with the
575 exception of the transitional requested state 11 (Reset). The value of the `RequestedState` property may
576 also change as a result of a request for a change to the cache memory's enabled state by a non-CIM
577 implementation.

578 7.8.3.1 RequestedState — 12 (Not Applicable) value

579 When cache memory state management is not supported, the value of the `CIM_Memory.RequestedState`
580 property shall be 12 (Not Applicable).

581 7.8.3.2 RequestedState — 5 (No Change) value

582 When cache memory state management is supported, the initial value of the
583 `CIM_Memory.RequestedState` property shall be 5 (No Change).

584 7.8.4 CIM_Memory.EnabledState

585 Table 8 describes the mapping between the values of the `CIM_Memory.EnabledState` property and the
586 corresponding description of the state of the cache memory. The `EnabledState` property shall match the
587 values that are specified in Table 8. When the `RequestStateChange()` method executes but does not
588 complete successfully, and the cache memory is in an indeterminate state, the `EnabledState` property
589 shall have value of 5 (Not Applicable). The value of this property may also change as a result of a change
590 to the cache memory's enabled state by a non-CIM implementation.

591

Table 8 – CIM_Memory.EnabledState value descriptions

Value	Description	Extended Description
2	Enabled	Cache memory shall be enabled.
3	Disabled	Cache memory shall be disabled.
5	Not Applicable	Cache memory state is indeterminate, or cache memory state management is not supported.

592 **7.9 Modeling physical aspects of processor and cache memory**

593 The [Physical Asset Profile](#) may be implemented to model the physical aspects of a processor, including
594 the asset information of the processor or the internal or off-chip cache memory.

595 When the processor's or internal cache memory's physical aspects are represented, a CIM_Chip instance
596 shall be instantiated and associated with the instance of CIM_Processor or with any instances of
597 CIM_Memory that represent the internal cache through instances of CIM_Realizes.

598 When the off-chip cache memory is represented along with its physical aspects, a CIM_PhysicalMemory
599 instance shall be instantiated and associated with the instance of CIM_Memory through an instance of
600 CIM_Realizes.

601 When processor cores or hardware threads for the processor are modeled with the physical aspects of
602 the processor, the instances of CIM_ProcessorCore and CIM_HardwareThread shall not be associated
603 with the instance of CIM_Chip that represents the physical aspects of the processor.

604 The configuration capacity of the managed system for processors may be modeled using the optional
605 behavior specified in the "Modeling Configuration Capacity" clause of the [Physical Asset Profile](#).

606 **8 Methods**

607 This clause details the requirements for supporting intrinsic operations and extrinsic methods for the CIM
608 elements defined by this profile.

609 **8.1 CIM_Processor.RequestStateChange()**

610 Invocation of the CIM_Processor.RequestStateChange() method changes the element's state to the
611 value that is specified in the RequestedState parameter.

612 Return code values for the RequestStateChange() method shall be as specified in Table 9. Parameters
613 of the RequestStateChange() method are specified in Table 10.

614 When processor state management is supported, the RequestStateChange() method shall be
615 implemented and shall not return a value of 1 (Not Supported) (see 7.3.1).

616 Invoking the CIM_Processor.RequestStateChange() method multiple times could result in earlier
617 requests being overwritten or lost.

618 No standard messages are defined for this method.

619 **Table 9 – CIM_Processor.RequestStateChange() method: Return code values**

Value	Description
0	Request was successfully executed.
1	Method is not supported in the implementation.
2	Error occurred
4096	Job started

620 **Table 10 – CIM_Processor.RequestStateChange() method: Parameters**

Qualifiers	Name	Type	Description/Values
IN, REQ	RequestedState	uint16	Valid state values: 2 (Enabled) 3 (Disabled) 11 (Reset)
OUT	Job	CIM_ConcreteJob REF	Returned if job started
IN, REQ	TimeoutPeriod	datetime	Client-specified maximum amount of time the transition to a new state is supposed to take: 0 or NULL – No time requirements <interval> – Maximum time allowed

621 **8.2 CIM_ProcessorCore.RequestStateChange()**

622 Invocation of the CIM_ProcessorCore.RequestStateChange() method changes the element’s state to the
623 value that is specified in the RequestedState parameter.

624 Return code values for the RequestStateChange() method shall be as specified in Table 11. Parameters
625 of the RequestStateChange() method are specified in Table 12.

626 When processor core state management is supported, the RequestStateChange() method shall be
627 implemented and shall not return a value of 1 (Not Supported) (see 7.6.2.1).

628 Invoking the CIM_ProcessorCore.RequestStateChange() method multiple times could result in earlier
629 requests being overwritten or lost.

630 No standard messages are defined for this method.

631 **Table 11 – CIM_ProcessorCore.RequestStateChange() method: Return code values**

Value	Description
0	Request was successfully executed.
1	Method is not supported in the implementation.
2	Error occurred
4096	Job started

632

Table 12 – CIM_ProcessorCore.RequestStateChange() method: Parameters

Qualifiers	Name	Type	Description/Values
IN, REQ	RequestedState	uint16	Valid state values: 2 (Enabled) 3 (Disabled) 11 (Reset)
OUT	Job	CIM_ConcreteJob REF	Returned if job started
IN, REQ	TimeoutPeriod	datetime	Client-specified maximum amount of time the transition to a new state is supposed to take: 0 or NULL – No time requirements <interval> – Maximum time allowed

633 8.3 CIM_HardwareThread.RequestStateChange()

634 Invocation of the CIM_HardwareThread.RequestStateChange() method changes the element's state to
635 the value that is specified in the RequestedState parameter.

636 Return code values for the RequestStateChange() method shall be as specified in Table 13. Parameters
637 of the RequestStateChange() method are specified in Table 14.

638 When hardware thread state management is supported, the RequestStateChange() method shall be
639 implemented and shall not return a value of 1 (Not Supported) (see 7.7.2.1).

640 Invoking the CIM_HardwareThread.RequestStateChange() method multiple times could result in earlier
641 requests being overwritten or lost.

642 No standard messages are defined for this method.

643 Table 13 – CIM_HardwareThread.RequestStateChange() method: Return code values

Value	Description
0	Request was successfully executed.
1	Method is not supported in the implementation.
2	Error occurred
4096	Job started

644

Table 14 – CIM_HardwareThread.RequestStateChange() method: Parameters

Qualifiers	Name	Type	Description/Values
IN, REQ	RequestedState	uint16	Valid state values: 2 (Enabled) 3 (Disabled) 11 (Reset)
OUT	Job	CIM_ConcreteJob REF	Returned if job started
IN, REQ	TimeoutPeriod	datetime	Client-specified maximum amount of time the transition to a new state is supposed to take: 0 or NULL – No time requirements <interval> – Maximum time allowed

645 **8.4 CIM_Memory.RequestStateChange()**

646 Invocation of the CIM_Memory.RequestStateChange() method changes the element’s state to the value
647 that is specified in the RequestedState parameter.

648 Return code values for the RequestStateChange() method shall be as specified in Table 15. Parameters
649 of the RequestStateChange() method are specified in Table 16.

650 When memory state management is supported, the RequestStateChange() method shall be implemented
651 and shall not return a value of 1 (Not Supported) (see 7.8.2.1).

652 Invoking the CIM_Memory.RequestStateChange() method multiple times could result in earlier requests
653 being overwritten or lost.

654 No standard messages are defined for this method.

655 **Table 15 – CIM_Memory.RequestStateChange() method: Return code values**

Value	Description
0	Request was successfully executed.
1	Method is not supported in the implementation.
2	Error occurred
4096	Job started

656 **Table 16 – CIM_Memory.RequestStateChange() method: Parameters**

Qualifiers	Name	Type	Description/Values
IN, REQ	RequestedState	uint16	Valid state values: 2 (Enabled) 3 (Disabled) 11 (Reset)
OUT	Job	CIM_ConcreteJob REF	Returned if job started
IN, REQ	TimeoutPeriod	datetime	Client-specified maximum amount of time the transition to a new state is supposed to take: 0 or NULL – No time requirements <interval> – Maximum time allowed

657 **8.5 Profile conventions for operations**

658 This profile specification defines operations in terms of [DSP0200](#).

659 For each profile class (including associations), the implementation requirements for operations, including
660 those in the following default list, are specified in class-specific subclauses of this clause.

661 The default list of operations is as follows:

- 662 • Associators()
- 663 • AssociatorNames()
- 664 • EnumerateInstances()

- 665 • EnumerateInstanceNames()
- 666 • GetInstance()
- 667 • References()
- 668 • ReferenceNames()

669 8.6 CIM_AssociatedCacheMemory

670 Table 17 lists implementation requirements for operations. If implemented, these operations shall be
 671 implemented as defined in [DSP0200](#). In addition, and unless otherwise stated in Table 17, all operations
 672 in the default list in 8.5 shall be implemented as defined in [DSP0200](#).

673 NOTE Related profiles may define additional requirements on operations for the profile class.

674 **Table 17 – Operations: CIM_AssociatedCacheMemory**

Operation	Requirement	Messages
Associators	Unspecified	None
AssociatorNames	Unspecified	None
References	Unspecified	None
ReferenceNames	Unspecified	None

675 8.7 CIM_ConcreteComponent — References CIM_HardwareThread and 676 CIM_Processor

677 Table 18 lists implementation requirements for operations. If implemented, these operations shall be
 678 implemented as defined in [DSP0200](#). In addition, and unless otherwise stated in Table 18, all operations
 679 in the default list in 8.5 shall be implemented as defined in [DSP0200](#).

680 NOTE Related profiles may define additional requirements on operations for the profile class.

681 **Table 18 – Operations: CIM_ConcreteComponent**

Operation	Requirement	Messages
Associators	Unspecified	None
AssociatorNames	Unspecified	None
References	Unspecified	None
ReferenceNames	Unspecified	None

682 8.8 CIM_ConcreteComponent — References CIM_ProcessorCore and 683 CIM_Processor

684 Table 19 lists implementation requirements for operations. If implemented, these operations shall be
 685 implemented as defined in [DSP0200](#). In addition, and unless otherwise stated in Table 19, all operations
 686 in the default list in 8.5 shall be implemented as defined in [DSP0200](#).

687 NOTE Related profiles may define additional requirements on operations for the profile class.

688

Table 19 – Operations: CIM_ConcreteComponent

Operation	Requirement	Messages
Associators	Unspecified	None
AssociatorNames	Unspecified	None
References	Unspecified	None
ReferenceNames	Unspecified	None

689

8.9 CIM_ElementCapabilities — References CIM_HardwareThread and CIM_EnabledLogicalElementCapabilities

690

691 Table 20 lists implementation requirements for operations. If implemented, these operations shall be
 692 implemented as defined in [DSP0200](#). In addition, and unless otherwise stated in Table 20, all operations
 693 in the default list in 8.5 shall be implemented as defined in [DSP0200](#).

694 NOTE Related profiles may define additional requirements on operations for the profile class.

695

Table 20 – Operations: CIM_ElementCapabilities

Operation	Requirement	Messages
Associators	Unspecified	None
AssociatorNames	Unspecified	None
References	Unspecified	None
ReferenceNames	Unspecified	None

696

8.10 CIM_ElementCapabilities — References CIM_Memory and CIM_EnabledLogicalElementCapabilities

697

698 Table 21 lists implementation requirements for operations. If implemented, these operations shall be
 699 implemented as defined in [DSP0200](#). In addition, and unless otherwise stated in Table 21, all operations
 700 in the default list in 8.5 shall be implemented as defined in [DSP0200](#).

701 NOTE Related profiles may define additional requirements on operations for the profile class.

702

Table 21 – Operations: CIM_ElementCapabilities

Operation	Requirement	Messages
Associators	Unspecified	None
AssociatorNames	Unspecified	None
References	Unspecified	None
ReferenceNames	Unspecified	None

703

8.11 CIM_ElementCapabilities — References CIM_Processor and CIM_ProcessorCapabilities

704

705 Table 22 lists implementation requirements for operations. If implemented, these operations shall be
 706 implemented as defined in [DSP0200](#). In addition, and unless otherwise stated in Table 22, all operations
 707 in the default list in 8.5 shall be implemented as defined in [DSP0200](#).

708 NOTE Related profiles may define additional requirements on operations for the profile class.

709

Table 22 – Operations: CIM_ElementCapabilities

Operation	Requirement	Messages
Associators	Unspecified	None
AssociatorNames	Unspecified	None
References	Unspecified	None
ReferenceNames	Unspecified	None

710

8.12 CIM_ElementCapabilities — References CIM_ProcessorCore and CIM_EnabledLogicalElementCapabilities

711

712 Table 23 lists implementation requirements for operations. If implemented, these operations shall be
 713 implemented as defined in [DSP0200](#). In addition, and unless otherwise stated in Table 23, all operations
 714 in the default list in 8.5 shall be implemented as defined in [DSP0200](#).

715 NOTE Related profiles may define additional requirements on operations for the profile class.

716

Table 23 – Operations: CIM_ElementCapabilities

Operation	Requirement	Messages
Associators	Unspecified	None
AssociatorNames	Unspecified	None
References	Unspecified	None
ReferenceNames	Unspecified	None

8.13 CIM_EnabledLogicalElementCapabilities

717

718 All operations in the default list in 8.5 shall be implemented as defined in [DSP0200](#).

719 NOTE Related profiles may define additional requirements on operations for the profile class.

8.14 CIM_HardwareThread

720

721 Table 24 lists implementation requirements for operations. If implemented, these operations shall be
 722 implemented as defined in [DSP0200](#). In addition, and unless otherwise stated in Table 24, all operations
 723 in the default list in 8.5 shall be implemented as defined in [DSP0200](#).

724 NOTE Related profiles may define additional requirements on operations for the profile class.

725

Table 24 – Operations: CIM_HardwareThread

Operation	Requirement	Messages
ModifyInstance	Optional. See 8.14.1.	None

8.14.1 CIM_HardwareThread — ModifyInstance

726

727 This clause details the requirements for the ModifyInstance operation applied to an instance of
 728 CIM_HardwareThread. The ModifyInstance operation may be supported.

729 The ModifyInstance operation shall be supported and the CIM_HardwareThread.ElementName property
 730 shall be modifiable when the ElementNameEditSupported property of the

731 CIM_EnabledLogicalElementCapabilities instance that is associated with the CIM_HardwareThread
 732 instance has a value of TRUE. See 7.7.1.2.

733 **8.15 CIM_Memory**

734 Table 25 lists implementation requirements for operations. If implemented, these operations shall be
 735 implemented as defined in [DSP0200](#). In addition, and unless otherwise stated in Table 25, all operations
 736 in the default list in 8.5 shall be implemented as defined in [DSP0200](#).

737 NOTE Related profiles may define additional requirements on operations for the profile class.

738 **Table 25 – Operations: CIM_Memory**

Operation	Requirement	Messages
ModifyInstance	Optional. See 8.15.1.	None

739 **8.15.1 CIM_Memory — ModifyInstance**

740 This clause details the requirements for the ModifyInstance operation applied to an instance of
 741 CIM_Memory. The ModifyInstance operation may be supported.

742 The ModifyInstance operation shall be supported and the CIM_Memory.ElementName property shall be
 743 modifiable when the ElementNameEditSupported property of the
 744 CIM_EnabledLogicalElementCapabilities instance that is associated with the CIM_Memory instance has
 745 a value of TRUE. See clause 7.8.1.2.

746 **8.16 CIM_Processor**

747 Table 26 lists implementation requirements for operations. If implemented, these operations shall be
 748 implemented as defined in [DSP0200](#). In addition, and unless otherwise stated in Table 26, all operations
 749 in the default list in 8.5 shall be implemented as defined in [DSP0200](#).

750 NOTE Related profiles may define additional requirements on operations for the profile class.

751 **Table 26 – Operations: CIM_Processor**

Operation	Requirement	Messages
ModifyInstance	Optional. See 8.16.1.	None

752 **8.16.1 CIM_Processor — ModifyInstance**

753 This clause details the requirements for the ModifyInstance operation applied to an instance of
 754 CIM_Processor. The ModifyInstance operation may be supported.

755 The ModifyInstance operation shall be supported and the CIM_Processor.ElementName property shall be
 756 modifiable when the ElementNameEditSupported property of the
 757 CIM_EnabledLogicalElementCapabilities instance that is associated with the CIM_Processor instance
 758 has a value of TRUE. See 7.2.4.

759 **8.17 CIM_ProcessorCapabilities**

760 All operations in the default list in 8.5 shall be implemented as defined in [DSP0200](#).

761 NOTE Related profiles may define additional requirements on operations for the profile class.

762 **8.18 CIM_ProcessorCore**

763 Table 27 lists implementation requirements for operations. If implemented, these operations shall be
 764 implemented as defined in [DSP0200](#). In addition, and unless otherwise stated in Table 27, all operations
 765 in the default list in 8.5 shall be implemented as defined in [DSP0200](#).

766 NOTE Related profiles may define additional requirements on operations for the profile class.

767 **Table 27 – Operations: CIM_ProcessorCore**

Operation	Requirement	Messages
ModifyInstance	Optional. See 8.18.1.	None

768 **8.18.1 CIM_ProcessorCore — ModifyInstance**

769 This clause details the requirements for the ModifyInstance operation applied to an instance of
 770 CIM_ProcessorCore. The ModifyInstance operation may be supported.

771 The ModifyInstance operation shall be supported and the CIM_ProcessorCore.ElementName property
 772 shall be modifiable when the ElementNameEditSupported property of the
 773 CIM_EnabledLogicalElementCapabilities instance that is associated with the CIM_ProcessorCore
 774 instance has a value of TRUE. See 7.6.1.2.

775 **8.19 CIM_SystemDevice**

776 Table 28 lists implementation requirements for operations. If implemented, these operations shall be
 777 implemented as defined in [DSP0200](#). In addition, and unless otherwise stated in Table 28, all operations
 778 in the default list in 8.5 shall be implemented as defined in [DSP0200](#).

779 NOTE Related profiles may define additional requirements on operations for the profile class.

780 **Table 28 – Operations: CIM_SystemDevice**


Operation	Requirement	Messages
Associators	Unspecified	None
AssociatorNames	Unspecified	None
References	Unspecified	None
ReferenceNames	Unspecified	None

781 **9 Use cases**

782 This clause contains object diagrams and use cases for the *CPU Profile*.

783 **9.1 Object diagrams**

784 Figure 2 represents a possible instantiation of the *CPU Profile*. In this instantiation, cpu1 belongs to
 785 system1. The capabilities of cpu1 are represented with capabilities1. cpu1 has cache memory
 786 represented by memory1. The *CPU Profile* implementation and versioning information is advertised
 787 through profile2.




788

789

Figure 2 – Registered Profile

790 Figure 3 represents a possible instantiation of the *CPU Profile* representing a dual core processor, cpu1.
 791 The individual cores and hardware threads of cpu1 are not represented, but capabilities1 advertises that
 792 cpu1 is a dual core processor capable of two hardware threads, one thread per each core. If system1
 793 supports [SMBIOS Reference Specification 2.6](#) or later, the value of the NumberOfProcessorCores
 794 property will be equal to the SMBIOS Processor Information structure's Core Count structure value, and
 795 the value of the NumberOfHardwareThreads property will be equal to the SMBIOS Processor Information
 796 structure's Thread Count structure value. memory1 and memory2 are the cache memories of cpu1.
 797 Memory1 represents the level 1 cache, and memory2 is the level 2 cache, as denoted by the instances of
 798 CIM_AssociatedCacheMemory that associate memory1 and memory2 with cpu1. The physical aspects of
 799 cpu1 are represented by chip1, associated to cpu1 through an instance of CIM_Realizes.




800

801

Figure 3 – Multi-core CPU

802 Figure 4 represents a possible instantiation of the *CPU Profile* representing a dual core processor, cpu1.
 803 Each of the processor cores is represented by an instance of CIM_ProcessorCore: core1 and core2,
 804 associated to the Host Processor, cpu1, through instances of CIM_ConcreteComponent. Each of the
 805 cores has one hardware thread, represented by thread1 and thread2, associated with it through instances
 806 of CIM_ConcreteComponent. The cache memories, memory1 and memory2, are associated to the
 807 processor cores that use them. Based on the capabilities of core1 and core2, represented by
 808 capabilities2, both processor cores can be enabled or disabled using the RequestStateChange() method.
 809 Figure 5 shows the same instantiation of *CPU Profile* after the RequestStateChange() method on core2
 810 has successfully executed.




811

812

Figure 4 – Detailed multi-core CPU

813 Figure 5 represents a possible instantiation of the *CPU Profile* in which one of the cores of a dual core
 814 processor, cpu1, has been disabled by the user using the RequestStateChange() method. core2's
 815 EnabledState property has value of 3 (Disabled) and the CoreEnabledState property has value 4 (Core
 816 Disabled by User).




817

818

Figure 5 – Multi-core CPU with a disabled core

819 Figure 6 represents a possible instantiation of the *CPU Profile* representing a single core processor with
 820 multiple threads. thread1 and thread2 represent the hardware threads that exist on core1 and are
 821 associated to core1 through an instance of CIM_ConcreteComponent. cpu1 advertises the capabilities of
 822 multiple hardware threads through the capabilities1 NumberOfProcessorThreads property. The cache
 823 memory, memory1, is associated to core1, which is using the cache memory.




824

825

Figure 6 – Single Core, Multi-Hardware Thread CPU

826 Figure 7 represents another instantiation of the *CPU Profile*. In this case, cpu1's cache memory,
 827 memory1, has a separate package represented by pmem1 and associated to memory1 through an
 828 instance of CIM_Realizes. The existence of pmem1 associated with the cpu1's cache memory indicates
 829 that the processor uses off-chip cache memory.



830

831

Figure 7 – Processor with Off-Chip Cache

832 **9.2 Change the enabled state of the memory to the desired state**

833 A client can change the enabled state of the memory as follows:

- 834 1) Select the instance of CIM_Memory.
- 835 2) Select the associated instance of CIM_EnabledLogicalElementCapabilities and verify whether
836 the RequestedStatesSupported property contains the desired state.
- 837 3) If the RequestedStatesSupported property contains the desired state, select the instance of
838 CIM_Memory and execute the RequestStateChange() method with the desired state as a
839 RequestedState parameter.

840 After the successful execution of the method, the EnabledState property of the instance of CIM_Memory
841 will have the value of the desired state.

842 **9.3 Change the enabled state of the CPU to the desired state**

843 A client can change the enabled state of the CPU as follows:

- 844 1) Select the instance of CIM_Processor.
- 845 2) Select the associated instance of CIM_ProcessorCapabilities and verify whether the
846 RequestedStatesSupported property contains the desired state.
- 847 3) If the RequestedStatesSupported property contains the desired state, select the instance of
848 CIM_Processor and execute the RequestStateChange() method with the desired state as a
849 RequestedState parameter.

850 After the successful execution of the method, the EnabledState property of the instance of
851 CIM_Processor will have the value of the desired state.

852 **9.4 Change the enabled state of the CPU's core to the desired state**

853 A client can change the enabled state of the CPU's core as follows:

- 854 1) Select the instance of CIM_ProcessorCore.
- 855 2) Select the associated instance of CIM_EnabledLogicalElementCapabilities and verify whether
856 the RequestedStatesSupported property contains the desired state.
- 857 3) If the RequestedStatesSupported property contains the desired state, select the instance of
858 CIM_ProcessorCore and execute the RequestStateChange() method with the desired state as
859 a RequestedState parameter.

860 After the successful execution of the method, the EnabledState property of the instance of
861 CIM_ProcessorCore will have the value of the desired state.

862 **9.5 Change the enabled state of the CPU's hardware thread to the desired state**

863 A client can change the enabled state of the CPU's hardware thread as follows:

- 864 1) Select the instance of CIM_HardwareThread.
- 865 2) Select the associated instance of CIM_EnabledLogicalElementCapabilities and verify whether
866 the RequestedStatesSupported property contains the desired state.
- 867 3) If the RequestedStatesSupported property contains the desired state, select the instance of
868 CIM_ProcessorThread and execute the RequestStateChange() method with the desired state
869 as a RequestedState parameter.

870 After the successful execution of the method, the EnabledState property of the instance of
 871 CIM_HardwareThread will have the value of the desired state.

872 **9.6 Retrieve all the processor cores for the CPU**

873 A client can retrieve all of the processor cores for the CPU by selecting all the CIM_ProcessorCore
 874 instances that are associated with the given instance of CIM_Processor through instances of
 875 CIM_Component.

876 **9.7 Retrieve all the hardware threads for the CPU**

877 A client can retrieve all of the hardware threads for the CPU as follows:

- 878 1) Select all the CIM_ProcessorCore instances that are associated with the given instance of
 879 CIM_Processor through instances of CIM_Component.
- 880 2) For each instance of CIM_ProcessorCore, select the instances of CIM_HardwareThread that
 881 are associated through instances of CIM_Component.

882 **9.8 Retrieve CPU’s cache memory information for the CPU**

883 A client can retrieve the CPU’s cache memory information as follows:

- 884 1) Select all the instances of CIM_ProcessorCore that are associated with the given instance of
 885 CIM_Processor through instances of CIM_Component.
- 886 2) If no instance of CIM_ProcessorCore exists, select the instances of
 887 CIM_AssociatedCacheMemory that reference the given instance of CIM_Processor, as well as
 888 all the instances of CIM_Memory that are associated with the given instance of CIM_Processor
 889 through instances of CIM_AssociatedCacheMemory.
- 890 3) Otherwise, for each instance of CIM_ProcessorCore, select the instances of
 891 CIM_AssociatedCacheMemory that reference the instance of CIM_ProcessorCore, as well as
 892 all the instances of CIM_Memory that are associated with the instance of CIM_ProcessorCore
 893 through instances of CIM_AssociatedCacheMemory.

894 **10 CIM Elements**

895 Table 29 shows the instances of CIM Elements for this profile. Instances of the CIM Elements shall be
 896 implemented as described in Table 29. Clauses 7 (“Implementation”) and 8 (“Methods”) may impose
 897 additional requirements on these elements.

898 **Table 29 – CIM Elements: CPU Profile**

Element Name	Requirement	Description
Classes		
CIM_AssociatedCacheMemory	Optional	See 10.1 and 7.8.
CIM_ConcreteComponent (references CIM_HardwareThread and CIM_ProcessorCore)	Optional	See 10.2.
CIM_ConcreteComponent (references CIM_ProcessorCore and CIM_Processor)	Optional	See 10.3.

Element Name	Requirement	Description
CIM_ElementCapabilities (references CIM_HardwareThread and CIM_EnabledLogicalElementCapabilities)	Optional	See 10.4.
CIM_ElementCapabilities (references CIM_Memory and CIM_EnabledLogicalElementCapabilities)	Optional	See 10.5.
CIM_ElementCapabilities (references CIM_Processor and CIM_ProcessorCapabilities)	Optional	See 10.6.
CIM_ElementCapabilities (references CIM_ProcessorCore and CIM_EnabledLogicalElementCapabilities)	Optional	See 10.7.
CIM_EnabledLogicalElementCapabilities	Optional	See 7.6.1, 7.7.1, 7.8.1, and 10.7.
CIM_HardwareThread	Optional	See 10.9.
CIM_Memory	Optional	See 10.10 and 7.8.
CIM_Processor	Mandatory	See 7.1 and 10.11.
CIM_ProcessorCapabilities	Optional	See 7.2 and 10.12.
CIM_ProcessorCore	Optional	See 10.13.
CIM_RegisteredProfile	Mandatory	See 10.14.
CIM_SystemDevice	Mandatory	See 10.15.
Indications		
None defined in this profile		

899 **10.1 CIM_AssociatedCacheMemory**

900 CIM_AssociatedCacheMemory associates an instance of CIM_Processor or CIM_ProcessorCore with an
 901 instance of CIM_Memory that represents the cache memory of the processor. Table 30 contains the
 902 requirements for elements of this class.

903 **Table 30 – Class: CIM_AssociatedCacheMemory**

Elements	Requirement	Notes
Antecedent	Mandatory	Key: This property shall reference the instance of CIM_Memory that represents the cache memory.
Dependent	Mandatory	Key: This property shall reference the instance of CIM_Processor or CIM_ProcessorCore. See 7.8 for more details.
Level	Mandatory	None
WritePolicy	Mandatory	None
CacheType	Mandatory	None
ReadPolicy	Mandatory	None
Associativity	Mandatory	None
OtherLevelDescription	Conditional	This property shall be implemented when the Level property has a value of 1 (Other).
OtherWritePolicyDescription	Conditional	This property shall be implemented when the WritePolicy property has a value of 1 (Other).
OtherCacheTypeDescription	Conditional	This property shall be implemented when the CacheType property has a value of 1 (Other).

904 **10.2 CIM_ConcreteComponent — References CIM_HardwareThread and**
905 **CIM_ProcessorCore**

906 CIM_ConcreteComponent associates an instance of CIM_ProcessorCore (the Threading Processor Core)
 907 with an instance CIM_HardwareThread that represents a hardware thread. CIM_ConcreteComponent
 908 shall be instantiated when the Threading Processor Core and the instance of CIM_HardwareThread are
 909 instantiated. Table 31 contains the requirements for elements of this class.

910 **Table 31 – Class: CIM_ConcreteComponent — References CIM_HardwareThread and**
911 **CIM_ProcessorCore**

Elements	Requirement	Notes
GroupComponent	Mandatory	Key: This property shall reference the Threading Processor Core.
PartComponent	Mandatory	Key: This property shall reference the CIM_HardwareThread that represents the hardware thread.

912 **10.3 CIM_ConcreteComponent — References CIM_ProcessorCore and**
 913 **CIM_Processor**

914 CIM_ConcreteComponent associates an instance of CIM_Processor (the Host Processor) with an
 915 instance CIM_ProcessorCore that represents a processor core. CIM_ConcreteComponent shall be
 916 instantiated when the Host Processor and the instance of CIM_ProcessorCore are instantiated. Table 32
 917 contains the requirements for elements of this class.

918 **Table 32 – Class: CIM_ConcreteComponent — References CIM_ProcessorCore and**
 919 **CIM_Processor**

Elements	Requirement	Notes
GroupComponent	Mandatory	Key: This property shall reference the Host Processor.
PartComponent	Mandatory	Key: This property shall reference the CIM_ProcessorCore that represents the hosted processor cores.

920 **10.4 CIM_ElementCapabilities — References CIM_HardwareThread and**
 921 **CIM_EnabledLogicalElementCapabilities**

922 CIM_ElementCapabilities associates an instance of CIM_HardwareThread with the instance of
 923 CIM_EnabledLogicalElementCapabilities that describes the capabilities of the instance of
 924 CIM_HardwareThread.

925 CIM_ElementCapabilities is mandatory when the instance of CIM_HardwareThread and the instance of
 926 CIM_EnabledLogicalElementCapabilities that describes the capabilities of the instance of
 927 CIM_HardwareThread exist. Table 33 contains the requirements for elements of this class.

928 **Table 33 – Class: CIM_ElementCapabilities — References CIM_HardwareThread and**
 929 **CIM_EnabledLogicalElementCapabilities**

Elements	Requirement	Notes
ManagedElement	Mandatory	Key: This property shall reference the instance of CIM_HardwareThread.
Capabilities	Mandatory	Key: This property shall reference the instance of CIM_EnabledLogicalElementCapabilities.

930 **10.5 CIM_ElementCapabilities — References CIM_Memory and**
 931 **CIM_EnabledLogicalElementCapabilities**

932 CIM_ElementCapabilities associates an instance of CIM_Memory with the instance of
 933 CIM_EnabledLogicalElementCapabilities that describes the capabilities of the instance of CIM_Memory.

934 CIM_ElementCapabilities is mandatory when the instance of CIM_Memory and the instance of
 935 CIM_EnabledLogicalElementCapabilities that describes the capabilities of the instance of CIM_Memory
 936 exist. Table 34 contains the requirements for elements of this class.

937
938**Table 34 – Class: CIM_ElementCapabilities — References CIM_Memory and CIM_EnabledLogicalElementCapabilities**

Elements	Requirement	Notes
ManagedElement	Mandatory	Key: This property shall reference the instance of CIM_Memory.
Capabilities	Mandatory	Key: This property shall reference the instance of CIM_EnabledLogicalElementCapabilities.

939
940**10.6 CIM_ElementCapabilities — References CIM_Processor and CIM_ProcessorCapabilities**941
942

CIM_ElementCapabilities associates an instance of CIM_Processor with the instance of CIM_ProcessorCapabilities that describes the capabilities of the instance of CIM_Processor.

943
944

CIM_ElementCapabilities is mandatory when the instance of CIM_Processor and the instance of CIM_ProcessorCapabilities exist. Table 35 contains the requirements for elements of this class.

945
946**Table 35 – Class: CIM_ElementCapabilities — References CIM_Processor and CIM_ProcessorCapabilities**

Elements	Requirement	Notes
ManagedElement	Mandatory	Key: This property shall reference the instance of CIM_Processor.
Capabilities	Mandatory	Key: This property shall reference the instance of CIM_ProcessorCapabilities.

947
948**10.7 CIM_ElementCapabilities — References CIM_ProcessorCore and CIM_EnabledLogicalElementCapabilities**949
950
951

CIM_ElementCapabilities associates an instance of CIM_ProcessorCore with the instance of CIM_EnabledLogicalElementCapabilities that describes the capabilities of the instance of CIM_ProcessorCore.

952
953
954

CIM_ElementCapabilities is mandatory when the instance of CIM_ProcessorCore and the instance of CIM_EnabledLogicalElementCapabilities that describes the capabilities of the instance of CIM_ProcessorCore exist. Table 36 contains the requirements for elements of this class.

955
956**Table 36 – Class: CIM_ElementCapabilities — References CIM_ProcessorCore and CIM_EnabledLogicalElementCapabilities**

Elements	Requirement	Notes
ManagedElement	Mandatory	Key: This property shall reference the instance of CIM_ProcessorCore.
Capabilities	Mandatory	Key: This property shall reference the instance of CIM_EnabledLogicalElementCapabilities.

957 **10.8 CIM_EnabledLogicalElementCapabilities**

958 CIM_EnabledLogicalElementCapabilities represents the capabilities of the memory, the processor core,
 959 or the hardware thread. Table 37 contains the requirements for elements of this class.

960 **Table 37 – Class: CIM_EnabledLogicalElementCapabilities**

Elements	Requirement	Notes
InstanceID	Mandatory	Key
RequestedStatesSupported	Mandatory	See 7.6.1.1, 7.7.1.1, and 7.8.1.1.
ElementNameEditSupported	Mandatory	See 7.6.1.2, 7.7.1.2, and 7.8.1.1.
MaxElementNameLen	Conditional	See 7.6.1.3, 7.7.1.3, and 7.8.1.3.

961 **10.9 CIM_HardwareThread**

962 CIM_HardwareThread represents the hardware thread of the processor. Table 38 contains the
 963 requirements for elements of this class.

964 **Table 38 – Class: CIM_HardwareThread**

Elements	Requirement	Notes
InstanceID	Mandatory	Key
EnabledState	Mandatory	See 7.7.4.
RequestedState	Mandatory	See 7.7.3.
OperationalStatus	Mandatory	None
HealthState	Mandatory	None
ElementName	Mandatory	The property shall match the pattern “.*”.
RequestStateChange()	Conditional	See 8.3.

965 **10.10 CIM_Memory**

966 CIM_Memory represents the CPU’s cache memory. Table 39 contains the requirements for elements of
 967 this class.

968 **Table 39 – Class: CIM_Memory**

Elements	Requirement	Notes
SystemCreationClassName	Mandatory	Key
CreationClassName	Mandatory	Key
SystemName	Mandatory	Key
DeviceID	Mandatory	Key
BlockSize	Mandatory	None
NumberOfBlocks	Mandatory	None
EnabledState	Mandatory	See 7.8.4.
RequestedState	Mandatory	See 7.8.3.
HealthState	Mandatory	None
OperationalStatus	Mandatory	None
ElementName	Mandatory	The property shall match the pattern “.*”.
RequestStateChange()	Conditional	See 8.4.

969 **10.11 CIM_Processor**

970 CIM_Processor represents the processor or CPU. Table 40 contains the requirements for elements of this
 971 class.

972 **Table 40 – Class: CIM_Processor**

Elements	Requirement	Notes
SystemCreationClassName	Mandatory	Key
SystemName	Mandatory	Key
CreationClassName	Mandatory	Key
DeviceID	Mandatory	Key
Family	Mandatory	None
CurrentClockSpeed	Mandatory	When the EnabledState property has a value of 2 (Enabled), a value of 0 shall indicate that the property value is unknown. When the EnabledState property has a value of 3 (Disabled), this property shall have no meaning.
MaxClockSpeed	Mandatory	When the EnabledState property has a value of 2 (Enabled), a value of 0 shall indicate that the property value is unknown. When the EnabledState property has a value of 3 (Disabled), this property shall have no meaning.
ExternalBusClockSpeed	Mandatory	When the EnabledState property has a value of 2 (Enabled), a value of 0 shall indicate that the property value is unknown. When the EnabledState property has a value of 3 (Disabled), this property shall have no meaning.
CPUStatus	Mandatory	See 7.5.1.
EnabledState	Mandatory	See 7.5.2.
RequestedState	Mandatory	See 7.4.
OperationalStatus	Mandatory	None
HealthState	Mandatory	None
ElementName	Mandatory	The property shall match the pattern “.*”.
OtherFamilyDescription	Conditional	This property shall be implemented if the Family property contains the value “Other”.
RequestStateChange()	Conditional	See 8.1.

973 **10.12 CIM_ProcessorCapabilities**

974 CIM_ProcessorCapabilities represents the capabilities of the processor. Table 41 contains the
 975 requirements for elements of this class.

976 **Table 41 – Class: CIM_ProcessorCapabilities**

Elements	Requirement	Notes
InstanceID	Mandatory	Key
NumberOfProcessorCores	Mandatory	A value of 0 shall mean “Unknown”.
NumberOfHardwareThreads	Mandatory	A value of 0 shall mean “Unknown”.

Elements	Requirement	Notes
RequestedStatesSupported	Mandatory	See 7.2.2.
ElementNameEditSupported	Mandatory	See 7.2.4.
MaxElementNameLen	Conditional	See 7.2.5.

977 **10.13 CIM_ProcessorCore**

978 CIM_ProcessorCore represents the core of the processor. Table 42 contains the requirements for
 979 elements of this class.

980 **Table 42 – Class: CIM_ProcessorCore**

Elements	Requirement	Notes
InstanceID	Mandatory	Key
CoreEnabledState	Mandatory	See 7.6.4.1.
EnabledState	Mandatory	See 7.6.4.2.
RequestedState	Mandatory	See 7.6.3.
OperationalStatus	Mandatory	None
HealthState	Mandatory	None
ElementName	Mandatory	The property shall match the pattern “.*”.
RequestStateChange()	Conditional	See 8.2.

981 **10.14 CIM_RegisteredProfile**

982 The CIM_RegisteredProfile class is defined by the [Profile Registration Profile](#). The requirements denoted
 983 in Table 43 are in addition to those mandated by the [Profile Registration Profile](#).

984 **Table 43 – Class: CIM_RegisteredProfile**

Elements	Requirement	Notes
RegisteredName	Mandatory	This property shall have a value of “CPU”.
RegisteredVersion	Mandatory	This property shall have a value of “1.0.1”.
RegisteredOrganization	Mandatory	This property shall have a value of 2 (DMTF).

985 NOTE Previous versions of this document included the suffix “Profile” for the RegisteredName value. If
 986 implementations querying for the RegisteredName value find the suffix “Profile”, they should ignore the suffix, with
 987 any surrounding white spaces, before any comparison is done with the value as specified in this document.

988 **10.15 CIM_SystemDevice**

989 CIM_SystemDevice associates an instance of CIM_Processor with the instance of CIM_ComputerSystem
 990 of which the CIM_Processor instance is a member. Table 44 contains the requirements for elements of
 991 this class.

992

Table 44 – Class: CIM_SystemDevice

Elements	Requirement	Notes
GroupComponent	Mandatory	Key: This property shall reference the instance of CIM_ComputerSystem of which the instance of CIM_Processor is a member.
PartComponent	Mandatory	Key: This property shall reference the instance of CIM_Processor.

993

994
995
996
997**ANNEX A**
(informative)**Change log**

Version	Date	Description
1.0.0c	2006-07-02	Preliminary Version of the Profile
1.0.0	2008-10-31	Final Version of the Profile
1.0.1	2010-04-22	Released as DMTF Standard — Changed ExternalClockSpeed to ExternalBusClockSpeed in use cases to be in sync with the MOF
1.0.2	2015-05-22	Release as DMTF Standard

998
999