



# Redfish

Document Identifier: DSP2053

Date: 2019-12-06

Version: 2019.4

## Redfish Property Guide

**Document Class: Informative**

**Document Status: Published**

**Document Language: en-US**

Copyright Notice

Copyright © 2019 DMTF. All rights reserved.

DMTF is a not-for-profit association of industry members dedicated to promoting enterprise and systems management and interoperability. Members and non-members may reproduce DMTF Specifications and documents, provided that correct attribution is given. As DMTF Specifications may be revised from time to time, the particular version and release date should always be noted.

Implementation of certain elements of this standard or proposed standard may be subject to third party patent rights, including provisional patent rights (herein "patent rights"). DMTF makes no representations to users of the standard as to the existence of such rights, and is not responsible to recognize, disclose, or identify any or all such third party patent right, owners or claimants, nor for any incomplete or inaccurate identification or disclosure of such rights, owners or claimants. DMTF shall have no liability to any party, in any manner or circumstance, under any legal theory whatsoever, for failure to recognize, disclose, or identify any such third party patent rights, or for such party's reliance on the standard or incorporation thereof in its product, protocols or testing procedures. DMTF shall have no liability to any party implementing such standard, whether such implementation is foreseeable or not, nor to any patent owner or claimant, and shall have no liability or responsibility for costs or losses incurred if a standard is withdrawn or modified after publication, and shall be indemnified and held harmless by any party implementing the standard from any and all claims of infringement by a patent owner for such implementations.

For information about patents held by third-parties that have notified the DMTF that, in their opinion, such patent may relate to or impact implementations of DMTF standards, visit <http://www.dmtf.org/about/policies/disclosures.php>.

This document's normative language is English. Translation into other languages is permitted.

# Overview

The Redfish standard comprises a set of Specifications maintained by the Redfish Forum, a working group within the DMTF. The standard defines a protocol that uses RESTful interfaces to provide access to data and operations associated with the management of systems and networks. One of the strengths of the Redfish protocol is that it works with a wide range of servers: from stand-alone servers to rack-mount and bladed environments to large-scale data centers and cloud environments.

The Redfish standard addresses several key issues for infrastructures that require scalability. Large infrastructures often consist of many simple servers of different makes and types. This hyper-scale usage model requires a new approach to systems management. The Redfish Scalable Platforms Management ("Redfish") protocol addresses these needs by providing a standard protocol based on out-of-band systems management.

With the above goals in mind, the Redfish protocol was designed as an open industry standard to meet scalability requirements in multivendor deployments. It easily integrates with commonly used tools, using RESTful interfaces to perform operations and using JSON and OData formats for data payloads.

## Who should read this document?

This document is intended primarily as a reference for Schema authors to locate existing property definitions within the Redfish Schema. End users and other consumers of Redfish data may also use this guide to look up property definitions without regard to their location in the Schema.

## Where can I find more information?

The following web sites provide more information about the Redfish standard:

- **Redfish Developer Hub:** <http://redfish.dmtf.org> Resources for developers building applications using Redfish. Contains an interactive Schema explorer, hosted Schema and other links.
- **Redfish User Forum:** <http://www.redfishforum.com> User forum monitored by DMTF Redfish personnel to answer questions about any Redfish-related topics:
- **DMTF Github Repositories:** <http://www.github.com/DMTF> Open source tools and libraries for working with the Redfish API.
- **Redfish Standards:** <http://www.dmtf.org/standards/redfish> Schemas, specs, mockups, white papers, FAQ, educational material and more.
- **DMTF Redfish Forum** (Working group that maintains the Redfish standard): <http://www.dmtf.org/standards/spmf> Companies involved, upcoming schedules and future work, charter, and information about joining.

# Using this guide

Every Redfish API response consists of a JSON payload containing properties that are strictly defined by a Schema for that Resource. The Schema defining a particular Resource can be determined from the value of the "@odata.type" property returned in every Redfish response. This guide details the definitions for every Redfish standard property defined in the DMTF-published Redfish Schemas.

The property-level details include:

Column	Purpose
Property Name	The name of the JSON property as it appears, case sensitive, in the JSON payload.
Defined in Schemas	The names of the Redfish Schemas where this property is defined, and therefore in which Resources it may appear. For properties that appear within embedded JSON objects, the object name appears in parentheses.
Type	The JSON data types for the property, which can include boolean, number, string, or object. String types that use defined enumerations state (enum). Number types state units, where used.
Description	The description of the property, as copied directly from the Schema <code>Description</code> definition, or, for properties that appear in multiple Schemas, a general description of its usage in any of the listed Schemas.

# Reference Guide

The DMTF's [Redfish Documentation Generator](#) automatically generates the bulk of the text from the Schema files from the DMTF Redfish Schema DSP8010 bundle and merges that text with supplemental text to build this guide.

Property Name	Defined In Schema(s)	Type	Description
<b>AccelerationFunction</b>	Processor (FPGA > ReconfigurationSlots)	object	The reference to the acceleration function provided by the code programmed into a reconfiguration slot.
<b>AccelerationFunctions</b>	Processor	object	The link to the collection of acceleration functions associated with this processor.
<b>AccelerationFunctionType</b>	AccelerationFunction	string (enum)	The acceleration function type.
<b>AccessCapabilities</b>	Volume	array	Supported IO access capabilities.
<b>AccessKey</b>	Endpoint (ConnectedEntities > GenZ)	string	The Access Key for the entity.
	AddressPool (GenZ)	string	The Access Key required for this address pool.
<b>AccessKeyViolations</b>	PortMetrics (GenZ)	integer	The total number of Access Key Violations detected.
<b>AccessMode</b>	ManagerNetworkProtocol (SNMP > CommunityStrings)	string (enum)	The access level of the SNMP community.
<b>AccountLockoutCounterResetAfter</b>	AccountService	integer (seconds)	The period of time, in seconds, between the last failed login attempt and the reset of the lockout threshold counter. This value must be less than or equal to the AccountLockoutDuration value. A reset sets the counter to `0`.
<b>AccountLockoutCounterResetEnabled</b>	AccountService	boolean	An indication of whether the threshold counter is reset after AccountLockoutCounterResetAfter expires. If `true`, it is reset. If `false`, only a successful login resets the threshold counter and if the user reaches the AccountLockoutThreshold limit, the account will be locked out indefinitely and only an administrator-issued reset clears the threshold counter. If this property is absent, the default is `true`.
<b>AccountLockoutDuration</b>	AccountService	integer (seconds)	The period of time, in seconds, that an account is locked after the number of failed login attempts reaches the account lockout threshold, within the period between the last failed login attempt and the reset of the lockout threshold counter. If this value is `0`, no lockout will occur. If the AccountLockoutCounterResetEnabled value is `false`, this property is

			ignored.
<b>AccountLockoutThreshold</b>	AccountService	integer	The number of allowed failed login attempts before a user account is locked for a specified duration. If `0`, the account is never locked.
<b>AccountProviderType</b>	AccountService (ActiveDirectory), AccountService (LDAP), ExternalAccountProvider	string (enum)	The type of external account provider to which this Service connects.
<b>Accounts</b>	AccountService	object	The collection of manager accounts.
<b>AccountService</b>	ServiceRoot	object	The link to the Account Service.
<b>AccountTypes</b>	ManagerAccount	array	The account types.
<b>Accuracy</b>	MetricDefinition	number	The estimated percent error of measured versus actual values.
	Sensor	number (%)	The estimated percent error of measured versus actual values.
<b>Actions</b>	<i>various</i> (AccelerationFunction, AccountService ... )	object	The available actions for this Resource.
	Circuit, Facility, Outlet, OutletGroup, PowerDistribution, PowerDistributionMetrics, PowerDomain, PowerEquipment, Volume	object	The available actions for this resource.
<b>Activation</b>	Sensor (Thresholds > LowerCaution), Sensor (Thresholds > LowerCritical), Sensor (Thresholds > LowerFatal), Sensor (Thresholds > UpperCaution), Sensor (Thresholds > UpperCritical), Sensor (Thresholds > UpperFatal), Triggers (NumericThresholds > LowerCritical), Triggers (NumericThresholds > LowerWarning), Triggers (NumericThresholds > UpperCritical), Triggers (NumericThresholds > UpperWarning)	string (enum)	The direction of crossing that activates this threshold.
<b>ActiveDirectory</b>	AccountService	object	The first Active Directory external account provider that this Account Service supports.
<b>ActiveLinkTechnology</b>	NetworkPort	string (enum)	Network port active link technology.
<b>ActiveMainsId</b>	PowerDistribution	string	The mains circuit that is switched on

	(TransferConfiguration)		and qualified to supply power to the output circuit.
<b>ActiveSoftwareImage</b>	Manager (Links)	object	The link to the SoftwareInventory Resource that represents the active firmware image for this manager.
	Bios (Links)	object	The link to the SoftwareInventory that represents the active BIOS firmware image.
<b>ActiveWidth</b>	Port	integer	The number of active lanes for this interface.
<b>Add</b>	Manager (Actions > ModifyRedundancySet (Action))	array	An array of managers to add to the redundancy set.
<b>AdditionalExternalAccountProviders</b>	AccountService	object	The additional external account providers that this Account Service uses.
<b>AddResourceBlock (Action)</b>	ComputerSystem (Actions)	object	This action adds a Resource Block to a system.
<b>AddressParityError</b>	MemoryMetrics (HealthData > AlarmTrips)	boolean	An indication of whether an address parity error was detected that a retry could not correct.
<b>AddressPools</b>	Endpoint (Links)	array	An array of links to the address pools associated with this endpoint.
	Zone (Links)	array	An array of links to the address pools associated with this zone.
	Fabric	object	The collection of links to the address pools that this fabric contains.
<b>AddressRangeOffsetMiB</b>	MemoryChunks	integer (mebibytes)	Offset of the memory chunk in the address range in MiB.
<b>AddressRangeType</b>	MemoryChunks	string (enum)	Memory type of this memory chunk.
<b>AdjustedMaxAllowableOperatingValue</b>	Thermal (Temperatures)	integer (Celsius)	Adjusted maximum allowable operating temperature for this equipment based on the current environmental conditions present.
	Sensor	number	The adjusted maximum allowable operating value for this equipment based on the current environmental conditions.
<b>AdjustedMinAllowableOperatingValue</b>	Thermal (Temperatures)	integer (Celsius)	Adjusted minimum allowable operating temperature for this equipment based on the current environmental conditions present.
	Sensor	number	The adjusted minimum allowable operating value for this equipment based on the current environmental conditions.
<b>AlarmTrips</b>	MemoryMetrics (HealthData)	object	Alarm trip information about the memory.
<b>Alias</b>	BootOption	string (enum)	The alias of this boot source.

<b>AliasBootOrder</b>	ComputerSystem (Boot)	array	Ordered array of boot source aliases representing the persistent boot order associated with this computer system.
<b>AllocatedPools</b>	Volume	object	An array of references to StoragePools allocated from this Volume.
<b>AllocationAlignmentMiB</b>	Memory	integer (mebibytes)	The boundary that memory regions are allocated on, measured in mebibytes (MiB).
<b>AllocationIncrementMiB</b>	Memory	integer (mebibytes)	The size of the smallest unit of allocation for a memory region in mebibytes (MiB).
<b>AllowableValues</b>	ActionInfo (Parameters)	array	The allowable values for this parameter as applied to this action target.
<b>AllowedSpeedsMHz</b>	Memory	array (MHz)	Speeds supported by this memory.
<b>AllowFIPVLANDiscovery</b>	NetworkDeviceFunction (FibreChannel)	boolean	An indication of whether the FCoE Initialization Protocol (FIP) populates the FCoE VLAN ID.
<b>AllowOverprovisioning</b>	CompositionService	boolean	An indication of whether this service is allowed to overprovision a composition relative to the composition request.
<b>AllowsBlockProvisioning</b>	MemoryDomain	boolean	An indication of whether this memory domain supports the provisioning of blocks of memory.
<b>AllowsMemoryChunkCreation</b>	MemoryDomain	boolean	An indication of whether this memory domain supports the creation of memory chunks.
<b>AllowsMirroring</b>	MemoryDomain	boolean	An indication of whether this memory domain supports the creation of memory chunks with mirroring enabled.
<b>AllowsSparing</b>	MemoryDomain	boolean	An indication of whether this memory domain supports the creation of memory chunks with sparing enabled.
<b>AllowZoneAffinity</b>	CompositionService	boolean	An indication of whether a client can request that a specific Resource Zone fulfill a composition request.
<b>AlternativeNames</b>	CertificateService (Actions > GenerateCSR (Action))	array	The additional host names of the component to secure.
<b>ApparentVA</b>	<i>various</i> (Circuit (PolyPhasePowerWatts > Line1ToLine2), Circuit (PolyPhasePowerWatts > Line1ToNeutral) ... )	number (V.A)	The product of voltage and current for an AC circuit, in Volt-Ampere units.
<b>AppendLimit</b>	MetricReportDefinition	integer	The maximum number of entries that can be appended to a metric report. When the metric report reaches its limit, its behavior is dictated by the ReportUpdates property.

<b>ApplyTime</b>	UpdateService (HttpPushUriOptions > HttpPushUriApplyTime)	string (enum)	The time when to apply the HttpPushUri-provided software update.
<b>ArchiveFile</b>	MessageRegistryFile (Location)	string	If the service hosts the Message Registry in an archive file, the name of the file within the archive.
	JsonSchemaFile (Location)	string	The name of the file in the archive, if the schema is hosted on the service in an archive file.
<b>ArchiveUri</b>	MessageRegistryFile (Location)	string	If the Message Registry is hosted on the service in an archive file, the link to the archive file.
	JsonSchemaFile (Location)	string	The link to an archive file, if the schema is hosted on the service in an archive file.
<b>ASICManufacturer</b>	FabricAdapter	string	The manufacturer name for the ASIC of this fabric adapter.
<b>ASICPartNumber</b>	FabricAdapter	string	The part number for the ASIC on this fabric adapter.
<b>ASICRevisionIdentifier</b>	FabricAdapter	string	The revision identifier for the ASIC on this fabric adapter.
<b>Assemblies</b>	Assembly	array	The assembly records.
<b>Assembly</b>	Chassis, Drive, Memory, NetworkAdapter, PCleDevice, Power (PowerSupplies), Processor, Storage (StorageControllers), Thermal (Fans)	object	The reference to the Assembly Resource associated with this item.
<b>AssetTag</b>	Chassis, ComputerSystem, Drive, PCleDevice, Storage (StorageControllers), Switch	string	The user-assigned asset tag for this device.
	PowerDistribution	string	The user-assigned asset tag for this equipment.
<b>AssignablePhysicalPorts</b>	NetworkDeviceFunction	array	An array of physical ports to which this network device function may be assigned.
<b>AssignedPrivileges</b>	Role	array	The Redfish privileges for this Role.
<b>AssignReplicaTarget (Action)</b>	Volume (Actions)	object	This action is used to establish a replication relationship by assigning an existing volume to serve as a target replica for an existing source volume.
<b>AssociatedEndpoints</b>	Port (Links)	array	An array of links to the endpoints that connect through this port.
<b>AssociatedNetworkAddresses</b>	NetworkPort	array	An array of configured MAC or WWN network addresses that are



			associated with this network port, including the programmed address of the lowest numbered network device function, the configured but not active address, if applicable, the address for hardware port teaming, or other network addresses.
<b>AssociatedTask</b>	Volume (Operations)	object	A reference to the task associated with the operation if any.
	Drive (Operations)	object	The link to the task associated with the operation, if any.
<b>AttributeName</b>	AttributeRegistry (RegistryEntries > Attributes)	string	The unique name for the attribute.
<b>AttributeRegistry</b>	Bios	string	The Resource ID of the Attribute Registry that has the system-specific information about a BIOS Resource.
<b>Attributes</b>	AttributeRegistry (RegistryEntries)	array	An array of attributes and their possible values.
	Bios	object	The manufacturer- or provider-specific list of BIOS attributes.
<b>Authentication</b>	AccountService (ActiveDirectory), AccountService (LDAP), ExternalAccountProvider	object	The authentication information for the external account provider.
	EventService (SMTP)	string (enum)	The authentication method for the SMTP server.
<b>AuthenticationKey</b>	EventDestination (SNMP), ManagerAccount (SNMP)	string	The secret authentication key for SNMPv3.
<b>AuthenticationKeySet</b>	ManagerAccount (SNMP)	boolean	Indicates if the AuthenticationKey property is set.
<b>AuthenticationMethod</b>	NetworkDeviceFunction (iSCSIBoot)	string (enum)	The iSCSI boot authentication method for this network device function.
<b>AuthenticationModes</b>	HostInterface	array	The authentication modes available on this interface.
<b>AuthenticationProtocol</b>	ManagerNetworkProtocol (SNMP)	string (enum)	The authentication protocol for SNMP.
	EventDestination (SNMP), ManagerAccount (SNMP)	string (enum)	The authentication protocol for SNMPv3.
<b>AuthenticationType</b>	AccountService (ActiveDirectory > Authentication), AccountService (LDAP > Authentication), ExternalAccountProvider (Authentication)	string (enum)	The type of authentication used to connect to the external account provider.
<b>AuthFailureLoggingThreshold</b>	AccountService	integer	The number of authorization failures that are allowed before the failed attempt is logged to the manager log.
<b>AuthNoneRole</b>	HostInterface (Links)	object	The link to the Redfish Role that contains the privileges on this Host Interface when no authentication is

			performed.
<b>AuthNoneRoleId</b>	HostInterface	string	The role when no authentication on this interface is used.
<b>AutoDSTEnabled</b>	Manager	boolean	An indication of whether the manager is configured for automatic Daylight Saving Time (DST) adjustment.
<b>AutoNeg</b>	EthernetInterface	boolean	An indication of whether the speed and duplex are automatically negotiated and configured on this interface.
<b>AutoSpeedNegotiation</b>	NetworkPort (SupportedLinkCapabilities)	boolean	An indication of whether the port is capable of auto-negotiating speed.
<b>AutoTransferEnabled</b>	PowerDistribution (TransferConfiguration)	boolean	Indicates if the qualified alternate mains circuit is automatically switched on when the preferred mains circuit becomes unqualified and is automatically switched off.
<b>AverageConsumedWatts</b>	Power (PowerControl > PowerMetrics)	number (Watts)	The average power level over the measurement window over the last IntervalInMin minutes.
<b>AverageFrequencyMHz</b>	ProcessorMetrics	number (MHz)	The average frequency of the processor.
<b>AveragePowerBudgetMilliWatts</b>	Memory (PowerManagementPolicy)	integer (milliWatts)	Average power budget, in milliwatts.
<b>BandwidthPercent</b>	ProcessorMetrics	number (%)	The CPU bandwidth as a percentage.
	MemoryMetrics	number (%)	The memory bandwidth utilization as a percentage.
<b>BaseDistinguishedNames</b>	ExternalAccountProvider (LDAPService > SearchSettings)	array	The base distinguished names to search an external LDAP service.
	AccountService (ActiveDirectory > LDAPService > SearchSettings), AccountService (LDAP > LDAPService > SearchSettings)	array	The base distinguished names to use to search an external LDAP service.
<b>BaseModuleType</b>	Memory	string (enum)	The base module type of the memory.
<b>BinaryDataURI</b>	Assembly (Assemblies)	string	The URI at which to access an image of the assembly information.
<b>Bios</b>	ComputerSystem	object	The link to the BIOS settings associated with this system.
<b>BiosVersion</b>	ComputerSystem	string	The version of the system BIOS or primary system firmware.
<b>BitRate</b>	SerialInterface	string (enum)	The receive and transmit rate of data flow, typically in bits-per-second (bps), over the serial connection.
<b>BlockSizeBytes</b>	MemoryMetrics	integer (bytes)	The block size, in bytes.

	Volume	integer (bytes)	The size of the smallest addressable unit (Block) of this volume in bytes.
	Drive	integer (bytes)	The size, in bytes, of the smallest addressable unit, or block.
<b>BlocksRead</b>	MemoryMetrics (CurrentPeriod), MemoryMetrics (LifeTime)	integer	The number of blocks read.
<b>BlocksWritten</b>	MemoryMetrics (CurrentPeriod), MemoryMetrics (LifeTime)	integer	The number of blocks written.
<b>Boot</b>	ComputerSystem	object	The boot settings for this system.
<b>BootMode</b>	NetworkDeviceFunction	string (enum)	The boot mode configured for this network device function.
<b>BootNext</b>	ComputerSystem (Boot)	string	The BootOptionReference of the Boot Option to perform a one-time boot from when BootSourceOverrideTarget is `UefiBootNext`.
<b>BootOptionEnabled</b>	BootOption	boolean	An indication of whether the boot option is enabled. If `true`, it is enabled. If `false`, the boot option that the boot order array on the computer system contains is skipped. In the UEFI context, this property shall influence the load option active flag for the boot option.
<b>BootOptionReference</b>	BootOption	string	The unique boot option.
<b>BootOptions</b>	ComputerSystem (Boot)	object	The link to the collection of the UEFI boot options associated with this computer system.
<b>BootOrder</b>	ComputerSystem (Boot)	array	An array of BootOptionReference strings that represent the persistent boot order for with this computer system.
<b>BootOrderPropertySelection</b>	ComputerSystem (Boot)	string (enum)	The name of the boot order property that the system uses for the persistent boot order.
<b>BootPriority</b>	NetworkDeviceFunction (FibreChannel > BootTargets)	integer	The relative priority for this entry in the boot targets array.
<b>BootSourceOverrideEnabled</b>	ComputerSystem (Boot)	string (enum)	The state of the boot source override feature.
<b>BootSourceOverrideMode</b>	ComputerSystem (Boot)	string (enum)	The BIOS boot mode to use when the system boots from the BootSourceOverrideTarget boot source.
<b>BootSourceOverrideTarget</b>	ComputerSystem (Boot)	string (enum)	The current boot source to use at the next boot instead of the normal boot device, if BootSourceOverrideEnabled is `true`.
<b>BootTargets</b>	NetworkDeviceFunction (FibreChannel)	array	An array of Fibre Channel boot targets configured for this network device function.

<b>BranchCircuit</b>	Circuit (Links)	object	A reference to the branch circuit related to this circuit.
	Outlet (Links)	object	A reference to the branch circuit related to this outlet.
<b>Branches</b>	PowerDistribution	object	A link to the branch circuits for this equipment.
<b>BreakerControl (Action)</b>	Circuit (Actions)	object	This action attempts to reset the circuit breaker.
<b>BreakerState</b>	Circuit	string (enum)	The state of the over current protection device.
<b>BusWidthBits</b>	Memory	integer	The bus width, in bits.
<b>Cache</b>	ProcessorMetrics	array	The processor cache metrics.
<b>CacheMiss</b>	ProcessorMetrics (Cache), ProcessorMetrics (CoreMetrics > CoreCache)	number	The number of cache line misses in millions.
<b>CacheMissesPerInstruction</b>	ProcessorMetrics (Cache), ProcessorMetrics (CoreMetrics > CoreCache)	number	The number of cache misses per instruction.
<b>CacheSizeMiB</b>	Memory	integer (mebibytes)	Total size of the cache portion memory in MiB.
<b>CacheSummary</b>	Storage (StorageControllers)	object	The cache memory of the storage controller in general detail.
<b>Calculable</b>	MetricDefinition	string (enum)	An indication of whether the metric can be used in a calculation.
<b>CalculationAlgorithm</b>	MetricDefinition	string (enum)	The calculation that is performed on a source metric to obtain the metric being defined.
<b>CalculationParameters</b>	MetricDefinition	array	The metric properties that are part of the synthesis calculation. This property is present when the MetricType property is 'Synthesized'.
<b>CalculationTimeInterval</b>	MetricDefinition	string	The time interval over which the metric calculation is performed.
<b>Calibration</b>	MetricDefinition	number	The calibration offset added to the metric reading.
<b>Capable</b>	NetworkAdapter (Controllers > ControllerCapabilities > DataCenterBridging)	boolean	An indication of whether this controller is capable of data center bridging (DCB).
<b>CapableLinkSpeedMbps</b>	NetworkPort (SupportedLinkCapabilities)	array	The set of link speed capabilities of this port.
<b>CapableSpeedGbs</b>	Drive	number (Gbit/s)	The speed, in gigabit per second (Gbit/s), at which this drive can communicate to a storage controller in ideal conditions.
<b>Capacity</b>	Volume	object	Capacity utilization.
<b>CapacityBytes</b>	Volume	integer (bytes)	The size in bytes of this Volume.
	SimpleStorage (Devices)	integer	The size, in bytes, of the storage

		(bytes)	device.
	Drive	integer (bytes)	The size, in bytes, of this drive.
<b>CapacityMiB</b>	Memory	integer (mebibytes)	Memory capacity in mebibytes (MiB).
	Processor (ProcessorMemory)	integer (mebibytes)	The memory capacity in MiB.
<b>CapacitySources</b>	Volume	array	An array of space allocations to this volume.
<b>CertificateCollection</b>	CertificateService (Actions > GenerateCSR (Action))	object	The URI of the Certificate Resource Collection where the certificate is installed after the certificate authority (CA) signs the certificate.
<b>CertificateLocations</b>	CertificateService	object	The information about the location of certificates.
<b>Certificates</b>	CertificateLocations (Links)	array	An array of links to the certificates installed on this service.
	AccountService (ActiveDirectory), AccountService (LDAP), ComputerSystem (Boot), ExternalAccountProvider, ManagerAccount, ManagerNetworkProtocol (HTTPS)	object	The reference to a collection of certificates.
<b>CertificateService</b>	ServiceRoot	object	The link to the Certificate Service.
<b>CertificateString</b>	Certificate, CertificateService (Actions > ReplaceCertificate (Action))	string	The string for the certificate.
<b>CertificateType</b>	Certificate, CertificateService (Actions > ReplaceCertificate (Action))	string (enum)	The format of the certificate.
<b>CertificateUri</b>	CertificateService (Actions > ReplaceCertificate (Action))	object	The link to the certificate that is being replaced.
<b>ChallengePassword</b>	Certificate (Actions > Rekey (Action)), Certificate (Actions > Renew (Action)), CertificateService (Actions > GenerateCSR (Action))	string	The challenge password to apply to the certificate for revocation requests.
<b>ChangePassword (Action)</b>	Bios (Actions)	object	This action changes a BIOS password.
<b>Channel</b>	Memory (MemoryLocation)	integer	The channel number to which the memory is connected.
<b>CHAPSecret</b>	NetworkDeviceFunction (iSCSIBoot)	string	The shared secret for CHAP authentication.
<b>CHAPUsername</b>	NetworkDeviceFunction (iSCSIBoot)	string	The user name for CHAP authentication.
<b>Chassis</b>	PowerDistribution (Links)	array	An array of links to the chassis that contain this equipment.

	ComputerSystem (Links), PCIeDevice (Links), ResourceBlock (Links)	array	An array of references to the chassis that either contain or are related to this Resource.
	Drive (Links), EthernetInterface (Links), Memory (Links), Processor (Links), ServiceRoot, SimpleStorage (Links), Switch (Links)	object	The reference to the chassis that either contains or is related to this Resource.
<b>ChassisType</b>	Chassis	string (enum)	The type of physical form factor of the chassis.
<b>CheckConsistency (Action)</b>	Volume (Actions)	object	This action is used to force a check of the Volume's parity or redundant data to ensure it matches calculated values.
<b>CID</b>	Endpoint (ConnectedEntities > GenZ > GCID)	string	The component identifier portion of the GCID for the entity.
<b>CircuitType</b>	Circuit	string (enum)	The type of circuit.
<b>City</b>	CertificateService (Actions > GenerateCSR (Action))	string	The city or locality of the organization making the request.
	Certificate (Issuer), Certificate (Subject)	string	The city or locality of the organization of the entity.
<b>ClassCode</b>	PCIeFunction	string	The Class Code of this PCIe function.
	Endpoint (ConnectedEntities > EntityPcild), Endpoint (Pcild)	string	The class code, subclass code, and programming interface code of this PCIe function.
<b>ClassOfService</b>	Volume (Links)	object	The ClassOfService that this storage volume conforms to.
<b>ClearCurrentPeriod (Action)</b>	MemoryMetrics (Actions)	object	This action sets the CurrentPeriod property's values to 0.
<b>ClearLog (Action)</b>	LogService (Actions)	object	The action to clear the log for this Log Service.
<b>ClientEndpoints</b>	Volume (Links)	array	An array of references to the client Endpoints associated with this volume.
<b>ClosedTransitionAllowed</b>	PowerDistribution (TransferConfiguration)	boolean	Indicates if a make-before-break switching sequence of the mains circuits is permitted when they are both qualified and in synchronization.
<b>ClosedTransitionTimeoutSeconds</b>	PowerDistribution (TransferConfiguration)	integer	The time in seconds to wait for a closed transition to occur.
<b>CollectionDuration</b>	MetricReportDefinition (Metrics)	string	The duration over which the function is computed.
<b>CollectionFunction</b>	MetricReportDefinition (Metrics), TelemetryService (SupportedCollectionFunctions)	string (enum)	The function to run on each metric in the collection.
<b>CollectionTimeScope</b>	MetricReportDefinition (Metrics)	string	The scope of time scope over which

		(enum)	the function is applied.
<b>CommandShell</b>	Manager	object	The command shell service that this manager provides.
<b>CommonName</b>	CertificateService (Actions > GenerateCSR (Action))	string	The fully qualified domain name of the component to secure.
	Certificate (Issuer), Certificate (Subject)	string	The fully qualified domain name of the entity.
<b>CommunityAccessMode</b>	ManagerNetworkProtocol (SNMP)	string (enum)	The access level of the SNMP community.
<b>CommunityString</b>	ManagerNetworkProtocol (SNMP > CommunityStrings)	string	The SNMP community string.
<b>CommunityStrings</b>	ManagerNetworkProtocol (SNMP)	array	The SNMP community strings.
<b>CompletedTaskOverWritePolicy</b>	TaskService	string (enum)	The overwrite policy for completed tasks. This property indicates whether the Task Service overwrites completed task information.
<b>CompositionService</b>	ServiceRoot	object	The link to the Composition Service.
<b>CompositionState</b>	ResourceBlock (CompositionStatus)	string (enum)	The current state of the Resource Block from a composition perspective.
<b>CompositionStatus</b>	ResourceBlock	object	The composition status details for this Resource Block.
<b>Compressed</b>	Volume	boolean	Indicator of whether or not the Volume has compression enabled.
<b>ComputerSystemETag</b>	ComputerSystem (Actions > AddResourceBlock (Action)), ComputerSystem (Actions > RemoveResourceBlock (Action))	string	The current ETag of the system.
<b>ComputerSystems</b>	Chassis (Links), HostInterface (Links), ResourceBlock, ResourceBlock (Links)	array	An array of references to computer systems related to this Resource.
<b>ConfigurationLockCapable</b>	Memory (SecurityCapabilities)	boolean	An indication of whether this memory supports the locking, or freezing, of the configuration.
<b>ConfigurationLocked</b>	Memory	boolean	An indication of whether the configuration of this memory is locked and cannot be altered.
<b>ConnectedEntities</b>	Endpoint	array	All the entities connected to this endpoint.
<b>ConnectedPorts</b>	Endpoint (Links)	array	An array of links to the ports that connect to this endpoint.
	Port (Links)	array	An array of links to the remote ports connected to this port.
<b>ConnectedProcessors</b>	Processor (Links)	array	An array of links to the processors directly connected to this processor.
<b>ConnectedSwitches</b>	Port (Links)	array	An array of links to the switches that connect to the device through this

			port.
<b>ConnectedSwitchPorts</b>	Port (Links)	array	An array of links to the ports that connect to the switch through this port.
<b>ConnectedVia</b>	VirtualMedia	string (enum)	The current virtual media connection method.
<b>ConnectionProtocol</b>	EventService (SMTP)	string (enum)	The connection type to the outgoing SMTP server.
<b>ConnectorType</b>	SerialInterface	string (enum)	The type of connector used for this interface.
<b>ConnectTypesSupported</b>	Manager (CommandShell), Manager (GraphicalConsole), Manager (SerialConsole)	array	An array of connection types that the implementation allows.
<b>ConsistencyCheckRatePercent</b>	Storage (StorageControllers > ControllerRates)	integer	The percentage of controller Resources used for performing a data consistency check on volumes.
<b>ConsistencyGroups</b>	Volume (Links)	array	An array of references to the ConsistencyGroups associated with this volume.
	Storage	object	The consistency groups, each of which contains a set of volumes that are treated by an application or set of applications as a single resource, that are managed by this storage subsystem.
<b>ConsumedPowerWatt</b>	ProcessorMetrics	number (Watts)	The power, in watts, that the processor has consumed.
<b>ConsumingComputerSystems</b>	ComputerSystem (Links)	array	An array of links to ComputerSystems that are realized, in whole or in part, from this ComputerSystem.
<b>ContactPerson</b>	CertificateService (Actions > GenerateCSR (Action))	string	The name of the user making the request.
<b>ContainedBy</b>	Chassis (Links)	object	The link to the chassis that contains this chassis.
<b>ContainedByFacility</b>	Facility (Links)	object	The link to the facility that contains this facility.
<b>ContainedByZones</b>	Zone (Links)	array	An array of links to the zone that contain this zone.
<b>Contains</b>	Chassis (Links)	array	An array of links to any other chassis that this chassis has in it.
<b>ContainsChassis</b>	Facility (Links)	array	An array of links to outermost chassis contained within this facility.
<b>ContainsFacilities</b>	Facility (Links)	array	An array of links to other facilities contained within this facility.
<b>ContainsZones</b>	Zone (Links)	array	An array of links to the zones that are contained by this zone.
<b>Context</b>	Event, Event (Events), EventDestination	string	The client-supplied string that is stored with the event destination subscription.



<b>ControllerCapabilities</b>	NetworkAdapter (Controllers)	object	The capabilities of this controller.
<b>ControllerRates</b>	Storage (StorageControllers)	object	This property describes the various controller rates used for processes such as Volume Rebuild or Consistency Checks.
<b>Controllers</b>	NetworkAdapter	array	The set of network controllers ASICs that make up this NetworkAdapter.
<b>CooledBy</b>	Chassis (Links), ComputerSystem (Links)	array	An array of IDs for Resources that cool this Resource. Normally, this ID is for a chassis or a set of fans.
<b>CoreCache</b>	ProcessorMetrics (CoreMetrics)	array	The cache metrics of this core in the processor.
<b>CoreId</b>	ProcessorMetrics (CoreMetrics)	string	The processor core identifier.
<b>CoreMetrics</b>	ProcessorMetrics	array	The processor core metrics.
<b>CorrectableECCError</b>	MemoryMetrics (HealthData > AlarmTrips)	boolean	An indication of whether the correctable error threshold crossing alarm trip was detected.
<b>CorrectionInMs</b>	Power (PowerControl > PowerLimit)	integer (ms)	The time required for the limiting process to reduce power consumption to below the limit.
<b>Count</b>	ComputerSystem (ProcessorSummary)	integer	The number of physical processors in the system.
<b>Country</b>	Certificate (Issuer), Certificate (Subject)	string	The country of the organization of the entity.
	CertificateService (Actions > GenerateCSR (Action))	string	The two-letter country code of the organization making the request.
<b>Created</b>	LogEntry	string	The date and time when the log entry was created.
<b>CreatedBy</b>	OutletGroup	string	The creator of this outlet group.
	Job	string	The person or program that created this job entry.
<b>CreateReplicaTarget (Action)</b>	Volume (Actions)	object	This action is used to create a new volume resource to provide expanded data protection through a replica relationship with the specified source volume.
<b>CrestFactor</b>	<i>various</i> (Circuit (CurrentAmps), Circuit (PolyPhaseCurrentAmps > Line1) ... )	number	The crest factor for this sensor.
<b>CriticalCircuit</b>	Circuit	boolean	Designates if this is a critical circuit.
<b>CStateResidency</b>	ProcessorMetrics (CoreMetrics)	array	The C-state residency of this core in the processor.
<b>CurrentAmps</b>	Circuit	object	The current reading for this single phase circuit.
	Outlet	object	The current reading for this single phase outlet.
<b>CurrentLinkSpeedMbps</b>	NetworkPort	integer	Network port current link speed.

		(Mbit/s)	
<b>CurrentPeriod</b>	MemoryMetrics	object	The memory metrics since the last reset or ClearCurrentPeriod action.
<b>CurrentSpeedGbps</b>	Port	number (Gbit/s)	The current speed of this port.
<b>CurrentValue</b>	AttributeRegistry (RegistryEntries > Attributes)	boolean, number, string	The placeholder of the current value for the attribute.
<b>DataBits</b>	SerialInterface	string (enum)	The number of data bits that follow the start bit over the serial connection.
<b>DataCenterBridging</b>	NetworkAdapter (Controllers > ControllerCapabilities)	object	Data center bridging (DCB) for this controller.
<b>DataLockCapable</b>	Memory (SecurityCapabilities)	boolean	An indication of whether this memory supports data locking.
<b>DataLossDetected</b>	MemoryMetrics (HealthData)	boolean	An indication of whether data loss was detected.
<b>DataSourceUri</b>	<i>various</i> (Circuit (CurrentAmps), Circuit (EnergykWh) ... )	string	The link to the Resource that provides the data for this sensor.
<b>DataType</b>	ActionInfo (Parameters)	string (enum)	The JSON property type for this parameter.
<b>DataWidthBits</b>	Memory	integer	Data width in bits.
<b>DateTime</b>	JobService, LogService, Manager, TaskService	string	The current date and time, with offset, that the service or manager uses to set or read time.
<b>DateTimeLocalOffset</b>	Manager	string	The time offset from UTC that the DateTime property is in <code>`+HH:MM`</code> format.
	LogService	string	The UTC offset that the current DateTime property value contains in the <code>`+HH:MM`</code> format.
<b>DedicatedSpareDrives</b>	Volume (Links)	array	An array of references to the drives which are dedicated spares for this volume.
<b>Deduplicated</b>	Volume	boolean	Indicator of whether or not the Volume has deduplication enabled.
<b>DefaultRoutingEnabled</b>	Zone	boolean	This property indicates whether routing within this zone is enabled.
<b>DefaultValue</b>	AttributeRegistry (RegistryEntries > Attributes)	boolean, number, string	The default value for the attribute.
<b>DELETE</b>	PrivilegeRegistry (Mappings > OperationMap), PrivilegeRegistry (Mappings > PropertyOverrides > OperationMap), PrivilegeRegistry (Mappings > ResourceURIOverrides > OperationMap),	array	The required privilege for the HTTP DELETE operation.

	PrivilegeRegistry (Mappings > SubordinateOverrides > OperationMap)		
<b>DeleteTargetVolume</b>	Volume (Actions > RemoveReplicaRelationship (Action))	boolean	Indicate whether or not to delete the target volume as part of the operation.
<b>DeliveryRetryAttempts</b>	EventService	integer	The number of times that the POST of an event is retried before the subscription terminates. This retry occurs at the service level, which means that the HTTP POST to the event destination fails with an HTTP `4XX` or `5XX` status code or an HTTP timeout occurs this many times before the event destination subscription terminates.
<b>DeliveryRetryIntervalSeconds</b>	EventService	integer (seconds)	The interval, in seconds, between retry attempts for sending any event.
<b>DeliveryRetryPolicy</b>	EventDestination	string (enum)	This property shall contain the subscription delivery retry policy for events, where the subscription type is RedfishEvent.
<b>DeltaPhysicalContext</b>	Thermal (Temperatures)	string (enum)	The area or device to which the DeltaReadingCelsius temperature measurement applies, relative to PhysicalContext.
<b>DeltaReadingCelsius</b>	Thermal (Temperatures)	number (Celsius)	Delta Temperature reading.
<b>Dependencies</b>	AttributeRegistry (RegistryEntries)	array	An array of dependencies of attributes on this component.
<b>Dependency</b>	AttributeRegistry (RegistryEntries > Dependencies)	object	The dependency expression for one or more attributes in this Attribute Registry.
<b>DependencyFor</b>	AttributeRegistry (RegistryEntries > Dependencies)	string	The AttributeName of the attribute whose change triggers the evaluation of this dependency expression.
<b>DepthMm</b>	Chassis	number (mm)	The depth of the chassis.
<b>Destination</b>	EventDestination	string	The URI of the destination event receiver.
<b>DeviceClass</b>	PCleFunction	string (enum)	The class for this PCIe function.
<b>DeviceEnabled</b>	NetworkDeviceFunction	boolean	An indication of whether the network device function is enabled.
<b>DeviceId</b>	Endpoint (ConnectedEntities > EntityPcid), Endpoint (Pcid), PCleFunction	string	The device ID of this PCIe function.
<b>DeviceID</b>	Memory	string	Device ID.
<b>DeviceLocator</b>	Memory	string	Location of the memory in the platform.

<b>DeviceMaxCount</b>	NetworkAdapter (Controllers > ControllerCapabilities > VirtualizationOffload > VirtualFunction)	integer	The maximum number of virtual functions (VFs) that this controller supports.
<b>Devices</b>	SimpleStorage	array	The storage devices.
<b>DeviceType</b>	PCIeDevice	string (enum)	The device type for this PCIe device.
<b>DHCP</b>	ManagerNetworkProtocol	object	The settings for this manager's DHCPv4 protocol support.
<b>DHCPEnabled</b>	EthernetInterface (DHCPv4)	boolean	An indication of whether DHCP v4 is enabled on this Ethernet interface.
<b>DHCPv4</b>	EthernetInterface	object	DHCPv4 configuration for this interface.
<b>DHCPv6</b>	EthernetInterface, ManagerNetworkProtocol	object	The DHCPv6 protocol configuration for this interface or manager.
<b>DisablePassphrase (Action)</b>	Memory (Actions)	object	Disable passphrase for given regions.
<b>DiscreteTriggerCondition</b>	Triggers	string (enum)	The conditions when a discrete metric triggers.
<b>DiscreteTriggers</b>	Triggers	array	The list of discrete triggers.
<b>DiscreteValues</b>	MetricDefinition	array	This array property specifies possible values of a discrete metric.
<b>DisplayName</b>	Volume	string	A user-configurable string to name the volume.
	AttributeRegistry (RegistryEntries > Attributes), AttributeRegistry (RegistryEntries > Menus)	string	The user-readable display name of the attribute or menu in the defined language.
	BootOption	string	The user-readable display name of the boot option that appears in the boot order list in the user interface.
<b>DisplayOrder</b>	AttributeRegistry (RegistryEntries > Attributes), AttributeRegistry (RegistryEntries > Menus)	integer	The display order, as an integer, that indicates where this attribute or menu appears, in ascending order, relative to other attributes or menus.
<b>DomainID</b>	Switch	integer	The domain ID for this switch.
<b>Drives</b>	Chassis (Links), PCIeFunction (Links), ResourceBlock, Storage, Volume (Links)	array	An array of references to the drives related to this Resource.
<b>DwellTime</b>	<i>various</i> (Sensor (Thresholds > LowerCaution), Sensor (Thresholds > LowerCritical) ... )	string	The duration of the sensor reading before the threshold is exceeded.
<b>EEEEnabled</b>	NetworkPort	boolean	An indication of whether IEEE 802.3az Energy-Efficient Ethernet (EEE) is enabled for this network port.
<b>EffectiveFamily</b>	Processor (ProcessorId)	string	The effective family for this processor.

<b>EffectiveModel</b>	Processor (ProcessorId)	string	The effective model for this processor.
<b>EfficiencyPercent</b>	Power (PowerSupplies)	number (%)	The measured efficiency of this power supply as a percentage.
<b>EgressIdentifier</b>	RouteSetEntry	integer	The egress interface identifier.
<b>EjectMedia (Action)</b>	VirtualMedia (Actions)	object	This action detaches remote media from virtual media.
<b>ElectricalContext</b>	Circuit, Outlet, Sensor	string (enum)	The combination of current-carrying conductors.
<b>Email</b>	CertificateService (Actions > GenerateCSR (Action))	string	The email address of the contact within the organization making the request.
	Certificate (Issuer), Certificate (Subject)	string	The email address of the contact within the organization of the entity.
<b>Enabled</b>	ManagerAccount	boolean	An indication of whether an account is enabled. An administrator can disable it without deleting the user information. If `true`, the account is enabled and the user can log in. If `false`, the account is disabled and, in the future, the user cannot log in.
<b>EnableSNMPv1</b>	ManagerNetworkProtocol (SNMP)	boolean	Indicates if access via SNMPv1 is enabled.
<b>EnableSNMPv2c</b>	ManagerNetworkProtocol (SNMP)	boolean	Indicates if access via SNMPv2c is enabled.
<b>EnableSNMPv3</b>	ManagerNetworkProtocol (SNMP)	boolean	Indicates if access via SNMPv3 is enabled.
<b>Enclosures</b>	Storage (Links)	array	An array of links to the chassis to which this storage subsystem is attached.
<b>Encrypted</b>	Volume	boolean	Is this Volume encrypted.
<b>EncryptionAbility</b>	Drive	string (enum)	The encryption ability of this drive.
<b>EncryptionKey</b>	Storage (Actions > SetEncryptionKey (Action))	string	The encryption key to set on the storage subsystem.
	EventDestination (SNMP)	string	The secret authentication key for SNMPv3.
	ManagerAccount (SNMP)	string	The secret authentication key used in SNMPv3.
<b>EncryptionKeySet</b>	ManagerAccount (SNMP)	boolean	Indicates if the EncryptionKey property is set.
<b>EncryptionProtocol</b>	EventDestination (SNMP), ManagerAccount (SNMP), ManagerNetworkProtocol (SNMP)	string (enum)	The encryption protocol for SNMPv3.
<b>EncryptionStatus</b>	Drive	string (enum)	The status of the encryption of this drive.
<b>EncryptionTypes</b>	Volume	array	The types of encryption used by this

			Volume.
<b>EndpointGroups</b>	Storage	object	All of the endpoint groups, each of which contains a set of endpoints that are used for a common purpose such as an ACL or logical identification, that belong to this storage subsystem.
<b>EndpointProtocol</b>	Endpoint	string (enum)	The protocol supported by this endpoint.
<b>Endpoints</b>	MediaController (Links)	array	An array of links to the endpoints that connect to this media controller.
	MemoryChunks (Links)	array	An array of links to the endpoints that connect to this memory chunk.
	Switch (Links)	array	An array of links to the endpoints that connect to this switch.
	FabricAdapter (Links)	array	An array of links to the endpoints that represent the logical fabric connection to this fabric adapter.
	AddressPool (Links)	array	An array of links to the endpoints that this address pool contains.
	AccelerationFunction (Links), ComputerSystem (Links), Drive (Links), EthernetInterface (Links), NetworkDeviceFunction (Links),  Processor (Links), Storage (StorageControllers > Links), Zone (Links)	array	An array of references to endpoints related to this Resource.
	Fabric	object	The collection of links to the endpoints that this fabric contains.
<b>EndTime</b>	Job, Task	string	The date and time when the job or task was completed.
<b>EndToEndCRCErrors</b>	PortMetrics (GenZ)	integer	The total number of ECRC transient errors detected.
<b>EnergykWh</b>	PowerDistributionMetrics	object	The energy consumption of this unit.
	Circuit	object	The energy reading for this circuit.
	OutletGroup	object	The energy reading for this outlet group.
	Outlet	object	The energy reading for this outlet.
<b>EngineeringChangeLevel</b>	Assembly (Assemblies)	string	The engineering change level of the assembly.
<b>Engineld</b>	ManagerNetworkProtocol (SNMP)	object	The engine ID.
<b>EnterpriseSpecificMethod</b>	ManagerNetworkProtocol (SNMP > Engineld)	string	The enterprise specific method.
<b>Entity</b>	PrivilegeRegistry (Mappings)	string	The Resource name, such as `Manager`.
<b>EntityLink</b>	Endpoint (ConnectedEntities)		The link to the associated entity.

<b>EntityPcild</b>	Endpoint (ConnectedEntities)	object	The PCI ID of the connected entity.
<b>EntityRole</b>	Endpoint (ConnectedEntities)	string (enum)	The role of the connected entity.
<b>EntityType</b>	Endpoint (ConnectedEntities)	string (enum)	The type of the connected entity.
<b>Entries</b>	LogService	object	The link to the log entry collection.
<b>EntryCode</b>	LogEntry	string (enum)	The entry code for the log entry if the entry type is `SEL`.
<b>EntryType</b>	LogEntry	string (enum)	The type of log entry.
<b>EnvironmentalClass</b>	Chassis	string (enum)	The ASHRAE Environmental Class for this chassis.
<b>EquipmentType</b>	PowerDistribution	string (enum)	The type of equipment this resource represents.
<b>ErrorCorrection</b>	Memory	string (enum)	Error correction scheme supported for this memory.
<b>Ethernet</b>	NetworkDeviceFunction, Processor (FPGA > ExternalInterfaces), Processor (FPGA > HostInterface)	object	The ethernet-related information for this device or interface.
<b>EthernetInterfaces</b>	PCIeFunction (Links), ResourceBlock	array	An array of references to the Ethernet interfaces related to this Resource.
	ComputerSystem, Manager	object	The reference to the collection of Ethernet interfaces related to this Resource.
<b>EventFormatType</b>	EventService (SSEFilterPropertiesSupported)	boolean	An indication of whether the service supports the EventFormatType property in the \$filter query parameter.
	EventDestination	string (enum)	The content types of the message that are sent to the EventDestination.
<b>EventFormatTypes</b>	EventService	array	The content types of the message that this service can send to the event destination.
<b>EventGroupId</b>	LogEntry	integer	An identifier that correlates events with the same cause.
	EventService (Actions > SubmitTestEvent (Action))	integer	The group ID for the event.
	Event (Events)	integer	The identifier that correlates events with the same root cause. If `0`, no other event is related to this event.
<b>EventId</b>	EventService (Actions > SubmitTestEvent (Action))	string	The ID for the event to add.
	LogEntry	string	The unique instance identifier for an event.
	Event (Events)	string	The unique instance identifier of an event.

<b>Events</b>	Event	array	Each event in this array has a set of properties that describe the event. Because this is an array, more than one event can be sent simultaneously.
<b>EventService</b>	ServiceRoot	object	The link to the Event Service.
<b>EventTimestamp</b>	EventService (Actions > SubmitTestEvent (Action))	string	The date and time stamp for the event to add.
	LogEntry	string	The date and time when the event occurred.
	Event (Events)	string	The time the event occurred.
<b>EventTriggers</b>	Triggers	array	The array of MessageIds that specify when a trigger condition is met based on an event.
<b>EventType</b>	EventService (SSEFilterPropertiesSupported)	boolean	An indication of whether the service supports the EventType property in the \$filter query parameter.
	EventService (Actions > SubmitTestEvent (Action))	string (enum)	The type for the event to add.
	Event (Events), LogEntry	string (enum)	The type of event that was sent or logged.
<b>EventTypes</b>	EventDestination	array	The types of events that are sent to the destination.
<b>EventTypesForSubscription</b>	EventService	array	The types of events to which a client can subscribe.
<b>ExcerptQuery</b>	ServiceRoot (ProtocolFeaturesSupported)	boolean	An indication of whether the service supports the excerpt query parameter.
<b>ExpandAll</b>	ServiceRoot (ProtocolFeaturesSupported > ExpandQuery)	boolean	An indication of whether the service supports the asterisk (*) option of the \$expand query parameter.
<b>ExpandQuery</b>	ServiceRoot (ProtocolFeaturesSupported)	object	The information about the use of \$expand in the service.
<b>ExternalAccessibility</b>	Zone	string (enum)	Indicates accessibility of endpoints in this zone to endpoints outside of this zone.
<b>ExternalInterfaces</b>	Processor (FPGA)	array	An array of the FPGA external interfaces.
<b>ExternallyAccessible</b>	HostInterface	boolean	An indication of whether external entities can access this interface. External entities are non-host entities. For example, if the host and manager are connected through a switch and the switch also exposes an external port on the system, external clients can also use the interface, and this property value is `true`.
<b>FabricAdapters</b>	ComputerSystem	object	The link to the collection of fabric adapters associated with this system.
<b>Fabrics</b>	ServiceRoot	object	The link to a collection of all fabric



			entities.
<b>FabricType</b>	Fabric	string (enum)	The protocol being sent over this fabric.
<b>Facilities</b>	ServiceRoot	object	The link to a collection of facilities.
<b>Facility</b>	PowerDistribution (Links)	object	A link to the facility that contains this equipment.
	Chassis (Links)	object	The link to the facility that contains this chassis.
<b>FacilityType</b>	Facility	string (enum)	The type of location this resource represents.
<b>FailurePredicted</b>	Drive	boolean	An indication of whether this drive currently predicts a failure in the near future.
<b>FallbackAddress</b>	EthernetInterface (DHCPv4)	string (enum)	DHCPv4 fallback address method for this interface.
<b>FanName</b>	Thermal (Fans)	string	The name of the fan.
<b>Fans</b>	Thermal	array	The set of fans for this chassis.
<b>FCFabricName</b>	NetworkPort	string	The FC Fabric Name provided by the switch.
<b>FCoEActiveVLANId</b>	NetworkDeviceFunction (FibreChannel)	integer	The active FCoE VLAN ID.
<b>FCoELocalVLANId</b>	NetworkDeviceFunction (FibreChannel)	integer	The locally configured FCoE VLAN ID.
<b>FCPortConnectionType</b>	NetworkPort	string (enum)	The connection type of this port.
<b>Feeders</b>	PowerDistribution	object	A link to the feeder circuits for this equipment.
<b>FibreChannel</b>	NetworkDeviceFunction	object	The Fibre Channel capabilities, status, and configuration values for this network device function.
<b>FibreChannelId</b>	NetworkDeviceFunction (FibreChannel)	string	The Fibre Channel ID that the switch assigns for this interface.
<b>FileSystems</b>	Storage	object	All filesystems that are allocated by this storage subsystem.
<b>FilterQuery</b>	ServiceRoot (ProtocolFeaturesSupported)	boolean	An indication of whether the service supports the \$filter query parameter.
<b>FirmwareApiVersion</b>	Memory	string	Version of API supported by the firmware.
<b>FirmwareAuthEnabled</b>	HostInterface	boolean	An indication of whether this firmware authentication is enabled for this interface.
<b>FirmwareAuthRole</b>	HostInterface (Links)	object	The link to the Redfish Role that has firmware authentication privileges on this Host Interface.
<b>FirmwareAuthRoleId</b>	HostInterface	string	The Role used for firmware authentication on this interface.

<b>FirmwareId</b>	Processor (FPGA)	string	The FPGA firmware identifier.
<b>FirmwareInventory</b>	UpdateService	object	An inventory of firmware.
<b>FirmwareManufacturer</b>	Processor (FPGA)	string	The FPGA firmware manufacturer.
<b>FirmwarePackageVersion</b>	NetworkAdapter (Controllers)	string	The version of the user-facing firmware package.
<b>FirmwareRevision</b>	Memory	string	Revision of firmware on the memory controller.
<b>FirmwareVersion</b>	AttributeRegistry (SupportedSystems), ComputerSystem (TrustedModules), Manager, PCleDevice, Power (PowerSupplies), Processor (FPGA), Storage (StorageControllers)	string	The firmware version for this device.
	Processor	string	The firmware version of the processor.
	PowerDistribution	string	The firmware version of this equipment.
	FabricAdapter	string	The firmware version of this fabric adapter.
	Switch	string	The firmware version of this switch.
<b>FirmwareVersion2</b>	ComputerSystem (TrustedModules)	string	The second firmware version of this Trusted Module, if applicable.
<b>FloorPDUs</b>	Facility (Links)	array	An array of links to the floor power distribution units in this facility.
	PowerDomain (Links)	array	An array of links to the floor power distribution units in this power domain.
	PowerEquipment	object	A link to a collection of floor power distribution units.
<b>FlowControl</b>	SerialInterface	string (enum)	The type of flow control, if any, that is imposed on the serial connection.
<b>FlowControlConfiguration</b>	NetworkPort	string (enum)	The locally configured 802.3x flow control setting for this network port.
<b>FlowControlStatus</b>	NetworkPort	string (enum)	The 802.3x flow control behavior negotiated with the link partner for this network port (Ethernet-only).
<b>ForceFailover (Action)</b>	Manager (Actions)	object	The ForceFailover action forces a failover of this manager to the manager used in the parameter.
<b>FPGA</b>	Processor	object	The properties for processors of the FPGA type.
<b>FpgaReconfigurationSlots</b>	AccelerationFunction	array	An array of the reconfiguration slot identifiers of the FPGA that this acceleration function occupies.
<b>FpgaType</b>	Processor (FPGA)	string (enum)	The FPGA type.

FQDN	EthernetInterface, ManagerNetworkProtocol	string	The DNS-obtained fully qualified domain name, including the host name and top-level domain name.
FrequencyHz	Circuit	object	The frequency reading for this circuit.
	Outlet	object	The frequency reading for this outlet.
FrequencyRatio	ProcessorMetrics	number	The frequency relative to the nominal processor frequency ratio.
FromAddress	EventService (SMTP)	string	The 'from' email address of the outgoing email.
FullDuplex	EthernetInterface	boolean	An indication of whether full-duplex mode is enabled on the Ethernet connection for this interface.
FunctionClasses	Memory	array	Function classes by the memory.
FunctionEnabled	ComputerSystem (HostWatchdogTimer)	boolean	An indication of whether a user has enabled the host watchdog timer functionality. This property indicates only that a user has enabled the timer. To activate the timer, installation of additional host-based software is necessary; an update to this property does not initiate the timer.
FunctionId	PCleFunction	integer	The PCIe Function Number.
FunctionNumber	Endpoint (ConnectedEntities > EntityPcild), Endpoint (Pcild)	integer	The PCI ID of the connected entity.
FunctionType	PCleFunction	string (enum)	The type of the PCIe function.
GCID	Endpoint (ConnectedEntities > GenZ)	object	The Global Component ID (GCID) for the entity.
GenerateCSR (Action)	CertificateService (Actions)	object	This action makes a certificate signing request.
GeneratedMetricReportValues	TelemetryService (Actions > SubmitTestMetricReport (Action))	array	The content of the MetricReportValues in the generated metric report.
GeneratorId	LogEntry	string	An identifier of the device that has generated the IPMI SEL Event Record.
GenZ	Port	object	Gen-Z specific properties.
	Endpoint (ConnectedEntities)	object	The Gen-Z related properties for the entity.
	AddressPool	object	The Gen-Z related properties for this address pool.
	FabricAdapter	object	The Gen-Z specific properties for this fabric adapter.
	PortMetrics	object	The port metrics specific to Gen-Z ports.
GET	PrivilegeRegistry (Mappings > OperationMap),	array	The required privilege for the HTTP GET operation.

	PrivilegeRegistry (Mappings > PropertyOverrides > OperationMap), PrivilegeRegistry (Mappings > ResourceURIOverrides > OperationMap), PrivilegeRegistry (Mappings > SubordinateOverrides > OperationMap)		
<b>GivenName</b>	CertificateService (Actions > GenerateCSR (Action))	string	The given name of the user making the request.
<b>GraphicalConsole</b>	Manager	object	The information about the graphical console (KVM-IP) service of this manager.
<b>GrayOut</b>	AttributeRegistry (RegistryEntries > Attributes), AttributeRegistry (RegistryEntries > Menus)	boolean	An indication of whether this attribute or menu is grayed out. A grayed-out menu is not accessible in user interfaces.
<b>GroupNameAttribute</b>	AccountService (ActiveDirectory > LDAPService > SearchSettings), AccountService (LDAP > LDAPService > SearchSettings), ExternalAccountProvider (LDAPService > SearchSettings)	string	The group name attribute. Contains the LDAP group name.
<b>GroupsAttribute</b>	AccountService (ActiveDirectory > LDAPService > SearchSettings), AccountService (LDAP > LDAPService > SearchSettings), ExternalAccountProvider (LDAPService > SearchSettings)	string	The groups attribute. Contains the groups on the LDAP user entry.
<b>HEAD</b>	PrivilegeRegistry (Mappings > OperationMap), PrivilegeRegistry (Mappings > PropertyOverrides > OperationMap), PrivilegeRegistry (Mappings > ResourceURIOverrides > OperationMap), PrivilegeRegistry (Mappings > SubordinateOverrides > OperationMap)	array	The required privilege for the HTTP HEAD operation.
<b>HealthData</b>	MemoryMetrics	object	The health information of the memory.
<b>HeightMm</b>	Chassis	number (mm)	The height of the chassis.
<b>HelpText</b>	AttributeRegistry (RegistryEntries > Attributes)	string	The help text for the attribute.
<b>Hidden</b>	AttributeRegistry (RegistryEntries > Attributes), AttributeRegistry (RegistryEntries > Menus)	boolean	An indication of whether this attribute or menu is hidden.

<b>HideCommunityStrings</b>	ManagerNetworkProtocol (SNMP)	boolean	Indicates if the community strings should be hidden.
<b>HidePayload</b>	Job, Task	boolean	An indication of whether the contents of the payload are hidden from view after the job or task is created. When True, a GET operation does not return the payload.
<b>HitRatio</b>	ProcessorMetrics (Cache), ProcessorMetrics (CoreMetrics > CoreCache)	number	The cache line hit ratio.
<b>HopCount</b>	RouteSetEntry	integer	The number of hops.
<b>HostedServices</b>	ComputerSystem	object	The services that this computer system supports.
<b>HostEthernetInterfaces</b>	HostInterface	object	A link to the collection of network interface controllers or cards (NICs) that a computer system uses to communicate with this Host Interface.
<b>HostingRole</b>	ComputerSystem (HostingRoles)	string (enum)	The enumerations of HostingRoles specify different features that the hosting ComputerSystem supports.
<b>HostingRoles</b>	ComputerSystem	array	The hosting roles that this computer system supports.
<b>HostInterface</b>	EthernetInterface (Links), Processor (FPGA)	object	The interface to the host.
<b>HostInterfaces</b>	Manager	object	The link to a collection of Host Interfaces that this manager uses for local host communication. Clients can find Host Interface configuration options and settings in this navigation property.
<b>HostInterfaceType</b>	HostInterface	string (enum)	The Host Interface type for this interface.
<b>HostName</b>	ComputerSystem, EthernetInterface, ManagerNetworkProtocol	string	The DNS host name without the domain information.
<b>HostReservationMemoryBytes</b>	Endpoint	integer (bytes)	The amount of memory in bytes that the host should allocate to connect to this endpoint.
<b>HostWatchdogTimer</b>	ComputerSystem	object	The host watchdog timer functionality for this system.
<b>HotPluggable</b>	PCIESlots (Slots)	boolean	An indication of whether this PCIe slot supports hotplug.
	Power (PowerSupplies), Thermal (Fans)	boolean	An indication of whether this slot supports hot plugging, which enables insertion of a device into or removal of a device from this slot while the equipment is in operation.
<b>HotspareReplacementMode</b>	Drive	string (enum)	The replacement mode for the hot spare drive.
<b>HotspareType</b>	Drive	string (enum)	The type of hot spare that this drive currently serves as.

<b>HTTP</b>	ManagerNetworkProtocol	object	The settings for this manager's HTTP protocol support.
<b>HttpBootUri</b>	ComputerSystem (Boot)	string	The URI to boot from when BootSourceOverrideTarget is set to `UefiHttp`.
<b>HttpHeaders</b>	EventDestination, Job (Payload), Task (Payload)	array	The HTTP headers in this task or job or supplied to an EventDestination when an Event is sent. For EventDestination usage, the GET operation returns a null object.
<b>HttpOperation</b>	Job (Payload), Task (Payload)	string	The HTTP operation to complete this job or task.
<b>HttpPushUri</b>	UpdateService	string	The URI used to perform an HTTP or HTTPS push update to the Update Service. The format of the message is vendor-specific.
<b>HttpPushUriApplyTime</b>	UpdateService (HttpPushUriOptions)	object	The settings for when to apply HttpPushUri-provided firmware.
<b>HttpPushUriOptions</b>	UpdateService	object	The options for HttpPushUri-provided software updates.
<b>HttpPushUriOptionsBusy</b>	UpdateService	boolean	An indication of whether a client has reserved the HttpPushUriOptions properties for software updates.
<b>HttpPushUriTargets</b>	UpdateService	array	An array of URIs that indicate where to apply the update image.
<b>HttpPushUriTargetsBusy</b>	UpdateService	boolean	An indication of whether any client has reserved the HttpPushUriTargets property.
<b>HTTPS</b>	ManagerNetworkProtocol	object	The settings for this manager's HTTPS protocol support.
<b>IdentificationRegisters</b>	Processor (ProcessorId)	string	The raw manufacturer-provided processor identification registers for this processor.
<b>Identifier</b>	Drive (Identifiers), Endpoint (ConnectedEntities > Identifiers), Endpoint (Identifiers), NetworkAdapter (Controllers > Identifiers), Storage (StorageControllers > Identifiers), Volume (Identifiers), Zone (Identifiers)	object	Any additional identifiers for a Resource.
<b>Identifiers</b>	Drive, Storage (StorageControllers), Volume	array	The durable names for the drives, storage controllers, or volumes.
	NetworkAdapter (Controllers)	array	The Durable names for the network adapter.
	Endpoint (ConnectedEntities), Endpoint, Zone	array	The identifiers for the endpoints, remote entities, or zones.

<b>Image</b>	VirtualMedia	string	The URI of the location of the selected image.
	VirtualMedia (Actions > InsertMedia (Action))	string	The URI of the remote media to attach to the virtual media.
<b>ImageName</b>	VirtualMedia	string	The current image name.
<b>ImageURI</b>	UpdateService (Actions > SimpleUpdate (Action))	string	The URI of the software image to install.
<b>Immutable</b>	AttributeRegistry (RegistryEntries > Attributes)	boolean	An indication of whether this attribute is immutable. Immutable attributes shall not be modified and typically reflect a hardware state.
<b>Implementation</b>	MetricDefinition	string (enum)	The implementation of the metric.
	Sensor	string (enum)	The implementation of the sensor.
<b>IndicatorLED</b>	Circuit	string (enum)	The state of the indicator LED, which identifies the circuit.
	Outlet	string (enum)	The state of the indicator LED, which identifies the outlet.
	Chassis, ComputerSystem, Drive, Power (PowerSupplies), Switch, Thermal (Fans)	string (enum)	The state of the indicator LED, which identifies this device.
<b>Initialize (Action)</b>	Volume (Actions)	object	This action is used to prepare the contents of the volume for use by the system. If InitializeType is not specified in the request body, the InitializeType should be Fast.
<b>InitializeType</b>	Volume (Actions > Initialize (Action))	string (enum)	The type of initialization to be performed.
<b>Initials</b>	CertificateService (Actions > GenerateCSR (Action))	string	The initials of the user making the request.
<b>InitiatorDefaultGateway</b>	NetworkDeviceFunction (iSCSIBoot)	string	The IPv6 or IPv4 iSCSI boot default gateway.
<b>InitiatorIPAddress</b>	NetworkDeviceFunction (iSCSIBoot)	string	The IPv6 or IPv4 address of the iSCSI initiator.
<b>InitiatorName</b>	NetworkDeviceFunction (iSCSIBoot)	string	The iSCSI initiator name.
<b>InitiatorNetmask</b>	NetworkDeviceFunction (iSCSIBoot)	string	The IPv6 or IPv4 netmask of the iSCSI boot initiator.
<b>InputRanges</b>	Power (PowerSupplies)	array	The input ranges that the power supply can use.
<b>InputType</b>	Power (PowerSupplies > InputRanges)	string (enum)	The Input type (AC or DC).
<b>Inserted</b>	VirtualMedia (Actions > InsertMedia (Action))	boolean	An indication of whether the image is treated as inserted upon completion of the action. The default is `true`.

	VirtualMedia	boolean	An indication of whether virtual media is inserted into the virtual device.
<b>InsertMedia (Action)</b>	VirtualMedia (Actions)	object	This action attaches remote media to virtual media.
<b>InstructionSet</b>	Processor	string (enum)	The instruction set of the processor.
<b>InstructionsPerCycle</b>	ProcessorMetrics (CoreMetrics)	number	The number of instructions per clock cycle of this core.
<b>IntegratedMemory</b>	Processor (ProcessorMemory)	boolean	An indication of whether this memory is integrated within the processor.
<b>InterfaceEnabled</b>	Port	boolean	An indication of whether the interface is enabled.
	EthernetInterface, HostInterface, SerialInterface	boolean	An indication of whether this interface is enabled.
<b>InterfaceType</b>	Processor (FPGA > ExternalInterfaces), Processor (FPGA > HostInterface)	string (enum)	The FPGA interface type.
	ComputerSystem (TrustedModules)	string (enum)	The interface type of the Trusted Module.
<b>InterfaceTypeSelection</b>	ComputerSystem (TrustedModules)	string (enum)	The interface type selection supported by this Trusted Module.
<b>InterleavableMemorySets</b>	MemoryDomain	array	The interleave sets for the memory chunk.
<b>InterleaveSets</b>	MemoryChunks	array	The interleave sets for the memory chunk.
<b>IntervallnMin</b>	Power (PowerControl > PowerMetrics)	integer (min)	The time interval, or window, over which the power metrics are measured.
<b>IntrusionSensor</b>	Chassis (PhysicalSecurity)	string (enum)	This indicates the known state of the physical security sensor, such as if it is hardware intrusion detected.
<b>IntrusionSensorNumber</b>	Chassis (PhysicalSecurity)	integer	A numerical identifier to represent the physical security sensor.
<b>IntrusionSensorReArm</b>	Chassis (PhysicalSecurity)	string (enum)	The method that restores this physical security sensor to the normal state.
<b>InvolvedSwitches</b>	Zone (Links)	array	The links to the collection of switches in this zone.
<b>IOStallCount</b>	ProcessorMetrics (CoreMetrics)	number	The number of stalled cycles due to I/O operations.
<b>IOStatistics</b>	Volume	object	Statistics for this volume.
<b>IPAddressType</b>	NetworkDeviceFunction (iSCSIBoot)	string (enum)	The type of IP address being populated in the iSCSIBoot IP address fields.
<b>IPMaskDNSViaDHCP</b>	NetworkDeviceFunction (iSCSIBoot)	boolean	An indication of whether the iSCSI boot initiator uses DHCP to obtain the initiator name, IP address, and



			netmask.
<b>IPMI</b>	ManagerNetworkProtocol	object	The settings for this manager's IPMI-over-LAN protocol support.
<b>IPTransportDetails</b>	Endpoint	array	An array of details for each IP transport supported by this endpoint. The array structure can model multiple IP addresses for this endpoint.
<b>IPv4Address</b>	Endpoint (IPTransportDetails), EthernetInterface (IPv4Addresses), EthernetInterface (IPv4StaticAddresses)	object	The IPv4 address assigned to the endpoint or interface.
<b>IPv4Addresses</b>	EthernetInterface	array	The IPv4 addresses currently assigned to this interface.
<b>IPv4AutoConfigEnabled</b>	EthernetInterface (StatelessAddressAutoConfig)	boolean	An indication of whether IPv4 stateless address autoconfiguration (SLAAC) is enabled for this interface.
<b>IPv4StaticAddresses</b>	EthernetInterface	array	The IPv4 static addresses assigned to this interface.
<b>IPv6Address</b>	Endpoint (IPTransportDetails), EthernetInterface (IPv6Addresses)	object	The IPv6 address assigned to the endpoint or interface.
<b>IPv6Addresses</b>	EthernetInterface	array	An array of the currently assigned IPv6 addresses on this interface.
<b>IPv6AddressPolicyTable</b>	EthernetInterface	array	An array that represents the RFC6724-defined address selection policy table.
<b>IPv6AutoConfigEnabled</b>	EthernetInterface (StatelessAddressAutoConfig)	boolean	An indication of whether IPv6 stateless address autoconfiguration (SLAAC) is enabled for this interface.
<b>IPv6DefaultGateway</b>	EthernetInterface	string	The IPv6 default gateway address in use on this interface.
<b>IPv6GatewayStaticAddress</b>	EthernetInterface (IPv6StaticDefaultGateways)	object	This type represents a single IPv6 static address to be assigned on a network interface.
<b>IPv6StaticAddress</b>	EthernetInterface (IPv6StaticAddresses)	object	This type represents a single IPv6 static address to be assigned on a network interface.
<b>IPv6StaticAddresses</b>	EthernetInterface	array	An array of the IPv6 static addresses to assign on this interface.
<b>IPv6StaticDefaultGateways</b>	EthernetInterface	array	The IPv6 static default gateways for this interface.
<b>iSCSIBoot</b>	NetworkDeviceFunction	object	The iSCSI boot capabilities, status, and configuration values for this network device function.
<b>IsLinear</b>	MetricDefinition	boolean	An indication of whether the metric values are linear versus non-linear.
<b>IsManaged</b>	Switch	boolean	An indication of whether the switch is in a managed or unmanaged state.

<b>IsMirrorEnabled</b>	MemoryChunks	boolean	An indication of whether memory mirroring is enabled for this memory chunk.
<b>IsPredefined</b>	Role	boolean	An indication of whether the Role is a Redfish-predefined Role rather than a custom Redfish Role.
<b>IsRankSpareEnabled</b>	Memory	boolean	An indication of whether rank spare is enabled for this memory.
<b>IsSpare</b>	MemoryChunks	boolean	An indication of whether sparing is enabled for this memory chunk.
<b>IsSpareDeviceEnabled</b>	Memory	boolean	An indication of whether a spare device is enabled for this memory.
<b>Issuer</b>	Certificate	object	The issuer of the certificate.
<b>IsSystemUniqueProperty</b>	AttributeRegistry (RegistryEntries > Attributes)	boolean	An indication of whether this attribute is unique for this system and should not be replicated.
<b>Jobs</b>	JobService	object	The links to the Jobs collection.
<b>JobService</b>	ServiceRoot	object	The link to the JobService.
<b>JobState</b>	Job	string (enum)	The state of the job.
<b>JobStatus</b>	Job	string (enum)	The status of the job.
<b>JsonBody</b>	Job (Payload), Task (Payload)	string	The JSON payload in this job or task.
<b>JsonSchemas</b>	ServiceRoot	object	The link to a collection of JSON Schema files.
<b>KerberosKeytab</b>	AccountService (ActiveDirectory > Authentication), AccountService (LDAP > Authentication), ExternalAccountProvider (Authentication)	string	The Base64-encoded version of the Kerberos keytab for this Service. A PATCH or PUT operation writes the keytab. This property is 'null' in responses.
<b>KernelAuthEnabled</b>	HostInterface	boolean	An indication of whether this kernel authentication is enabled for this interface.
<b>KernelAuthRole</b>	HostInterface (Links)	object	The link to the Redfish Role defining privileges for this Host Interface when using kernel authentication.
<b>KernelAuthRoleId</b>	HostInterface	string	The Role used for kernel authentication on this interface.
<b>KernelPercent</b>	ProcessorMetrics	number (%)	The percentage of time spent in kernel mode.
<b>KeyBitLength</b>	Certificate (Actions > Rekey (Action)), CertificateService (Actions > GenerateCSR (Action))	integer	The length of the key, in bits, if needed based on the KeyPairAlgorithm parameter value.
<b>KeyCurveId</b>	Certificate (Actions > Rekey (Action)),	string	The curve ID to use with the key, if needed based on the

	CertificateService (Actions > GenerateCSR (Action))		KeyPairAlgorithm parameter value.
<b>KeyPairAlgorithm</b>	Certificate (Actions > Rekey (Action)), CertificateService (Actions > GenerateCSR (Action))	string	The type of key-pair for use with signing algorithms.
<b>Keys</b>	MetricReportDefinition (Wildcards)	array	An array of values to substitute for the wildcard.
<b>KeyUsage</b>	Certificate	array	The key usage extension, which defines the purpose of the public keys in this certificate.
	CertificateService (Actions > GenerateCSR (Action))	array	The usage of the key contained in the certificate.
	Certificate (KeyUsage), CertificateService (Actions > GenerateCSR (Action) > KeyUsage)	string (enum)	The usages of a key contained within a certificate.
<b>KVMIP</b>	ManagerNetworkProtocol	object	The settings for this manager's KVM-IP protocol support.
<b>Label</b>	EthernetInterface (IPv6AddressPolicyTable)	integer	The IPv6 label, as defined in RFC6724, section 2.1.
<b>Lanes</b>	PCleSlots (Slots)	integer	The number of PCIe lanes supported by this slot.
<b>LanesInUse</b>	PCleDevice (PCleInterface)	integer	The number of PCIe lanes in use by this device.
<b>Language</b>	AttributeRegistry, JsonSchemaFile (Location), MessageRegistry, MessageRegistryFile (Location)	string	The RFC5646-compliant language code for the Schema file or registry.
<b>Languages</b>	MessageRegistryFile	array	The RFC5646-conformant language codes for the available Message Registries.
	JsonSchemaFile	array	The RFC5646-conformant language codes for the available schemas.
<b>LastPowerOutputWatts</b>	Power (PowerSupplies)	number (Watts)	The average power output of this power supply.
<b>LastShutdownSuccess</b>	MemoryMetrics (HealthData)	boolean	An indication of whether the last shutdown succeeded.
<b>LDAP</b>	AccountService	object	The first LDAP external account provider that this Account Service supports.
<b>LDAPService</b>	AccountService (ActiveDirectory), AccountService (LDAP), ExternalAccountProvider	object	The additional mapping information needed to parse a generic LDAP service.
<b>Level</b>	ProcessorMetrics (CoreMetrics > CStateResidency)	string	The C-state level, such as C0, C1, or C2.
	ProcessorMetrics (Cache), ProcessorMetrics (CoreMetrics > CoreCache)	string	The cache level.

<b>Levels</b>	ServiceRoot (ProtocolFeaturesSupported > ExpandQuery)	boolean	An indication of whether the service supports the \$levels option of the \$expand query parameter.
<b>LifeCycleEventOnTaskStateChange</b>	TaskService	boolean	An indication of whether a task state change sends an event.
<b>LifeTime</b>	MemoryMetrics	object	The memory metrics for the lifetime of the memory.
<b>LifetimeReading</b>	Circuit (EnergykWh), Circuit (PolyPhaseEnergykWh > Line1ToLine2), Circuit (PolyPhaseEnergykWh > Line1ToNeutral), Circuit (PolyPhaseEnergykWh > Line2ToLine3), Circuit (PolyPhaseEnergykWh > Line2ToNeutral), Circuit (PolyPhaseEnergykWh > Line3ToLine1), Circuit (PolyPhaseEnergykWh > Line3ToNeutral), Outlet (EnergykWh), OutletGroup (EnergykWh), Sensor	number	The total accumulation value for this sensor.
<b>LimitException</b>	Power (PowerControl > PowerLimit)	string (enum)	The action that is taken if the power cannot be maintained below the LimitInWatts.
<b>LimitInWatts</b>	Power (PowerControl > PowerLimit)	number (Watts)	The power limit, in watts. If `null`, power capping is disabled.
<b>Line1</b>	Circuit (PolyPhaseCurrentAmps), Outlet (PolyPhaseCurrentAmps)	object	Line 1 current sensor.
<b>Line1ToLine2</b>	Circuit (PolyPhaseEnergykWh)	object	The Line 1 to Line 2 energy reading for this circuit.
	Circuit (PolyPhasePowerWatts)	object	The Line 1 to Line 2 power reading for this circuit.
	Circuit (PolyPhaseVoltage)	object	The Line 1 to Line 2 voltage reading for this circuit.
	Outlet (PolyPhaseVoltage)	object	The Line 1 to Line 2 voltage reading for this outlet.
<b>Line1ToNeutral</b>	Circuit (PolyPhaseEnergykWh)	object	The Line 1 to Neutral energy reading for this circuit.
	Circuit (PolyPhasePowerWatts)	object	The Line 1 to Neutral power reading for this circuit.
	Circuit (PolyPhaseVoltage)	object	The Line 1 to Neutral voltage reading for this circuit.
	Outlet (PolyPhaseVoltage)	object	The Line 1 to Neutral voltage reading for this outlet.
<b>Line2</b>	Circuit (PolyPhaseCurrentAmps), Outlet (PolyPhaseCurrentAmps)	object	Line 2 current sensor.

<b>Line2ToLine3</b>	Circuit (PolyPhaseEnergykWh)	object	The Line 2 to Line 3 energy reading for this circuit.
	Circuit (PolyPhasePowerWatts)	object	The Line 2 to Line 3 power reading for this circuit.
	Circuit (PolyPhaseVoltage)	object	The Line 2 to Line 3 voltage reading for this circuit.
	Outlet (PolyPhaseVoltage)	object	The Line 2 to Line 3 voltage reading for this outlet.
<b>Line2ToNeutral</b>	Circuit (PolyPhaseEnergykWh)	object	The Line 2 to Neutral energy reading for this circuit.
	Circuit (PolyPhasePowerWatts)	object	The Line 2 to Neutral power reading for this circuit.
	Circuit (PolyPhaseVoltage)	object	The Line 2 to Neutral voltage reading for this circuit.
	Outlet (PolyPhaseVoltage)	object	The Line 2 to Neutral voltage reading for this outlet.
<b>Line3</b>	Circuit (PolyPhaseCurrentAmps), Outlet (PolyPhaseCurrentAmps)	object	Line 3 current sensor.
<b>Line3ToLine1</b>	Circuit (PolyPhaseEnergykWh)	object	The Line 3 to Line 1 energy reading for this circuit.
	Circuit (PolyPhasePowerWatts)	object	The Line 3 to Line 1 power reading for this circuit.
	Circuit (PolyPhaseVoltage)	object	The Line 3 to Line 1 voltage reading for this circuit.
	Outlet (PolyPhaseVoltage)	object	The Line 3 to Line 1 voltage reading for this outlet.
<b>Line3ToNeutral</b>	Circuit (PolyPhaseEnergykWh)	object	The Line 3 to Neutral energy reading for this circuit.
	Circuit (PolyPhasePowerWatts)	object	The Line 3 to Neutral power reading for this circuit.
	Circuit (PolyPhaseVoltage)	object	The Line 3 to Neutral voltage reading for this circuit.
	Outlet (PolyPhaseVoltage)	object	The Line 3 to Neutral voltage reading for this outlet.
<b>LineInputVoltage</b>	Power (PowerSupplies)	number (Volts)	The line input voltage at which the power supply is operating.
<b>LineInputVoltageType</b>	Power (PowerSupplies)	string (enum)	The line voltage type supported as an input to this power supply.
<b>LinkNetworkTechnology</b>	NetworkPort (SupportedLinkCapabilities), Port	string (enum)	The link network technology capabilities of this port.
<b>LinkNTE</b>	PortMetrics (GenZ)	integer	The total number of link-local non-transient errors detected.
<b>Links</b>	ServiceRoot (ProtocolFeaturesSupported > ExpandQuery)	boolean	An indication of whether the tilde (~) option of the \$expand query parameter is supported. This option

			expands all hyperlinks found in the Links property section of the Resource.
	AddressPool, Bios, FabricAdapter, MediaController, MemoryChunks, MemoryDomain	object	The links to other Resources that are related to this Resource.
	Circuit, Outlet, OutletGroup, PowerDistribution, PowerDomain, PowerEquipment	object	The links to other resources that are related to this resource.
	Facility	object	The links to other Resources that are related to this resource.
	<i>various</i> (AccelerationFunction, CertificateLocations ... )	object	The references to other Resources related to this Resource.
<b>LinkSpeedMbps</b>	NetworkPort (SupportedLinkCapabilities)	integer (Mbit/s)	The speed of the link in Mbps when this link network technology is active.
<b>LinkState</b>	Port	string (enum)	The desired link state for this interface.
<b>LinkStatus</b>	Port	string (enum)	The desired link status for this interface.
	EthernetInterface, NetworkPort	string (enum)	The status between this port and its link.
<b>LinkTransitionIndicator</b>	Port	integer	The number of link state transitions for this interface.
<b>LLRRecovery</b>	PortMetrics (GenZ)	integer	The total number of times Link-Level Reliability (LLR) recovery has been initiated.
<b>LoadPercent</b>	Sensor	number (%)	The power load utilization for this sensor.
<b>LocalAccountAuth</b>	AccountService	string (enum)	An indication of how the Service uses the accounts collection within this Account Service as part of authentication. The enumerated values describe the details for each mode.
<b>LocalMemoryBandwidthBytes</b>	ProcessorMetrics	integer (bytes)	The local memory bandwidth usage in bytes.
<b>LocalRole</b>	AccountService (ActiveDirectory > RemoteRoleMapping), AccountService (LDAP > RemoteRoleMapping), ExternalAccountProvider (RemoteRoleMapping)	string	The name of the local Redfish Role to which to map the remote user or group.
<b>Location</b>	Drive, JsonSchemaFile, MessageRegistryFile	array	The location of the drive or file.

	PowerDistribution	object	The location of the equipment.
	Facility	object	The location of the facility.
	<i>various</i> (Chassis, Drive (Location) ... )	object	The physical location of the Resource.
<b>Locked</b>	ManagerAccount	boolean	An indication of whether the Account Service automatically locked the account because the lockout threshold was exceeded. To manually unlock the account before the lockout duration period, an administrator can change the property to `false` to clear the lockout condition.
<b>Log</b>	JobService	object	The link to a Log Service that the Job Service uses. This service may be a dedicated Log Service or a pointer a Log Service under another entity, such as Manager.
<b>LogEntryType</b>	LogService	string (enum)	The format of the log entries.
<b>LogicalProcessorCount</b>	ComputerSystem (ProcessorSummary)	integer	The number of logical processors in the system.
<b>LogicalSizeMiB</b>	Memory	integer (mebibytes)	Total size of the logical memory in MiB.
<b>LogicalUnitNumber</b>	Volume	integer	Indicates the host-visible LogicalUnitNumber assigned to this Volume.
<b>LogService</b>	TelemetryService	object	The link to a Log Service that the Telemetry Service uses. This service may be a dedicated Log Service or a pointer a Log Service under another entity, such as Manager.
<b>LogServices</b>	Chassis, ComputerSystem, Manager, Switch	object	A reference to the collection of log services.
<b>LowerBound</b>	AttributeRegistry (RegistryEntries > Attributes)	integer	The lower limit for an integer attribute.
<b>LowerCaution</b>	Sensor (Thresholds)	object	The value at which the reading is below normal range.
<b>LowerCritical</b>	Sensor (Thresholds), Triggers (NumericThresholds)	object	Below normal range but not fatal. Requires attention.
<b>LowerFatal</b>	Sensor (Thresholds)	object	The value at which the reading is below normal range and fatal.
<b>LowerThresholdCritical</b>	Thermal (Fans)	integer	The value at which the reading is below normal range but not yet fatal.
	Thermal (Temperatures)	number (Celsius)	The value at which the reading is below normal range but not yet fatal.
	Power (Voltages)	number (Volts)	The value at which the reading is below normal range but not yet fatal.

<b>LowerThresholdFatal</b>	Thermal (Fans)	integer	The value at which the reading is below normal range and fatal.
	Thermal (Temperatures)	number (Celsius)	The value at which the reading is below normal range and fatal.
	Power (Voltages)	number (Volts)	The value at which the reading is below normal range and fatal.
<b>LowerThresholdNonCritical</b>	Thermal (Fans)	integer	The value at which the reading is below normal range.
	Thermal (Temperatures)	number (Celsius)	The value at which the reading is below normal range.
	Power (Voltages)	number (Volts)	The value at which the reading is below normal range.
<b>LowerThresholdUser</b>	Thermal (Temperatures)	integer (Celsius)	The value at which the reading is below the user-defined range.
<b>LowerWarning</b>	Triggers (NumericThresholds)	object	The value at which the reading is below normal range.
<b>LowestSupportedVersion</b>	SoftwareInventory	string	The lowest supported version of this software.
<b>LowSpaceWarningThresholdPercents</b>	Volume	array (%)	Low space warning.
<b>LPRT</b>	Port (GenZ)	object	The Linear Packet Relay Table for the port.
<b>LUNID</b>	NetworkDeviceFunction (FibreChannel > BootTargets)	string	The logical unit number (LUN) ID from which to boot on the device to which the corresponding WWPN refers.
<b>MACAddress</b>	EthernetInterface, NetworkDeviceFunction (Ethernet)	string	The currently configured MAC address for the interface.
<b>Mains</b>	PowerDistribution	object	A link to the power input circuits for this equipment.
<b>MaintenanceWindowDurationInSeconds</b>	UpdateService (HttpPushUriOptions > HttpPushUriApplyTime)	integer (seconds)	The expiry time, in seconds, of the maintenance window.
<b>MaintenanceWindowStartTime</b>	UpdateService (HttpPushUriOptions > HttpPushUriApplyTime)	string	The start time of a maintenance window.
<b>ManagedBy</b>	PowerDistribution (Links)	array	An array of links to the managers responsible for managing this equipment.
	Facility (Links)	array	An array of links to the managers responsible for managing this facility.
	PowerDomain (Links)	array	An array of links to the managers responsible for managing this power domain.
	PowerEquipment (Links)	array	An array of links to the managers responsible for managing this power equipment.
	Chassis (Links),	array	An array of references to the



	ComputerSystem (Links), Switch (Links)		managers of this Resource.
<b>ManagerEthernetInterface</b>	HostInterface	object	A link to a single network interface controllers or cards (NIC) that this manager uses for network communication with this Host Interface.
<b>ManagerForChassis</b>	Manager (Links)	array	An array of links to the chassis this manager controls.
<b>ManagerForServers</b>	Manager (Links)	array	An array of links to the systems that this manager controls.
<b>ManagerForSwitches</b>	Manager (Links)	array	An array of links to the switches that this manager controls.
<b>ManagerInChassis</b>	Manager (Links)	object	The link to the chassis where this manager is located.
<b>Managers</b>	ServiceRoot	object	The link to a collection of managers.
<b>ManagersInChassis</b>	Chassis (Links)	array	An array of links to the managers located in this chassis.
<b>ManagerType</b>	Manager	string (enum)	The type of manager that this Resource represents.
<b>Manufacturer</b>	PowerDistribution	string	The manufacturer of this equipment.
	Manager	string	The manufacturer of this manager.
	MediaController	string	The manufacturer of this media controller.
	FabricAdapter	string	The manufacturer or OEM of this fabric adapter.
	Volume	string	The manufacturer or OEM of this storage volume.
	<i>various</i> (AccelerationFunction, Chassis ... )	string	The manufacturer or producer of this device or Resource.
<b>MapFrom</b>	AttributeRegistry (RegistryEntries > Dependencies > Dependency)	array	An array of the map-from conditions for a mapping dependency.
<b>MapFromAttribute</b>	AttributeRegistry (RegistryEntries > Dependencies > Dependency > MapFrom)	string	The attribute to use to evaluate this dependency expression.
<b>MapFromCondition</b>	AttributeRegistry (RegistryEntries > Dependencies > Dependency > MapFrom)	string (enum)	The condition to use to evaluate this dependency expression.
<b>MapFromProperty</b>	AttributeRegistry (RegistryEntries > Dependencies > Dependency > MapFrom)	string (enum)	The metadata property for the attribute that the MapFromAttribute property specifies to use to evaluate this dependency expression.
<b>MapFromValue</b>	AttributeRegistry (RegistryEntries > Dependencies > Dependency >	boolean, number, string	The value to use to evaluate this dependency expression.

	MapFrom)		
<b>Mappings</b>	PrivilegeRegistry	array	The mappings between entities and the relevant privileges that access those entities.
<b>MapTerms</b>	AttributeRegistry (RegistryEntries > Dependencies > Dependency > MapFrom)	string (enum)	The logical term that combines two or more map-from conditions in this dependency expression. For example, `AND` for logical AND, or `OR` for logical OR.
<b>MapToAttribute</b>	AttributeRegistry (RegistryEntries > Dependencies > Dependency)	string	The AttributeName of the attribute that is affected by this dependency expression.
<b>MapToProperty</b>	AttributeRegistry (RegistryEntries > Dependencies > Dependency)	string (enum)	The metadata property for the attribute that contains the map-from condition that evaluates this dependency expression.
<b>MapToValue</b>	AttributeRegistry (RegistryEntries > Dependencies > Dependency)	boolean, number, string	The value that the map-to property changes to if the dependency expression evaluates to `true`.
<b>MarkedECN</b>	PortMetrics (GenZ)	integer	The number of packets with the Congestion ECN bit set.
<b>MaxAllowableOperatingValue</b>	Thermal (Temperatures)	integer (Celsius)	Maximum allowable operating temperature for this equipment.
	Sensor	number	The maximum allowable operating value for this equipment.
<b>MaxBlockSizeBytes</b>	Volume	integer (bytes)	Max Block size in bytes.
<b>MaxBWAllocPercent</b>	NetworkPort (NetDevFuncMaxBWAlloc)	integer (%)	The maximum bandwidth allocation percentage allocated to the corresponding network device function instance.
<b>MaxCID</b>	AddressPool (GenZ)	integer	The maximum value for the Component Identifier (CID).
<b>MaxCompositions</b>	ResourceBlock (CompositionStatus)	integer	The maximum number of compositions in which this Resource Block can participate simultaneously.
<b>MaxConcurrentSessions</b>	Manager (CommandShell), Manager (GraphicalConsole), Manager (SerialConsole)	integer	The maximum number of service sessions, regardless of protocol, that this manager can support.
<b>MaxConsumedWatts</b>	Power (PowerControl > PowerMetrics)	number (Watts)	The highest power consumption level, in watts, that has occurred over the measurement window within the last IntervalInMin minutes.
<b>MaxDeviceLogins</b>	NetworkAdapter (Controllers > ControllerCapabilities > NPIV)	integer	The maximum number of N_Port ID Virtualization (NPIV) logins allowed simultaneously from all ports on this controller.
<b>MaxExecutionTime</b>	Job	string	The maximum amount of time the job is allowed to execute.
<b>MaxFrameSize</b>	NetworkPort	integer (bytes)	The maximum frame size supported by the port.

<b>MaxImageSizeBytes</b>	UpdateService	integer (bytes)	The maximum size in bytes of the software update image that this Service supports.
<b>MaximumFrequencyHz</b>	Power (PowerSupplies > InputRanges)	number (Hz)	The maximum line input frequency at which this power supply input range is effective.
<b>MaximumValue</b>	ActionInfo (Parameters)	number	The maximum supported value for this parameter.
<b>MaximumVoltage</b>	Power (PowerSupplies > InputRanges)	number (Volts)	The maximum line input voltage at which this power supply input range is effective.
<b>MaxIPv6StaticAddresses</b>	EthernetInterface	integer	The maximum number of static IPv6 addresses that can be configured on this interface.
<b>MaxJobs</b>	JobService (ServiceCapabilities)	integer	The maximum number of jobs supported.
<b>MaxLanes</b>	PCIeDevice (PCIeInterface), Processor (FPGA > ExternalInterfaces > Ethernet), Processor (FPGA > HostInterface > Ethernet)	integer	The number of lanes that this interface supports.
<b>MaxLength</b>	AttributeRegistry (RegistryEntries > Attributes)	integer	The maximum character length of a string attribute.
<b>MaxLevels</b>	ServiceRoot (ProtocolFeaturesSupported > ExpandQuery)	integer	The maximum \$levels option value in the \$expand query parameter.
<b>MaxNumberOfRecords</b>	LogService	integer	The maximum number of log entries that this service can have.
<b>MaxPassphraseCount</b>	Memory (SecurityCapabilities)	integer	Maximum number of passphrases supported for this memory.
<b>MaxPasswordLength</b>	AccountService	integer	The maximum password length for this Account Service.
<b>MaxPCIeType</b>	PCIeDevice (PCIeInterface)	string (enum)	The highest version of the PCIe specification supported by this device.
<b>MaxPortLogins</b>	NetworkAdapter (Controllers > ControllerCapabilities > NPIV)	integer	The maximum number of N_Port ID Virtualization (NPIV) logins allowed per physical port on this controller.
<b>MaxReadingRange</b>	Thermal (Fans)	integer	Maximum value for this sensor.
	MetricDefinition	number	The maximum value for the reading.
	Power (Voltages)	number (Volts)	Maximum value for this sensor.
<b>MaxReadingRangeTemp</b>	Thermal (Temperatures)	number (Celsius)	Maximum value for this sensor.
<b>MaxReports</b>	TelemetryService	integer	The maximum number of metric reports that this service supports.
<b>MaxSID</b>	AddressPool (GenZ)	integer	The maximum value for the Subnet Identifier (SID).
<b>MaxSpeedGbps</b>	Port	number	The maximum speed of this port as

		(Gbit/s)	currently configured.
<b>MaxSpeedMbps</b>	Processor (FPGA > ExternalInterfaces > Ethernet), Processor (FPGA > HostInterface > Ethernet)	integer (Mbit/s)	The maximum speed supported by this interface.
<b>MaxSpeedMHz</b>	Processor	integer (MHz)	The maximum clock speed of the processor.
<b>MaxSteps</b>	JobService (ServiceCapabilities)	integer	The maximum number of job steps supported.
<b>MaxTDPMilliWatts</b>	Memory	array (milliWatts)	Set of maximum power budgets supported by the memory in milliwatts.
	Memory (PowerManagementPolicy)	integer (milliWatts)	Maximum TDP in milliwatts.
<b>MaxTDPWatts</b>	Processor	integer (Watts)	The maximum Thermal Design Power (TDP) in watts.
<b>MaxVirtualFunctions</b>	NetworkDeviceFunction	integer	The number of virtual functions that are available for this network device function.
<b>MaxZones</b>	Fabric	integer	The maximum number of zones the switch can currently configure.
<b>MediaControllers</b>	MemoryDomain (Links)	array	An array of links to the media controllers for this memory domain.
	Chassis	object	The link to the collection of media controllers located in this chassis.
<b>MediaControllerType</b>	MediaController	string (enum)	The type of media controller.
<b>MediaSpanCount</b>	Volume	integer	Indicates the number of media elements used per span in the secondary RAID for a hierarchical RAID type.
<b>MediaType</b>	Drive	string (enum)	The type of media contained in this drive.
<b>MediaTypes</b>	VirtualMedia	array	The media types supported as virtual media.
<b>MemberId</b>	Assembly (Assemblies), Event (Events), Power (PowerControl), Power (PowerSupplies), Power (Voltages), Storage (StorageControllers), Thermal (Fans), Thermal (Temperatures)	string	The identifier for the member within the collection.
	Power (Actions > PowerSupplyReset (Action))	string	The MemberId of the power supply within the PowerSupplies array on which to perform the reset.
<b>Memory</b>	ResourceBlock	array	An array of links to the memory available in this Resource Block.
	MemoryChunks (InterleaveSets)	object	Describes a memory device of the interleave set.

	ComputerSystem	object	The link to the collection of memory associated with this system.
	Chassis	object	The link to the collection of memory located in this chassis.
<b>MemoryChunks</b>	MemoryDomain	object	The link to the collection of memory chunks associated with this memory domain.
<b>MemoryChunkSizeMiB</b>	MemoryChunks	integer (mebibytes)	Size of the memory chunk measured in mebibytes (MiB).
<b>MemoryClassification</b>	Memory (Regions)	string (enum)	The classification of memory that the memory region occupies.
<b>MemoryController</b>	Memory (MemoryLocation)	integer	The memory controller number to which the memory is connected.
<b>MemoryDeviceType</b>	Memory	string (enum)	Type details of the memory.
<b>MemoryDomains</b>	MediaController (Links)	array	An array of links to the memory domains associated with this media controller.
	ComputerSystem	object	The link to the collection of memory domains associated with this system.
	Chassis	object	The link to the collection of memory domains located in this chassis.
<b>MemoryLevel</b>	MemoryChunks (InterleaveSets)	integer	Level of the interleave set for multi-level tiered memory.
<b>MemoryLocation</b>	Memory	object	Memory connection information to sockets and memory controllers.
<b>MemoryMedia</b>	Memory	array	Media of this memory.
<b>MemoryMirroring</b>	ComputerSystem (MemorySummary)	string (enum)	The ability and type of memory mirroring that this computer system supports.
<b>MemorySet</b>	MemoryDomain (InterleavableMemorySets)	array	The set of memory for a particular interleave set.
<b>MemoryStallCount</b>	ProcessorMetrics (CoreMetrics)	number	The number of stalled cycles due to memory operations.
<b>MemorySubsystemControllerManufacturerID</b>	Memory	string	The manufacturer ID of the memory subsystem controller of this memory module.
<b>MemorySubsystemControllerProductID</b>	Memory	string	The product ID of the memory subsystem controller of this memory module.
<b>MemorySummary</b>	ComputerSystem	object	The central memory of the system in general detail.
<b>MemoryType</b>	Memory, Processor (ProcessorMemory)	string (enum)	The type of memory.
<b>MenuName</b>	AttributeRegistry (RegistryEntries > Menus)	string	The unique name string of this menu.
<b>MenuPath</b>	AttributeRegistry	string	The menu hierarchy path for an

	(RegistryEntries > Attributes), AttributeRegistry (RegistryEntries > Menu)		attribute or for a menu relative to other menus.
<b>Menus</b>	AttributeRegistry (RegistryEntries)	array	An array for the attributes menus and their hierarchy in the Attribute Registry.
<b>Message</b>	Job (Messages), Task (Messages)	object	The message that the Redfish Service returns.
	Event (Events)	string	The human-readable event message.
	EventService (Actions > SubmitTestEvent (Action))	string	The human-readable message for the event to add.
	LogEntry	string	The message of the log entry. This property decodes from the entry type. If the entry type is `Event`, this property contains a message. If the entry type is `SEL`, this property contains an SEL-specific message. Otherwise, this property contains an OEM-specific log entry. In most cases, this property contains the actual log entry.
<b>MessageArgs</b>	EventService (Actions > SubmitTestEvent (Action))	array	An array of message arguments for the event to add.
	Event (Events), LogEntry	array	An array of message arguments. These arguments replace the message arguments in a message in the message registry.
<b>MessageId</b>	EventService (SSEFilterPropertiesSupported)	boolean	An indication of whether the service supports the MessageId property in the \$filter query parameter.
	Event (Events)	string	The key used to find the message in a Message Registry.
	EventService (Actions > SubmitTestEvent (Action))	string	The MessageId for the event to add.
	LogEntry	string	The MessageId, event data, or OEM-specific information. This property decodes from the entry type. If the entry type is `Event`, this property contains a Redfish Specification-defined MessageId. If the entry type is `SEL`, this property contains the Event Data. Otherwise, this property contains OEM-specific information.
<b>MessageIds</b>	EventDestination	array	The list of MessageIds that the service sends. If this property is absent or the array is empty, events with any MessageId are sent to the subscriber.
<b>Messages</b>	Job, Task	array	An array of messages related to the job or task.
	MessageRegistry	object	The message keys contained in the Message Registry.
<b>MetricDataType</b>	MetricDefinition	string	The data type of the metric.

<b>MetricDefinition</b>	MetricReport (MetricValues), TelemetryService (Actions > SubmitTestMetricReport (Action) > GeneratedMetricReportValues)	object	The link to the metric.
<b>MetricDefinitions</b>	TelemetryService	object	The link to the collection of metric definitions.
<b>MetricId</b>	MetricReport (MetricValues), MetricReportDefinition (Metrics)	string	The label for the metric definition, which matches the Id property value of the corresponding metric definition.
	TelemetryService (Actions > SubmitTestMetricReport (Action) > GeneratedMetricReportValues)	string	The metric definitions identifier for this metric.
<b>MetricProperties</b>	MetricDefinition, MetricReportDefinition, MetricReportDefinition (Metrics), Triggers	array	An array of URIs that contains optional wildcards and property identifiers. The Wildcards array property specifies the character or characters that replace each wildcard. After each wildcard in a URI is replaced, the URI references a Resource property. A metric definition can apply to this property, or this property is included in a metric report. The property identifiers portion of the URI shall follow RFC6901-defined JSON fragment notation rules.
<b>MetricProperty</b>	MetricReport (MetricValues), TelemetryService (Actions > SubmitTestMetricReport (Action) > GeneratedMetricReportValues)	string	The URI for the property from which this metric is derived.
<b>MetricReport</b>	MetricReportDefinition	object	The location where the resultant metric report is placed.
<b>MetricReportDefinition</b>	EventService (SSEFilterPropertiesSupported)	boolean	An indication of whether the service supports the MetricReportDefinition property in the \$filter query parameter.
	MetricReport	object	The definitions in the metric report.
<b>MetricReportDefinitionEnabled</b>	MetricReportDefinition	boolean	An indication of whether the generation of new metric reports is enabled.
<b>MetricReportDefinitions</b>	EventDestination	array	A list of metric report definitions for which the service only sends related metric reports. If this property is absent or the array is empty, metric reports that originate from any metric report definition are sent to the subscriber.
	Triggers (Links)	array	The metric report definitions that generate new metric reports when a trigger condition is met and when the TriggerActions property contains 'RedfishMetricReport'.

	TelemetryService	object	The link to the collection of metric report definitions.
<b>MetricReportDefinitionType</b>	MetricReportDefinition	string (enum)	Specifies when the metric report is generated.
<b>MetricReportHeartbeatInterval</b>	MetricReportDefinition	string	The interval at which to send the complete metric report because the Redfish client wants refreshed metric data even when the data has not changed. This property value is always greater than the recurrence interval of a metric report, and it only applies when the SuppressRepeatedMetricValue property is `true`.
<b>MetricReportName</b>	TelemetryService (Actions > SubmitTestMetricReport (Action))	string	The name of the metric report in generated metric report.
<b>MetricReports</b>	TelemetryService	object	The link to the collection of metric reports.
<b>MetricReportValues</b>	TelemetryService (Actions > SubmitTestMetricReport (Action))	string	The contents of MetricReportValues array in the generated metric report.
<b>Metrics</b>	MetricReportDefinition	array	The list of metrics to include in the metric report. The metrics may include metric properties or calculations applied to a metric property.
	PowerDistribution	object	A link to the summary metrics for this equipment.
	ComputerSystem (MemorySummary)	object	The link to the metrics associated with all memory in this system.
	Port	object	The link to the metrics associated with this port.
	ComputerSystem (ProcessorSummary), Memory, Processor	object	The reference to the metrics related to all processors, a processor, or the memory in this system.
<b>MetricType</b>	Triggers	string (enum)	The metric type of the trigger.
	MetricDefinition	string (enum)	The type of metric.
<b>MetricValue</b>	MetricReport (MetricValues), TelemetryService (Actions > SubmitTestMetricReport (Action) > GeneratedMetricReportValues)	string	The metric value, as a string.
<b>MetricValues</b>	MetricReport	array	An array of metric values for the metered items of this Metric.
<b>MicrocodeInfo</b>	Processor (ProcessorId)	string	The microcode information for this processor.
<b>MinAllowableOperatingValue</b>	Thermal (Temperatures)	integer	Minimum allowable operating



		(Celsius)	temperature for this equipment.
	Sensor	number	The minimum allowable operating value for this equipment.
<b>MinAssignmentGroupSize</b>	NetworkAdapter (Controllers > ControllerCapabilities > VirtualizationOffload > VirtualFunction)	integer	The minimum number of virtual functions that can be allocated or moved between physical functions for this controller.
<b>MinBWAllocPercent</b>	NetworkPort (NetDevFuncMinBWAlloc)	integer (%)	The minimum bandwidth allocation percentage allocated to the corresponding network device function instance.
<b>MinCID</b>	AddressPool (GenZ)	integer	The minimum value for the Component Identifier (CID).
<b>MinCollectionInterval</b>	TelemetryService	string	The minimum time interval between gathering metric data that this service allows.
<b>MinConsumedWatts</b>	Power (PowerControl > PowerMetrics)	number (Watts)	The lowest power consumption level, in watts, over the measurement window that occurred within the last IntervalInMin minutes.
<b>MinimumFrequencyHz</b>	Power (PowerSupplies > InputRanges)	number (Hz)	The minimum line input frequency at which this power supply input range is effective.
<b>MinimumHopCount</b>	RouteEntry	integer	The minimum number of hops.
<b>MinimumValue</b>	ActionInfo (Parameters)	number	The minimum supported value for this parameter.
<b>MinimumVoltage</b>	Power (PowerSupplies > InputRanges)	number (Volts)	The minimum line input voltage at which this power supply input range is effective.
<b>MinLength</b>	AttributeRegistry (RegistryEntries > Attributes)	integer	The minimum character length of the string attribute.
<b>MinPasswordLength</b>	AccountService	integer	The minimum password length for this Account Service.
<b>MinReadingRange</b>	Thermal (Fans)	integer	Minimum value for this sensor.
	MetricDefinition	number	Minimum value for metric reading.
	Power (Voltages)	number (Volts)	Minimum value for this sensor.
<b>MinReadingRangeTemp</b>	Thermal (Temperatures)	number (Celsius)	Minimum value for this sensor.
<b>MinSID</b>	AddressPool (GenZ)	integer	The minimum value for the Subnet Identifier (SID).
<b>Model</b>	Volume	string	The model number for this storage volume.
	<i>various</i> (Assembly (Assemblies), Chassis ... )	string	The model number of this product or device.
	MediaController	string	The model of this media controller.
	FabricAdapter	string	The model string for this fabric

			adapter.
	PowerDistribution	string	The product model number of this equipment.
<b>ModifyRedundancySet (Action)</b>	Manager (Actions)	object	The ModifyRedundancySet operation adds members to or removes members from a redundant group of managers.
<b>ModuleManufacturerID</b>	Memory	string	The manufacturer ID of this memory module.
<b>ModuleProductID</b>	Memory	string	The product ID of this memory module.
<b>MPRT</b>	Port (GenZ)	object	the Multi-subnet Packet Relay Table for the port.
<b>MSDT</b>	FabricAdapter (GenZ)	object	The Multi Subnet Destination Table for the component.
<b>MTUSize</b>	EthernetInterface, NetworkDeviceFunction (Ethernet)	integer	The configured maximum transmission unit (MTU) for this interface.
<b>MultipartHttpPushUri</b>	UpdateService	string	The URI used to perform a Redfish Specification-defined Multipart HTTP or HTTPS push update to the Update Service.
<b>Multipath</b>	Drive	boolean	An indication of whether the drive is accessible from multiple paths.
<b>MutualCHAPSecret</b>	NetworkDeviceFunction (iSCSIBoot)	string	The CHAP secret for two-way CHAP authentication.
<b>MutualCHAPUsername</b>	NetworkDeviceFunction (iSCSIBoot)	string	The CHAP user name for two-way CHAP authentication.
<b>MutuallyExclusiveEndpoints</b>	Endpoint (Links)	array	An array of links to the endpoints that may not be used in zones if this endpoint is in a zone.
<b>NameServers</b>	EthernetInterface	array	The DNS servers in use on this interface.
<b>NegotiatedSpeedGbs</b>	Drive	number (Gbit/s)	The speed, in gigabit per second (Gbit/s), at which this drive currently communicates to the storage controller.
<b>NetDevFuncCapabilities</b>	NetworkDeviceFunction	array	An array of capabilities for this network device function.
<b>NetDevFuncMaxBWAlloc</b>	NetworkPort	array	An array of maximum bandwidth allocation percentages for the network device functions associated with this port.
<b>NetDevFuncMinBWAlloc</b>	NetworkPort	array	An array of minimum bandwidth allocation percentages for the network device functions associated with this port.
<b>NetDevFuncType</b>	NetworkDeviceFunction	string (enum)	The configured capability of this network device function.

<b>NetworkAdapter</b>	NetworkInterface (Links)	object	The link to the network adapter that contains this network interface.
<b>NetworkAdapters</b>	Chassis	object	The link to the collection of Network Adapters associated with this chassis.
<b>NetworkDeviceFunction</b>	Endpoint (Links)	array	When NetworkDeviceFunction Resources are present, this array contains links to the network device functions that connect to this endpoint.
	NetworkPort (NetDevFuncMaxBWAlloc), NetworkPort (NetDevFuncMinBWAlloc)	object	The link to the NetworkDeviceFunction associated with this bandwidth setting of this network port.
<b>NetworkDeviceFunctionCount</b>	NetworkAdapter (Controllers > ControllerCapabilities)	integer	The maximum number of physical functions available on this controller.
<b>NetworkDeviceFunctions</b>	NetworkAdapter (Controllers > Links), PCleFunction (Links)	array	An array of references to the network device functions that either a PCIe device produces or is associated with a network controller.
	NetworkAdapter, NetworkInterface	object	The reference to a collection of network device functions associated with a network adapter or network interface.
<b>NetworkInterfaces</b>	ResourceBlock	array	An array of links to the Network Interfaces available in this Resource Block.
	ComputerSystem	object	The link to the collection of Network Interfaces associated with this system.
<b>NetworkPortCount</b>	NetworkAdapter (Controllers > ControllerCapabilities)	integer	The number of physical ports on this controller.
<b>NetworkPortMaxCount</b>	NetworkAdapter (Controllers > ControllerCapabilities > VirtualizationOffload > VirtualFunction)	integer	The maximum number of virtual functions supported per network port for this controller.
<b>NetworkPorts</b>	NetworkAdapter (Controllers > Links)	array	An array of links to the NetworkPorts associated with this Network Controller.
	NetworkAdapter, NetworkInterface	object	The reference to a collection of network ports associated with this network adapter or network interface.
<b>NetworkProtocol</b>	HostInterface, Manager	object	The reference to the network services and their settings that the manager controls. The client can find the network configuration options and network services in this property.
<b>Neutral</b>	Circuit (PolyPhaseCurrentAmps), Outlet (PolyPhaseCurrentAmps)	object	Neutral line current sensor.
<b>NewManager</b>	Manager (Actions > ForceFailover (Action))	object	The manager to which to fail over.

<b>NewPassword</b>	Bios (Actions > ChangePassword (Action))	string	The new BIOS password.
<b>NoLinks</b>	ServiceRoot (ProtocolFeaturesSupported > ExpandQuery)	boolean	An indication of whether the service supports the period (`. `) option of the \$expand query parameter.
<b>NominalVoltage</b>	Circuit	string (enum)	The nominal voltage for this circuit.
	Outlet	string (enum)	The nominal voltage for this outlet.
<b>NonCRCTransientErrors</b>	PortMetrics (GenZ)	integer	The total number transient errors detected that are unrelated to CRC validation.
<b>NonVolatileSizeMiB</b>	Memory	integer (mebibytes)	Total size of the non-volatile portion memory in MiB.
<b>NotifyIPv6Scope</b>	ManagerNetworkProtocol (SSDP)	string (enum)	The IPv6 scope for multicast NOTIFY messages for SSDP.
<b>NotifyMulticastIntervalSeconds</b>	ManagerNetworkProtocol (SSDP)	integer (seconds)	The time interval, in seconds, between transmissions of the multicast NOTIFY ALIVE message from this service for SSDP.
<b>NotifyTTL</b>	ManagerNetworkProtocol (SSDP)	integer	The time-to-live hop count for SSDP multicast NOTIFY messages.
<b>NPAR</b>	NetworkAdapter (Controllers > ControllerCapabilities)	object	NIC Partitioning (NPAR) capabilities for this controller.
<b>NparCapable</b>	NetworkAdapter (Controllers > ControllerCapabilities > NPAR)	boolean	An indication of whether the controller supports NIC function partitioning.
<b>NparEnabled</b>	NetworkAdapter (Controllers > ControllerCapabilities > NPAR)	boolean	An indication of whether NIC function partitioning is active on this controller.
<b>NPIV</b>	NetworkAdapter (Controllers > ControllerCapabilities)	object	N_Port ID Virtualization (NPIV) capabilities for this controller.
<b>NTP</b>	ManagerNetworkProtocol	object	The settings for this manager's NTP protocol support.
<b>NTPServers</b>	ManagerNetworkProtocol (NTP)	array	Indicates to which NTP servers this manager is subscribed.
<b>NumberDiscoveredRemotePorts</b>	NetworkPort	integer	The number of ports not on this adapter that this port has discovered.
<b>NumberOfCompositions</b>	ResourceBlock (CompositionStatus)	integer	The number of compositions in which this Resource Block is currently participating.
<b>NumericThresholds</b>	Triggers	object	The thresholds when a numeric metric triggers.
<b>ObjectDataType</b>	ActionInfo (Parameters)	string	The data type of an object-based parameter.
<b>OccupancyBytes</b>	ProcessorMetrics (Cache), ProcessorMetrics (CoreMetrics > CoreCache)	integer (bytes)	The total cache level occupancy in bytes.
<b>OccupancyPercent</b>	ProcessorMetrics (Cache), ProcessorMetrics (CoreMetrics > CoreCache)	number (%)	The total cache occupancy percentage.

<b>OEMAccountTypes</b>	ManagerAccount	array	The OEM account types.
<b>OemLogEntryCode</b>	LogEntry	string	The OEM-specific entry code, if the LogEntryCode type is `OEM`.
<b>OemPrivileges</b>	Role	array	The OEM privileges for this Role.
<b>OEMPrivilegesUsed</b>	PrivilegeRegistry	array	The set of OEM privileges used in this mapping.
<b>OemRecordFormat</b>	LogEntry	string	The OEM-specific format of the entry. If the entry type is `Oem`, this property contains more information about the record format from the OEM.
<b>OemSensorType</b>	LogEntry	string	The OEM-specific sensor type if the sensor type is `OEM`.
<b>OemSessionType</b>	Session	string	The active OEM-defined session type.
<b>OffsetMiB</b>	MemoryChunks (InterleaveSets)	integer (mebibytes)	Offset within the DIMM that corresponds to the start of this memory region, measured in mebibytes (MiB).
	Memory (Regions)	integer (mebibytes)	Offset within the memory that corresponds to the start of this memory region in mebibytes (MiB).
<b>OldPassword</b>	Bios (Actions > ChangePassword (Action))	string	The existing BIOS password.
<b>OnlyMemberQuery</b>	ServiceRoot (ProtocolFeaturesSupported)	boolean	An indication of whether the service supports the only query parameter.
<b>OperatingMemoryModes</b>	Memory	array	Memory modes supported by the memory.
<b>OperatingMode</b>	EthernetInterface (DHCPv6)	string (enum)	Determines the DHCPv6 operating mode for this interface.
<b>OperatingSpeedMhz</b>	Memory	integer (MHz)	Operating speed of memory in MHz or MT/s as appropriate.
<b>OperationMap</b>	PrivilegeRegistry (Mappings), PrivilegeRegistry (Mappings > PropertyOverrides), PrivilegeRegistry (Mappings > ResourceURIOverrides), PrivilegeRegistry (Mappings > SubordinateOverrides)	object	The mapping between the HTTP method and privilege required for an entity or to complete an operation.
<b>OperationName</b>	Drive (Operations), Volume (Operations)	string	The name of the operation.
<b>Operations</b>	Drive, Volume	array	The operations currently running on the drive or volume.
<b>OptimumIOSizeBytes</b>	Volume	integer (bytes)	The size in bytes of this Volume's optimum IO size.
<b>Organization</b>	CertificateService (Actions > GenerateCSR (Action))	string	The name of the organization making the request.
	Certificate (Issuer), Certificate (Subject)	string	The name of the organization of the entity.

<b>OrganizationalUnit</b>	CertificateService (Actions > GenerateCSR (Action))	string	The name of the unit or division of the organization making the request.
	Certificate (Issuer), Certificate (Subject)	string	The name of the unit or division of the organization of the entity.
<b>OriginOfCondition</b>	Event (Events), LogEntry (Links)	object	The reference to the Resource that triggered the event.
	EventService (Actions > SubmitTestEvent (Action))	string	The URL in the OriginOfCondition property of the event to add. It is not a reference object.
<b>OriginResource</b>	EventService (SSEFilterPropertiesSupported)	boolean	An indication of whether the service supports the OriginResource property in the \$filter query parameter.
<b>OriginResources</b>	EventDestination	array	The array of Resources for which the service sends only related events. If this property is absent or the array is empty, the service sends the events that originate from any Resource to the subscriber.
<b>OutletGroups</b>	PowerDistribution	object	A link to the outlet groups for this equipment.
<b>Outlets</b>	Circuit (Links)	array	An array of references to the outlets contained by this circuit.
	OutletGroup (Links)	array	The set of outlets in this outlet group.
	PowerDistribution	object	A link to the outlets for this equipment.
<b>OutletType</b>	Outlet	string (enum)	The type of receptacle according to NEMA, IEC, or regional standards.
<b>OutputWattage</b>	Power (PowerSupplies > InputRanges)	number (Watts)	The maximum capacity of this power supply when operating in this input range.
<b>OverNominalFrequencyHz</b>	PowerDistribution (TransferCriteria)	number (Hz)	The frequency in Hertz over the nominal value that satisfies a criterion for transfer.
<b>OverVoltageRMSPercentage</b>	PowerDistribution (TransferCriteria)	number (%)	The positive percentage of voltage RMS over the nominal value that satisfies a criterion for transfer.
<b>OverWritePolicy</b>	LogService	string (enum)	The overwrite policy for this service that takes place when the log is full.
<b>OverwriteUnit (Action)</b>	Memory (Actions)	object	This contains the action for securely erasing given regions using the NIST SP800-88 Purge: Overwrite.
<b>OwningEntity</b>	AttributeRegistry	string	The organization or company that publishes this Attribute Registry.
	MessageRegistry	string	The organization or company that publishes this Message Registry.
<b>OwningStorageService</b>	Volume (Links)	object	A pointer to the StorageService that owns or contains this volume.
<b>PacketCRCErrors</b>	PortMetrics (GenZ)	integer	The total number of PCRC transient errors detected.
<b>PacketDeadlineDiscards</b>	PortMetrics (GenZ)	integer	The number of packets discarded due

			to the Congestion Deadline sub-field reaching zero.
<b>Parameters</b>	ActionInfo	array	The list of parameters included in the specified Redfish action.
<b>Parity</b>	SerialInterface	string (enum)	The type of parity used by the sender and receiver to detect errors over the serial connection.
<b>PartNumber</b>	<i>various</i> (Assembly (Assemblies), Chassis ... )	string	The part number for this device or Resource.
	PowerDistribution	string	The part number for this equipment.
	FabricAdapter	string	The part number for this fabric adapter.
	Manager	string	The part number of the manager.
	Processor	string	The part number of the processor.
	MediaController	string	The part number of this media controller.
<b>Passphrase</b>	Memory (Actions > DisablePassphrase (Action)), Memory (Actions > OverwriteUnit (Action)), Memory (Actions > SecureEraseUnit (Action)), Memory (Actions > SetPassphrase (Action))	string	Passphrase for doing the operation.
	Memory (Actions > UnlockUnit (Action))	string	The passphrase required to complete the operation.
<b>PassphraseCapable</b>	Memory (SecurityCapabilities)	boolean	An indication of whether the memory is passphrase capable.
<b>PassphraseEnabled</b>	Memory (Regions)	boolean	An indication of whether the passphrase is enabled for this region.
<b>PassphraseLockLimit</b>	Memory (SecurityCapabilities)	integer	The maximum number of incorrect passphrase attempts allowed before memory is locked.
<b>PassphraseState</b>	Memory (Regions)	boolean	An indication of whether the state of the passphrase for this region is enabled.
<b>Password</b>	EventService (SMTP)	string	The password for authentication with the SMTP server. The value is `null` in responses.
	AccountService (ActiveDirectory > Authentication), AccountService (LDAP > Authentication), ExternalAccountProvider (Authentication), ManagerAccount, Session, VirtualMedia	string	The password to access an Image parameter-specified URI, create a session, write the password for an account service or an account. A GET of this property returns null.
	VirtualMedia (Actions >	string	The password to access the Image

	InsertMedia (Action))		parameter-specified URI.
	UpdateService (Actions > SimpleUpdate (Action))	string	The password to access the URI specified by the ImageURI parameter.
<b>PasswordChangeRequired</b>	ManagerAccount	boolean	An indication of whether the service requires that the password for this account be changed before further access to the account is allowed.
<b>PasswordName</b>	Bios (Actions > ChangePassword (Action))	string	The name of the BIOS password to change.
<b>PasswordSet</b>	AccountService (ActiveDirectory), AccountService (LDAP)	boolean	Indicates if the Password property is set.
<b>PATCH</b>	PrivilegeRegistry (Mappings > OperationMap), PrivilegeRegistry (Mappings > PropertyOverrides > OperationMap), PrivilegeRegistry (Mappings > ResourceURIOverrides > OperationMap), PrivilegeRegistry (Mappings > SubordinateOverrides > OperationMap)	array	The privilege required to complete an HTTP PATCH operation.
<b>Payload</b>	Job, Task	object	The HTTP and JSON payload details for a job or task.
<b>PciClassCode</b>	Endpoint (ConnectedEntities)	string	The Class Code, Subclass, and Programming Interface code of this PCIe function.
<b>PCle</b>	Processor (FPGA > ExternalInterfaces), Processor (FPGA > HostInterface)	object	The PCIe-related information for this FPGA interface.
<b>PCleDevice</b>	PCleSlots (Slots > Links)	array	An array of links to the PCIe devices contained in this slot.
	PCleFunction (Links), Processor (Links)	object	The reference to the PCIe device associated with a processor or on which a function resides.
<b>PCleDevices</b>	Chassis (Links), ComputerSystem, NetworkAdapter (Controllers > Links)	array	An array of references to a collection of PCIe devices that a computer system uses or a chassis contains, or that is associated with a network controller.
	Chassis	object	The link to the collection of PCIe devices located in this chassis.
<b>PCleFunction</b>	NetworkDeviceFunction (Links)	object	The link to the PCIe function associated with this network device function.
<b>PCleFunctions</b>	AccelerationFunction (Links), ComputerSystem, Drive (Links), PCleDevice (Links), Processor (Links), Storage (StorageControllers >	array	An array of references to a collection of PCIe devices that a computer system uses, a device exposes, a drive or storage controller produces, or that is associated with a processor or an acceleration function.



	Links)		
	PCleDevice	object	The link to the collection of PCIe functions associated with this PCIe device.
<b>PCleInterface</b>	NetworkAdapter (Controllers), PCleDevice, Storage (StorageControllers)	object	The PCIe interface details for a PCIe device or controller.
	FabricAdapter	object	The PCIe interface details for this fabric adapter.
<b>PCleSlots</b>	Chassis	object	The link to the PCIe slot properties for this chassis.
<b>PCleType</b>	PCleDevice (PCleInterface), PCleSlots (Slots)	string (enum)	The version of the PCIe Specification that a device uses or a slot supports.
<b>PCleVirtualFunctions</b>	Processor (FPGA)	integer	The number of the PCIe Virtual Functions.
<b>PciFunctionNumber</b>	Endpoint (ConnectedEntities)	integer	The PCI ID of the connected entity.
<b>Pcild</b>	Endpoint	object	The PCI ID of the endpoint.
<b>PeakPowerBudgetMilliWatts</b>	Memory (PowerManagementPolicy)	integer (milliWatts)	Peak power budget, in milliwatts.
<b>PeakReading</b>	Sensor	number	The peak sensor value.
<b>PeakReadingTime</b>	Sensor	string	The time when the peak sensor value occurred.
<b>PercentageComplete</b>	Volume (Operations)	integer	The percentage of the operation that has been completed.
	Drive (Operations)	integer (%)	The percentage of the operation that has been completed.
<b>PercentComplete</b>	Job	integer (%)	The completion percentage of this job.
	Task	integer (%)	The completion percentage of this task.
<b>PerformanceDegraded</b>	MemoryMetrics (HealthData)	boolean	An indication of whether performance has degraded.
<b>PermanentMACAddress</b>	EthernetInterface, NetworkDeviceFunction (Ethernet)	string	The permanent MAC address assigned to a port or network device, or physical, function.
<b>PermanentWWNN</b>	NetworkDeviceFunction (FibreChannel)	string	The permanent World Wide Node Name (WWNN) address assigned to this function.
<b>PermanentWWPN</b>	NetworkDeviceFunction (FibreChannel)	string	The permanent World Wide Port Name (WWPN) address assigned to this function.
<b>PersistentCacheSizeMiB</b>	Storage (StorageControllers > CacheSummary)	integer (mebibytes)	The portion of the cache memory that is persistent, measured in MiB.
<b>PersistentRegionNumberLimit</b>	Memory	integer	Total number of persistent regions this memory can support.
<b>PersistentRegionSizeLimitMiB</b>	Memory	integer (mebibytes)	Total size of persistent regions in mebibytes (MiB).

<b>PersistentRegionSizeMaxMiB</b>	Memory	integer (mebibytes)	Maximum size of a single persistent region in mebibytes (MiB).
<b>PhaseWiringType</b>	Circuit, Outlet	string (enum)	The number of ungrounded current-carrying conductors (phases) and the total number of conductors (wires).
<b>PhysicalContext</b>	Assembly (Assemblies), MetricDefinition, Power (PowerControl), Power (Voltages), Sensor, Thermal (Fans), Thermal (Temperatures)	string (enum)	The physical context, or the area, device, or set of devices, for this Resource.
<b>PhysicalLocation</b>	Drive	object	The location of the drive.
<b>PhysicalPortAssignment</b>	NetworkDeviceFunction (Links), NetworkDeviceFunction	object	The physical port to which this network device function is currently assigned.
<b>PhysicalPortNumber</b>	NetworkPort	string	The physical port number label for this port.
<b>PhysicalSecurity</b>	Chassis	object	The state of the physical security sensor.
<b>PhysicalSubContext</b>	Sensor	string (enum)	The usage or location within a device to which this sensor measurement applies.
<b>PIDT</b>	FabricAdapter (GenZ)	array	An array of table entry values for the Packet Injection Delay Table.
<b>PinOut</b>	SerialInterface	string (enum)	The physical pinout configuration for a serial connector.
<b>PlugType</b>	Circuit	string (enum)	The type of plug according to NEMA, IEC, or regional standards.
<b>PolicyEnabled</b>	Memory (PowerManagementPolicy)	boolean	An indication of whether the power management policy is enabled.
<b>PolyPhaseCurrentAmps</b>	Circuit	object	The current readings for this circuit.
	Outlet	object	The current readings for this outlet.
<b>PolyPhaseEnergykWh</b>	Circuit	object	The energy readings for this circuit.
<b>PolyPhasePowerWatts</b>	Circuit	object	The power readings for this circuit.
<b>PolyPhaseVoltage</b>	Circuit	object	The voltage readings for this circuit.
	Outlet	object	The voltage readings for this outlet.
<b>Port</b>	EventService (SMTP)	integer	The destination SMTP port.
	<i>various</i> (ManagerNetworkProtocol (DHCP), ManagerNetworkProtocol (DHCPv6) ... )	integer	The protocol port.
	Endpoint (IPTransportDetails)	number	The UDP or TCP port number used by the endpoint.
<b>PortId</b>	Port	string	The label of this port on the physical package for this port.

<b>PortMaximumMTU</b>	NetworkPort	integer	The largest maximum transmission unit (MTU) that can be configured for this network port.
<b>PortMedium</b>	Port	string (enum)	The physical connection medium for this port.
<b>PortProtocol</b>	Port	string (enum)	The protocol being sent over this port.
<b>Ports</b>	Endpoint (Links)	array	An array of links to the physical ports associated with this endpoint.
	Storage (StorageControllers), Switch	object	The collection of ports that a switch or a storage controller contains.
	MediaController	object	The link to the collection of ports associated with this media controller.
	FabricAdapter	object	The link to the collection of ports that exist on the fabric adapter.
<b>PortType</b>	Port	string (enum)	The type of this port.
<b>POST</b>	PrivilegeRegistry (Mappings > OperationMap), PrivilegeRegistry (Mappings > PropertyOverrides > OperationMap), PrivilegeRegistry (Mappings > ResourceURIOverrides > OperationMap), PrivilegeRegistry (Mappings > SubordinateOverrides > OperationMap)	array	The required privilege for the HTTP POST operation.
<b>Power</b>	Chassis	object	The link to the power properties, or power supplies, power policies, and sensors, for this chassis.
<b>PowerAllocatedWatts</b>	Power (PowerControl)	number (Watts)	The total amount of power that has been allocated or budgeted to chassis.
<b>PowerAvailableWatts</b>	Power (PowerControl)	number (Watts)	The amount of reserve power capacity, in watts, that remains. This value is the PowerCapacity value minus the PowerAllocated value.
<b>PowerCapacityWatts</b>	Power (PowerSupplies)	number (Watts)	The maximum capacity of this power supply.
	Power (PowerControl)	number (Watts)	The total amount of power that can be allocated to the chassis. This value can be either the power supply capacity or the power budget that an upstream chassis assigns to this chassis.
<b>PowerConsumedWatts</b>	Power (PowerControl)	number (Watts)	The actual power that the chassis consumes, in watts.
<b>PowerControl</b>	Power	array	The set of power control functions, including power reading and limiting.
<b>PowerControl (Action)</b>	Circuit (Actions)	object	This action turns the circuit on or off.

	OutletGroup (Actions)	object	This action turns the outlet group on or off.
	Outlet (Actions)	object	This action turns the outlet on or off.
<b>PowerCycleDelaySeconds</b>	Circuit, Outlet, OutletGroup	number	The number of seconds to delay power on after a PowerControl action to cycle power. Zero seconds indicates no delay.
<b>PowerDomains</b>	Facility	object	Link to the power domains in this facility.
<b>PoweredBy</b>	Chassis (Links), ComputerSystem (Links)	array	An array of IDs of the Resources that power this chassis or system. Each ID in the array is for a chassis or a specific set of power supplies.
<b>PowerEnabled</b>	Circuit	boolean	Indicates if the circuit can be powered.
	Outlet	boolean	Indicates if the outlet can be powered.
	OutletGroup	boolean	Indicates if the outlet group can be powered.
<b>PowerEquipment</b>	ServiceRoot	object	The link to a set of power equipment.
<b>PowerFactor</b>	<i>various</i> (Circuit (PolyPhasePowerWatts > Line1ToLine2), Circuit (PolyPhasePowerWatts > Line1ToNeutral) ... )	number	The power factor for this sensor.
<b>PowerInputWatts</b>	Power (PowerSupplies)	number (Watts)	The measured input power of this power supply.
<b>PowerLimit</b>	Power (PowerControl)	object	The power limit status and configuration information for this chassis.
<b>PowerManagementPolicy</b>	Memory	object	Power management policy information.
<b>PowerMetrics</b>	Power (PowerControl)	object	The power readings for this chassis.
<b>PowerOffDelaySeconds</b>	Circuit, Outlet, OutletGroup	number	The number of seconds to delay power off after a PowerControl action. Zero seconds indicates no delay to power off.
<b>PowerOnDelaySeconds</b>	Circuit, Outlet, OutletGroup	number	The number of seconds to delay power up after a power cycle or a PowerControl action. Zero seconds indicates no delay to power up.
<b>PowerOutputWatts</b>	Power (PowerSupplies)	number (Watts)	The measured output power of this power supply.
<b>PowerRequestedWatts</b>	Power (PowerControl)	number (Watts)	The potential power, in watts, that the chassis requests, which may be higher than the current level being consumed because the requested power includes a budget that the chassis wants for future use.
<b>PowerRestoreDelaySeconds</b>	Circuit, Outlet,	number	The number of seconds to delay power on after power has been

	OutletGroup		restored. Zero seconds indicates no delay.
<b>PowerRestorePolicy</b>	Circuit	string (enum)	The desired power state of the circuit when power is restored after a power loss.
	OutletGroup	string (enum)	The desired power state of the outlet group when power is restored after a power loss.
	Outlet	string (enum)	The desired power state of the outlet when power is restored after a power loss.
	ComputerSystem	string (enum)	The desired power state of the system when power is restored after a power loss.
<b>PowerState</b>	Chassis, ComputerSystem, Manager, Switch	string (enum)	The current power state of the chassis, manager, switch or computer system.
	Circuit (Actions > BreakerControl (Action))	string (enum)	The desired power state of the circuit if the breaker is reset successfully.
	Circuit (Actions > PowerControl (Action))	string (enum)	The desired power state of the circuit.
	OutletGroup (Actions > PowerControl (Action))	string (enum)	The desired power state of the outlet group.
	Outlet (Actions > PowerControl (Action))	string (enum)	The desired power state of the outlet.
	Circuit	string (enum)	The power state of the circuit.
	OutletGroup	string (enum)	The power state of the outlet group.
	Outlet	string (enum)	The power state of the outlet.
<b>PowerSupplies</b>	Power	array	The set of power supplies associated with this system or device.
<b>PowerSupplyReset (Action)</b>	Power (Actions)	object	This action resets the targeted power supply.
<b>PowerSupplyType</b>	Power (PowerSupplies)	string (enum)	The power supply type (AC or DC).
<b>PowerWatts</b>	AccelerationFunction	integer (Watts)	The acceleration function power consumption, in watts.
	Circuit	object	The power reading for this circuit.
	OutletGroup	object	The power reading for this outlet group.
	Outlet	object	The power reading for this outlet.
	PowerDistributionMetrics	object	The total power reading for this equipment.
<b>Precedence</b>	EthernetInterface (IPv6AddressPolicyTable)	integer	The IPv6 precedence, as defined in RFC6724, section 2.1.

<b>Precision</b>	MetricDefinition	integer	Number of significant digits in the metric reading.
	Sensor	number	The number of significant digits in the reading.
<b>PredictedMediaLifeLeftPercent</b>	Drive	number (%)	The percentage of reads and writes that are predicted to be available for the media.
	MemoryMetrics (HealthData)	number (%)	The percentage of reads and writes that are predicted to still be available for the media.
<b>PreferredMainsId</b>	PowerDistribution (TransferConfiguration)	string	The preferred source for the mains circuit to this equipment.
<b>Prefix</b>	EthernetInterface (IPv6AddressPolicyTable)	string	The IPv6 address prefix, as defined in RFC6724, section 2.1.
<b>PrimaryDNS</b>	NetworkDeviceFunction (iSCSIBoot)	string	The IPv6 or IPv4 address of the primary DNS server for the iSCSI boot initiator.
<b>PrimaryLUN</b>	NetworkDeviceFunction (iSCSIBoot)	integer	The logical unit number (LUN) for the primary iSCSI boot target.
<b>PrimaryTargetIPAddress</b>	NetworkDeviceFunction (iSCSIBoot)	string	The IPv4 or IPv6 address for the primary iSCSI boot target.
<b>PrimaryTargetName</b>	NetworkDeviceFunction (iSCSIBoot)	string	The name of the iSCSI primary boot target.
<b>PrimaryTargetTCPPort</b>	NetworkDeviceFunction (iSCSIBoot)	integer	The TCP port for the primary iSCSI boot target.
<b>PrimaryVLANEnable</b>	NetworkDeviceFunction (iSCSIBoot)	boolean	An indication of whether the primary VLAN is enabled.
<b>PrimaryVLANId</b>	NetworkDeviceFunction (iSCSIBoot)	integer	The 802.1q VLAN ID to use for iSCSI boot from the primary target.
<b>PrivateEnterpriseId</b>	ManagerNetworkProtocol (SNMP > EngineId)	string	The private enterprise ID.
<b>Privilege</b>	<i>various</i> (PrivilegeRegistry (Mappings > OperationMap > DELETE), PrivilegeRegistry (Mappings > OperationMap > GET) ... )	array	An array of privileges that are required to complete a specific HTTP operation on a Resource.
<b>PrivilegeMap</b>	AccountService	object	The link to the mapping of the privileges required to complete a requested operation on a URI associated with this Service.
<b>PrivilegesUsed</b>	PrivilegeRegistry	array	The set of Redfish standard privileges used in this mapping.
<b>ProcessorArchitecture</b>	Processor	string (enum)	The architecture of the processor.
<b>ProcessorId</b>	Processor	object	The identification information for this processor.
<b>ProcessorMemory</b>	Processor	array	The memory directly attached or integrated within this Processor.

<b>Processors</b>	Chassis (Links), ResourceBlock	array	An array of references to the processors in this Resource block or chassis.
	ComputerSystem	object	The link to the collection of processors associated with this system.
<b>ProcessorSummary</b>	ComputerSystem	object	The central processors of the system in general detail.
<b>ProcessorType</b>	Processor	string (enum)	The type of processor.
<b>Producer</b>	Assembly (Assemblies)	string	The producer or manufacturer of the assembly.
<b>Product</b>	ServiceRoot	string	The product associated with this Redfish Service.
<b>ProductionDate</b>	Assembly (Assemblies)	string	The production date of the assembly.
	PowerDistribution	string	The production or manufacturing date of this equipment.
<b>ProductName</b>	AttributeRegistry (SupportedSystems)	string	The product name of the computer system to which this Attribute Registry applies.
<b>ProgrammableFromHost</b>	Processor (FPGA), Processor (FPGA > ReconfigurationSlots)	boolean	An indication of whether system software on the host can reprogram the FPGA firmware or the reconfiguration slot.
<b>PropertyOverrides</b>	PrivilegeRegistry (Mappings)	array	The privilege overrides of properties within a Resource.
<b>Protocol</b>	Drive, EventDestination	string (enum)	The protocol that either a drive uses to communicate with the storage controller or the event uses to communicate with the destination.
<b>ProtocolEnabled</b>	<i>various</i> (ManagerNetworkProtocol (DHCP), ManagerNetworkProtocol (DHCPv6) ... )	boolean	An indication of whether the protocol is enabled.
<b>ProtocolFeaturesSupported</b>	ServiceRoot	object	The information about protocol features that the service supports.
<b>ProvisioningPolicy</b>	Volume	string (enum)	This property specifies the volume's storage allocation, or provisioning policy.
<b>PublicationUri</b>	JsonSchemaFile (Location)	string	The link to publicly available (canonical) URI for schema.
	MessageRegistryFile (Location)	string	The link to publicly available (canonical) URI for the Message Registry.
<b>PUT</b>	PrivilegeRegistry (Mappings > OperationMap), PrivilegeRegistry (Mappings > PropertyOverrides > OperationMap), PrivilegeRegistry (Mappings >	array	The required privilege for the HTTP PUT operation.

	ResourceURIOverrides > OperationMap), PrivilegeRegistry (Mappings > SubordinateOverrides > OperationMap)		
<b>RackPDUs</b>	Facility (Links)	array	An array of links to the rack-level power distribution units in this facility.
	PowerDomain (Links)	array	An array of links to the rack-level power distribution units in this power domain.
	PowerEquipment	object	A link to a collection of rack-level power distribution units.
<b>RAIDType</b>	Volume	string (enum)	The RAID type of this volume.
<b>RankCount</b>	Memory	integer	Number of ranks available in the memory.
<b>RatedCurrentAmps</b>	Circuit	number (A)	The rated maximum current allowed for this circuit.
	Outlet	number (A)	The rated maximum current allowed for this outlet.
<b>RawEntryHex</b>	VCATEntry	string	The hexadecimal value of the Virtual Channel Action Table entries.
	RouteEntry	string	The raw data of route entry rows.
<b>RDP</b>	ManagerNetworkProtocol	object	The settings for this manager's Remote Desktop Protocol support.
<b>ReactiveVAR</b>	<i>various</i> (Circuit (PolyPhasePowerWatts > Line1ToLine2), Circuit (PolyPhasePowerWatts > Line1ToNeutral) ... )	number (V.A)	The square root of the difference term of squared ApparentVA and squared Power (Reading) for a circuit, in var units.
<b>ReadCachePolicy</b>	Volume	string (enum)	Indicates the read cache policy setting for the Volume.
<b>Reading</b>	Thermal (Fans)	integer	The fan speed.
	<i>various</i> (Circuit (CurrentAmps), Circuit (EnergykWh) ... )	number	The sensor value.
	Sensor (Thresholds > LowerCaution), Sensor (Thresholds > LowerCritical), Sensor (Thresholds > LowerFatal), Sensor (Thresholds > UpperCaution), Sensor (Thresholds > UpperCritical), Sensor (Thresholds > UpperFatal), Triggers (NumericThresholds > LowerCritical), Triggers (NumericThresholds > LowerWarning), Triggers (NumericThresholds >	number	The threshold value.



	UpperCritical), Triggers (NumericThresholds > UpperWarning)		
<b>ReadingCelsius</b>	Thermal (Temperatures)	number (Celsius)	The temperature in degrees Celsius.
<b>ReadingRangeMax</b>	Sensor	number	The maximum possible value for this sensor.
<b>ReadingRangeMin</b>	Sensor	number	The minimum possible value for this sensor.
<b>ReadingTime</b>	Sensor	string	The date and time that the reading was acquired from the sensor.
<b>ReadingType</b>	Sensor	string (enum)	The type of sensor.
<b>ReadingUnits</b>	Sensor	string	The units in which the reading and thresholds are measured.
	Thermal (Fans)	string (enum)	The units in which the fan reading and thresholds are measured.
<b>ReadingVolts</b>	Power (Voltages)	number (Volts)	The reading of the voltage sensor.
<b>ReadOnly</b>	AttributeRegistry (RegistryEntries > Attributes), AttributeRegistry (RegistryEntries > Menus)	boolean	An indication of whether this attribute or menu is read-only.
<b>RebuildRatePercent</b>	Storage (StorageControllers > ControllerRates)	integer	The percentage of controller Resources used for rebuilding/repairing volumes.
<b>ReceivedECN</b>	PortMetrics (GenZ)	integer	The number of packets received on this interface with the Congestion ECN bit set.
<b>ReconfigurationSlots</b>	Processor (FPGA)	array	An array of the FPGA reconfiguration slots. An FPGA uses a reconfiguration slot to contain an acceleration function that can change as the FPGA is provisioned.
<b>RecoverableCapacitySourceCount</b>	Volume	integer	Current number of capacity source resources that are available as replacements.
<b>RedfishVersion</b>	ServiceRoot	string	The version of the Redfish Service.
<b>Redundancy</b>	ComputerSystem, Endpoint, Manager, Power (PowerSupplies), Power, Storage, Switch, Thermal (Fans), Thermal	array	The reference to a collection of redundancy entities. These entities name a set of computer systems that provide redundancy, show how an endpoint or manager is grouped with other endpoints or managers to form redundancy sets, or provide redundancy information for the power subsystem of a system or device, the storage subsystem, the switches, or fans. For power supplies or fans, the component IDs reference the members of the redundancy groups.
<b>RegionId</b>	MemoryChunks	string	DIMM region identifier.

	(InterleaveSets)		
	Memory (Actions > DisablePassphrase (Action)), Memory (Actions > OverwriteUnit (Action)), Memory (Actions > SecureEraseUnit (Action)), Memory (Actions > SetPassphrase (Action)), Memory (Actions > UnlockUnit (Action))	string	The memory region ID to which to apply this action.
	Memory (Regions)	string	Unique region ID representing a specific region within the memory.
<b>RegionKey</b>	Endpoint (ConnectedEntities > GenZ)	string	The Region Key for the entity.
<b>Regions</b>	Memory	array	Memory regions information within the memory.
<b>Registries</b>	ServiceRoot	object	The link to a collection of Registries.
<b>Registry</b>	MessageRegistryFile	string	The registry name and its major and minor versions. This registry can be any type of registry, such as a Message Registry, Privilege Registry, or Attribute Registry.
<b>RegistryEntries</b>	AttributeRegistry	object	The list of all attributes and their metadata for this component.
<b>RegistryPrefix</b>	EventService (SSEFilterPropertiesSupported)	boolean	An indication of whether the service supports the RegistryPrefix property in the \$filter query parameter.
	MessageRegistry	string	The single-word prefix that is used in forming and decoding MessageIds.
<b>RegistryPrefixes</b>	EventDestination	array	The list of the prefixes for the Message Registries that contain the MessageIds that are sent to this event destination.
	EventService	array	The list of the prefixes of the Message Registries that can be used for the RegistryPrefix property on a subscription. If this property is absent or contains an empty array, the service does not support RegistryPrefix-based subscriptions.
<b>RegistryVersion</b>	AttributeRegistry	string	The Attribute Registry version.
	MessageRegistry	string	The Message Registry version in the middle portion of a MessageId.
<b>Rekey (Action)</b>	Certificate (Actions)	object	This action generates a new key-pair for a certificate and produces a certificate signing request.
<b>RelatedItem</b>	BootOption, Power (PowerControl), Power (PowerSupplies), Power (Voltages), SoftwareInventory, Thermal (Fans),	array	The areas or devices related to this Resource.

	Thermal (Temperatures)		
<b>ReleaseDate</b>	SoftwareInventory	string	The release date of this software.
<b>RemainingCapacityPercent</b>	Volume	integer	The percentage of the capacity remaining in the Volume.
<b>RemainingSpareBlockPercentage</b>	MemoryMetrics (HealthData)	number (%)	The remaining spare blocks, as a percentage.
<b>RemoteAccountService</b>	Manager	object	The link to the AccountService Resource for the remote manager that this Resource represents.
<b>RemoteGroup</b>	AccountService (ActiveDirectory > RemoteRoleMapping), AccountService (LDAP > RemoteRoleMapping), ExternalAccountProvider (RemoteRoleMapping)	string	The name of the remote group, or the remote role in the case of a Redfish Service, that maps to the local Redfish Role to which this entity links.
<b>RemoteMemoryBandwidthBytes</b>	ProcessorMetrics	integer (bytes)	The remote memory bandwidth usage in bytes.
<b>RemoteRedfishServiceUri</b>	Manager	string	The URI of the Redfish Service Root for the remote manager that this Resource represents.
<b>RemoteRoleMapping</b>	AccountService (ActiveDirectory), AccountService (LDAP), ExternalAccountProvider	array	The mapping rules to convert the external account providers account information to the local Redfish Role.
<b>RemoteUser</b>	AccountService (ActiveDirectory > RemoteRoleMapping), AccountService (LDAP > RemoteRoleMapping), ExternalAccountProvider (RemoteRoleMapping)	string	The name of the remote user that maps to the local Redfish Role to which this entity links.
<b>Remove</b>	Manager (Actions > ModifyRedundancySet (Action))	array	An array of managers to remove from the redundancy set.
<b>RemoveReplicaRelationship (Action)</b>	Volume (Actions)	object	This action is used to disable data synchronization between a source and target volume, remove the replication relationship, and optionally delete the target volume.
<b>RemoveResourceBlock (Action)</b>	ComputerSystem (Actions)	object	This action removes a Resource Block from a system.
<b>Renew (Action)</b>	Certificate (Actions)	object	This action generates a certificate signing request by using the existing information and key-pair of the certificate.
<b>ReplaceCertificate (Action)</b>	CertificateService (Actions)	object	This action replaces a certificate.
<b>ReplicaInfo</b>	Volume	object	Describes this storage volume in its role as a target replica.
<b>ReplicaTargets</b>	Volume	array	The resources that are target replicas of this source.
<b>ReplicaType</b>	Volume (Actions >	string	The type of replica relationship to be

	AssignReplicaTarget (Action)), Volume (Actions > CreateReplicaTarget (Action))	(enum)	created.
<b>ReplicaUpdateMode</b>	Volume (Actions > AssignReplicaTarget (Action)), Volume (Actions > CreateReplicaTarget (Action))	string (enum)	The replica update mode (synchronous vs asynchronous).
<b>ReportActions</b>	MetricReportDefinition	array	The set of actions to perform when a metric report is generated.
<b>ReportActionsEnum</b>	MetricReportDefinition (ReportActions)	string (enum)	Actions to perform when a metric report is generated.
<b>ReportSequence</b>	MetricReport	string	The current sequence identifier for this metric report.
<b>ReportTimespan</b>	MetricReportDefinition	string	Specifies the timespan duration of the metric report.
<b>ReportUpdates</b>	MetricReportDefinition	string (enum)	When logging metric reports, specifies how subsequent metric reports are handled in relationship to an existing metric report created from the metric report definition. Namely, whether to overwrite, append, or create a report Resource.
<b>RequestorVCAT</b>	FabricAdapter (GenZ)	object	The Requestor Virtual Channel Action Table for the component.
<b>Required</b>	ActionInfo (Parameters)	boolean	An indication of whether the parameter is required to complete this action.
<b>Reserved</b>	ResourceBlock (CompositionStatus)	boolean	An indication of whether any client has reserved the Resource Block.
<b>Reset (Action)</b>	Processor (Actions)	object	This action resets the processor.
	Chassis (Actions)	object	This action resets this chassis but not related Resources. However, a reset of the chassis can affect those related Resources.
	Drive (Actions)	object	This action resets this drive.
	MediaController (Actions)	object	This action resets this media controller.
	Memory (Actions)	object	This action resets this memory.
	ComputerSystem (Actions), Manager (Actions), Port (Actions), Switch (Actions)	object	This action resets this Resource.
<b>ResetBios (Action)</b>	Bios (Actions)	object	This action resets the BIOS attributes to default.
<b>ResetKeys (Action)</b>	SecureBoot (Actions)	object	This action resets the Secure Boot keys.
<b>ResetKeysType</b>	SecureBoot (Actions > ResetKeys (Action))	string (enum)	The type of keys to reset or delete.
<b>ResetMetrics (Action)</b>	Sensor (Actions)	object	Resets metrics related to this sensor.

	Circuit (Actions)	object	This action resets metrics related to this circuit.
	OutletGroup (Actions)	object	This action resets metrics related to this outlet group.
	Outlet (Actions)	object	This action resets metrics related to this outlet.
	PowerDistributionMetrics (Actions)	object	This action resets the summary metrics related to this equipment.
<b>ResetRequired</b>	AttributeRegistry (RegistryEntries > Attributes)	boolean	An indication of whether a system or device reset is required for this attribute value change to take effect.
<b>ResetSettingsToDefault (Action)</b>	NetworkAdapter (Actions)	object	This action is to clear the settings back to factory defaults.
<b>ResetType</b>	Chassis (Actions > Reset (Action)), ComputerSystem (Actions > Reset (Action)), Drive (Actions > Reset (Action)), Manager (Actions > Reset (Action)), MediaController (Actions > Reset (Action)), Memory (Actions > Reset (Action)), Port (Actions > Reset (Action)), Power (Actions > PowerSupplyReset (Action)), Processor (Actions > Reset (Action)), Switch (Actions > Reset (Action))	string (enum)	The type of reset.
<b>ResidencyPercent</b>	ProcessorMetrics (CoreMetrics > CStateResidency)	number (%)	The percentage of time that the processor or core has spent in this particular level of C-state.
<b>ResourceBlock</b>	ComputerSystem (Actions > AddResourceBlock (Action))	object	The Resource Block to add to the system.
	ComputerSystem (Actions > RemoveResourceBlock (Action))	object	The Resource Block to remove from the system.
<b>ResourceBlockETag</b>	ComputerSystem (Actions > AddResourceBlock (Action))	string	The current ETag of the Resource Block to add to the system.
	ComputerSystem (Actions > RemoveResourceBlock (Action))	string	The current ETag of the Resource Block to remove from the system.
<b>ResourceBlocks</b>	Chassis (Links)	array	An array of references to the Resource blocks that this chassis contains.
	ComputerSystem (Links), Zone (Links)	array	An array of references to the Resource blocks that this system or zone uses.
	ServiceRoot	object	The link to a collection of all Resource Block Resources. This collection is

			intended for implementations that do not contain a Composition Service but that expose Resources to an orchestrator that implements a Composition Service.
	CompositionService	object	The Resource Blocks available on the service.
<b>ResourceBlockType</b>	ResourceBlock	array	The types of Resources available on this Resource Block.
<b>ResourceType</b>	EventService (SSEFilterPropertiesSupported)	boolean	An indication of whether the service supports the ResourceType property in the \$filter query parameter.
<b>ResourceTypes</b>	EventService	array	The list of @odata.type values, or Schema names, that can be specified in the ResourceTypes array in a subscription. If this property is absent or contains an empty array, the service does not support Resource type-based subscriptions.
	EventDestination	array	The list of Resource Type values (Schema names) that correspond to the OriginOfCondition. The version and full namespace should not be specified.
<b>ResourceURIOverrides</b>	PrivilegeRegistry (Mappings)	array	The privilege overrides of Resource URIs.
<b>ResourceZones</b>	CompositionService	object	The Resource Zones available on the service.
<b>ResponderVCAT</b>	FabricAdapter (GenZ)	object	The Responder Virtual Channel Action Table for the component.
<b>ResultMetric</b>	MetricDefinition (CalculationParameters)	string	The link to a metric property that stores the result of the calculation.
<b>ResumeReplication (Action)</b>	Volume (Actions)	object	This action is used to resume the active data synchronization between a source and target volume, without otherwise altering the replication relationship.
<b>ResumeSubscription (Action)</b>	EventDestination (Actions)	object	This action resumes a suspended event subscription.
<b>RetransferDelaySeconds</b>	PowerDistribution (TransferConfiguration)	integer	The time in seconds to delay the automatic transfer from the alternate mains circuit back to the preferred mains circuit.
<b>RetransferEnabled</b>	PowerDistribution (TransferConfiguration)	boolean	Indicates if the automatic transfer is permitted from the alternate mains circuit back to the preferred mains circuit after the preferred mains circuit is qualified again and the Retransfer Delay time has expired.
<b>ReverseReplicationRelationship (Action)</b>	Volume (Actions)	object	This action is used to reverse the replication relationship between a source and target volume.
<b>Revision</b>	Drive	string	The revision of this drive. This is

			typically the firmware or hardware version of the drive.
<b>RevisionId</b>	PCleFunction	string	The Revision ID of this PCIe function.
<b>RFB</b>	ManagerNetworkProtocol	object	The settings for this manager's Remote Frame Buffer protocol support, which can support VNC.
<b>RITable</b>	FabricAdapter (GenZ)	array	An array of table entry values for the Responder Interface Table.
<b>Role</b>	ManagerAccount (Links)	object	The link to the Redfish Role that defines the privileges for this account.
<b>RoleId</b>	ManagerAccount, Role	string	The name of the role.
<b>Roles</b>	AccountService	object	The collection of Redfish Roles.
<b>RotationSpeedRPM</b>	Drive	number (RPM)	The rotation speed of this drive, in revolutions per minute (RPM).
<b>RouterAdvertisementEnabled</b>	NetworkDeviceFunction (iSCSIBoot)	boolean	An indication of whether IPv6 router advertisement is enabled for the iSCSI boot target.
<b>RouteSet</b>	RouteEntry	object	The link to the collection of route set entries associated with this route.
<b>RXStompedECRC</b>	PortMetrics (GenZ)	integer	The total number of packets received with a stomped ECRC field.
<b>ScalarIncrement</b>	AttributeRegistry (RegistryEntries > Attributes)	integer	The amount to increment or decrement an integer attribute each time a user requests a value change. The `0` value indicates a free-form numeric user-input attribute.
<b>Schedule</b>	Job, MetricReportDefinition	object	The schedule for this job or metric report.
<b>Scheduling</b>	JobService (ServiceCapabilities)	boolean	An indication of whether scheduling of jobs is supported.
<b>Schema</b>	JsonSchemaFile	string	The @odata.type name this schema describes.
<b>SearchSettings</b>	AccountService (ActiveDirectory > LDAPService), AccountService (LDAP > LDAPService), ExternalAccountProvider (LDAPService)	object	The required settings to search an external LDAP service.
<b>SecondaryDNS</b>	NetworkDeviceFunction (iSCSIBoot)	string	The IPv6 or IPv4 address of the secondary DNS server for the iSCSI boot initiator.
<b>SecondaryLUN</b>	NetworkDeviceFunction (iSCSIBoot)	integer	The logical unit number (LUN) for the secondary iSCSI boot target.
<b>SecondaryTargetIPAddress</b>	NetworkDeviceFunction (iSCSIBoot)	string	The IPv4 or IPv6 address for the secondary iSCSI boot target.
<b>SecondaryTargetName</b>	NetworkDeviceFunction (iSCSIBoot)	string	The name of the iSCSI secondary boot target.

<b>SecondaryTargetTCPPort</b>	NetworkDeviceFunction (iSCSIBoot)	integer	The TCP port for the secondary iSCSI boot target.
<b>SecondaryVLANEnable</b>	NetworkDeviceFunction (iSCSIBoot)	boolean	An indication of whether the secondary VLAN is enabled.
<b>SecondaryVLANId</b>	NetworkDeviceFunction (iSCSIBoot)	integer	The 802.1q VLAN ID to use for iSCSI boot from the secondary target.
<b>SecureBoot</b>	ComputerSystem	object	The link to the UEFI Secure Boot associated with this system.
<b>SecureBootCurrentBoot</b>	SecureBoot	string (enum)	Secure Boot state during the current boot cycle.
<b>SecureBootEnable</b>	SecureBoot	boolean	An indication of whether UEFI Secure Boot is enabled.
<b>SecureBootMode</b>	SecureBoot	string (enum)	Current Secure Boot Mode.
<b>SecureErase (Action)</b>	Drive (Actions)	object	This action securely erases the contents of the drive.
<b>SecureEraseUnit (Action)</b>	Memory (Actions)	object	This contains the action for securely erasing given regions using the NIST SP800-88 Purge: Cryptographic Erase.
<b>SecurityCapabilities</b>	Memory	object	Security capabilities of the memory.
<b>SecurityState</b>	Memory	string (enum)	The current security state of this memory.
<b>SecurityStates</b>	Memory (SecurityCapabilities)	array	Security states supported by the memory.
<b>SelectQuery</b>	ServiceRoot (ProtocolFeaturesSupported)	boolean	An indication of whether the service supports the \$select query parameter.
<b>SensingFrequency</b>	Sensor	number	The time interval between readings of the physical sensor.
<b>SensingInterval</b>	Sensor	string	The time interval between readings of the sensor.
	MetricDefinition	string	The time interval between when a metric is updated.
<b>SensorNumber</b>	Power (Voltages), Thermal (Fans), Thermal (Temperatures)	integer	The numerical ID for this sensor.
	LogEntry	integer	The sensor number, the count of events, or OEM-specific information. This property value is decoded from the entry type. If the entry type is `SEL`, this property contains the sensor number. If the entry type is `Event`, this property contains the count of events. Otherwise, this property contains OEM-specific information.
<b>SensorResetTime</b>	Circuit (EnergykWh), Circuit (PolyPhaseEnergykWh > Line1ToLine2), Circuit (PolyPhaseEnergykWh > Line1ToNeutral),	string	The date and time when the time-based properties were last reset.



	Circuit (PolyPhaseEnergykWh > Line2ToLine3), Circuit (PolyPhaseEnergykWh > Line2ToNeutral), Circuit (PolyPhaseEnergykWh > Line3ToLine1), Circuit (PolyPhaseEnergykWh > Line3ToNeutral), Outlet (EnergykWh), OutletGroup (EnergykWh), Sensor		
<b>Sensors</b>	PowerDistribution	object	A link to the collection of sensors located in the equipment and sub-components.
	Chassis	object	The navigation pointer to the collection of sensors located in the equipment and sub-components.
<b>SensorType</b>	LogEntry	string (enum)	The sensor type to which the log entry pertains if the entry type is `SEL`.
<b>SerialConsole</b>	Manager	object	The serial console service that this manager provides.
<b>SerialInterfaces</b>	Manager	object	The link to a collection of serial interfaces that this manager uses for serial and console communication.
<b>SerialNumber</b>	PowerDistribution	string	The serial number for this equipment.
	FabricAdapter	string	The serial number for this fabric adapter.
	Manager	string	The serial number of the manager.
	Processor	string	The serial number of the processor.
	<i>various</i> (Assembly (Assemblies), Chassis ... )	string	The serial number of this device.
	MediaController	string	The serial number of this media controller.
<b>ServerAddress</b>	EventService (SMTP)	string	The address of the SMTP server.
<b>ServerEndpoints</b>	Volume (Links)	array	An array of references to the server Endpoints associated with this volume.
<b>ServerSentEventUri</b>	EventService	string	The link to a URI for receiving Server-Sent Event representations for the events that this service generates.
<b>ServiceAddresses</b>	AccountService (ActiveDirectory), AccountService (LDAP), ExternalAccountProvider	array	The addresses of the user account providers to which this external account provider links. The format of this field depends on the type of external account provider.
<b>ServiceCapabilities</b>	JobService	object	The supported capabilities of this Job Service implementation.
<b>ServiceEnabled</b>	EventService (SMTP)	boolean	An indication if SMTP for event delivery is enabled.

	AccountService	boolean	An indication of whether the Account Service is enabled. If `true`, it is enabled. If `false`, it is disabled and users cannot be created, deleted, or modified, and new sessions cannot be started. However, established sessions may still continue to run. Any service, such as the Session Service, that attempts to access the disabled Account Service fails. However, this does not affect HTTP Basic Authentication connections.
	Manager (CommandShell), Manager (GraphicalConsole), Manager (SerialConsole)	boolean	An indication of whether the service is enabled for this manager.
	AccountService (ActiveDirectory), AccountService (LDAP), CompositionService, EventService, ExternalAccountProvider, JobService, LogService, TaskService, TelemetryService, UpdateService	boolean	An indication of whether this service is enabled.
	SessionService	boolean	An indication of whether this service is enabled. If `true`, this service is enabled. If `false`, it is disabled, and new sessions cannot be created, old sessions cannot be deleted, and established sessions may continue operating.
<b>ServiceEntryPointUUID</b>	Manager	string	The UUID of the Redfish Service that is hosted by this manager.
<b>Sessions</b>	ServiceRoot (Links)	object	The link to a collection of Sessions.
	SessionService	object	The link to a collection of sessions.
<b>SessionService</b>	ServiceRoot	object	The link to the Sessions Service.
<b>SessionTimeout</b>	SessionService	integer (seconds)	The number of seconds of inactivity that a session may have before the Session Service closes the session due to inactivity.
<b>SessionType</b>	Session	string (enum)	The active session type.
<b>SetDefaultBootOrder (Action)</b>	ComputerSystem (Actions)	object	This action sets the BootOrder to the default settings.
<b>SetEncryptionKey (Action)</b>	Storage (Actions)	object	This action sets the encryption key for the storage subsystem.
<b>SetPassphrase (Action)</b>	Memory (Actions)	object	Set passphrase for the given regions.
<b>Severity</b>	EventService (Actions > SubmitTestEvent (Action))	string	The severity for the event to add.
	Event (Events)	string	The severity of the event.
	Triggers (DiscreteTriggers)	string	The severity of the event message.

		(enum)	
	LogEntry	string (enum)	The severity of the log entry.
<b>SharingCapable</b>	ResourceBlock (CompositionStatus)	boolean	An indication of whether this Resource Block can participate in multiple compositions simultaneously.
<b>SharingEnabled</b>	ResourceBlock (CompositionStatus)	boolean	An indication of whether this Resource Block is allowed to participate in multiple compositions simultaneously.
<b>SID</b>	Endpoint (ConnectedEntities > GenZ > GCID)	string	The subnet identifier portion of the GCID for the entity.
<b>SignalDetected</b>	Port	boolean	An indication of whether a signal is detected on this interface.
	NetworkPort	boolean	An indication of whether the port has detected enough signal on enough lanes to establish a link.
<b>SignalType</b>	SerialInterface	string (enum)	The type of signal used for the communication connection.
<b>SimpleStorage</b>	ResourceBlock	array	An array of links to the simple storage available in this Resource Block.
	ComputerSystem	object	The link to the collection of storage devices associated with this system.
<b>SimpleUpdate (Action)</b>	UpdateService (Actions)	object	This action updates software components.
<b>SizeMiB</b>	Memory (Regions)	integer (mebibytes)	Size of this memory region in mebibytes (MiB).
	MemoryChunks (InterleaveSets)	integer (mebibytes)	Size of this memory region measured in mebibytes (MiB).
<b>SKU</b>	FabricAdapter	string	The manufacturer SKU for this fabric adapter.
	Assembly (Assemblies), Chassis, ComputerSystem, Drive, NetworkAdapter, PCleDevice, Storage (StorageControllers), Switch	string	The SKU of the product or device.
<b>Slot</b>	Memory (MemoryLocation)	integer	The slot number to which the memory is connected.
<b>SlotId</b>	Processor (FPGA > ReconfigurationSlots)	string	The FPGA reconfiguration slot identifier.
<b>Slots</b>	PCleSlots	array	An array of PCI Slot information.
<b>SlotType</b>	PCleSlots (Slots)	string (enum)	The PCIe slot type for this slot.
<b>SMTP</b>	EventService	object	Settings for SMTP event delivery.
<b>SNMP</b>	EventDestination	object	Settings for an SNMP event destination.

	ManagerNetworkProtocol	object	The settings for this manager's SNMP support.
	ManagerAccount	object	The SNMP settings for this account.
<b>Socket</b>	Memory (MemoryLocation)	integer	The socket number to which the memory is connected.
	Processor	string	The socket or location of the processor.
<b>SoftwareId</b>	SoftwareInventory	string	The implementation-specific label that identifies this software.
<b>SoftwareImages</b>	Bios (Links)	array	The images that are associated with this BIOS.
	Manager (Links)	array	The images that are associated with this manager.
<b>SoftwareInventory</b>	UpdateService	object	An inventory of software.
<b>SourceMetric</b>	MetricDefinition (CalculationParameters)	string	The metric property used as the input into the calculation.
<b>SpareBlock</b>	MemoryMetrics (HealthData > AlarmTrips)	boolean	An indication of whether the spare block capacity crossing alarm trip was detected.
<b>SpareDeviceCount</b>	Memory	integer	Number of unused spare devices available in the memory.
<b>SparePartNumber</b>	FabricAdapter	string	The spare part number for this fabric adapter.
	Assembly (Assemblies), Power (PowerSupplies), Thermal (Fans)	string	The spare part number of the assembly, fan, or power supply.
<b>SpareResourceSets</b>	Volume (Links)	array	An array of references to SpareResourceSets.
<b>SpeedGbps</b>	Storage (StorageControllers)	number (Gbit/s)	The maximum speed of the storage controller's device interface.
<b>SpeedMbps</b>	EthernetInterface	integer (Mbit/s)	The current speed, in Mbps, of this interface.
<b>SpeedMHz</b>	Processor (ProcessorMemory)	integer	The operating speed of the memory in MHz.
<b>SplitReplication (Action)</b>	Volume (Actions)	object	This action is used to split the replication relationship and suspend data synchronization between a source and target volume.
<b>SRIOV</b>	NetworkAdapter (Controllers > ControllerCapabilities > VirtualizationOffload)	object	Single-Root Input/Output Virtualization (SR-IOV) capabilities.
<b>SRIOVVEPACapable</b>	NetworkAdapter (Controllers > ControllerCapabilities > VirtualizationOffload > SRIOV)	boolean	An indication of whether this controller supports single root input/output virtualization (SR-IOV) in Virtual Ethernet Port Aggregator (VEPA) mode.
<b>SSDP</b>	ManagerNetworkProtocol	object	The settings for this manager's SSDP support.

<b>SSDT</b>	FabricAdapter (GenZ)	object	The Single Subnet Destination Table for the component.
<b>SSEFilterPropertiesSupported</b>	EventService	object	The set of properties that are supported in the \$filter query parameter for the ServerSentEventUri.
<b>SSH</b>	ManagerNetworkProtocol	object	The settings for this manager's Secure Shell (SSH) protocol support.
<b>StartTime</b>	Job	string	The date and time when the job was started or is scheduled to start.
	Task	string	The date and time when the task was started.
<b>StartUpdate (Action)</b>	UpdateService (Actions)	object	This action starts an update of software components.
<b>State</b>	CertificateService (Actions > GenerateCSR (Action))	string	The state, province, or region of the organization making the request.
	Certificate (Issuer), Certificate (Subject)	string	The state, province, or region of the organization of the entity.
<b>StatelessAddressAutoConfig</b>	EthernetInterface	object	Stateless address autoconfiguration (SLAAC) parameters for this interface.
<b>StaticNameServers</b>	EthernetInterface	array	The statically-defined set of DNS server IPv4 and IPv6 addresses.
<b>Status</b>	<i>various</i> (AccelerationFunction, AccountService ... )	object	The state and health of the Resource and its children.
<b>StatusIndicator</b>	Drive	string (enum)	The state of the status indicator, which communicates status information about this drive.
<b>Step</b>	Processor (ProcessorId)	string	The step value for this processor.
<b>StepOrder</b>	Job	array	The serialized execution order of the job Steps.
<b>Steps</b>	Job	object	The link to a collection of steps for this job.
<b>StopBits</b>	SerialInterface	string (enum)	The period of time before the next start bit is transmitted.
<b>Storage</b>	Chassis (Links), ResourceBlock	array	An array of references to the available storage.
	ComputerSystem	object	The link to the collection of storage devices associated with this system.
<b>StorageAccessCapability</b>	Volume (AccessCapabilities)	string (enum)	Values of StorageAccessCapability describe abilities to read or write storage.
<b>StorageControllers</b>	PCIeFunction (Links)	array	An array of links to the storage controllers that the PCIe device produces.
	Storage	array	The set of storage controllers that this Resource represents.

<b>StorageGroups</b>	Volume (Links)	array	An array of references to the StorageGroups associated with this volume.
	Storage	object	All of the storage groups, each of which contains a set of volumes and endpoints that are managed as a group for mapping and masking, that belong to this storage subsystem.
	Volume	object	An array of references to Storage Groups that includes this volume.
<b>StoragePools</b>	Drive (Links)	array	An array of links to the storage pools to which this drive belongs.
	Storage	object	The set of all storage pools that are allocated by this storage subsystem. A storage pool is the set of storage capacity that can be used to produce volumes or other storage pools.
<b>StorageServices</b>	Storage (StorageControllers > Links)	array	An array of links to the Storage Services that connect to this controller.
	ServiceRoot	object	The link to a collection of all storage service entities.
	ComputerSystem (HostedServices)	object	The link to a collection of storage services that this computer system supports.
<b>StorageSystems</b>	ServiceRoot	object	The link to a collection of storage systems.
<b>StripSizeBytes</b>	Volume	integer (bytes)	The number of blocks (bytes) in a strip in a disk array that uses striped data mapping.
<b>Subfeeds</b>	PowerDistribution	object	A link to the subfeed circuits for this equipment.
<b>Subject</b>	Certificate	object	The subject of the certificate.
<b>SubmitTestEvent (Action)</b>	EventService (Actions)	object	This action generates a test event.
<b>SubmitTestMetricReport (Action)</b>	TelemetryService (Actions)	object	This action generates a metric report.
<b>SubModel</b>	ComputerSystem	string	The sub-model for this system.
<b>SubordinateOverrides</b>	PrivilegeRegistry (Mappings)	array	The privilege overrides of the subordinate Resource.
<b>SubordinateResources</b>	EventService (SSEFilterPropertiesSupported)	boolean	An indication of whether the service supports the SubordinateResources property in the \$filter query parameter.
	EventDestination	boolean	An indication of whether the subscription is for events in the OriginResources array and its subordinate Resources. If `true` and the OriginResources array is specified, the subscription is for events in the OriginResources array and its subordinate Resources. Note that Resources associated through

			the Links section are not considered subordinate. If `false` and the OriginResources array is specified, the subscription shall be for events in the OriginResources array only. If the OriginResources array is not present, this property shall have no relevance.
<b>SubordinateResourcesSupported</b>	EventService	boolean	An indication of whether the service supports the SubordinateResource property on both event subscriptions and generated events.
<b>SubProcessors</b>	Processor	object	The link to the collection of subprocessors associated with this system, such as cores or threads, that are part of a processor.
<b>Subscriptions</b>	EventService	object	The link to a collection of event destination Resources.
<b>SubscriptionType</b>	EventDestination	string (enum)	The subscription type for events.
<b>SubsystemDeviceID</b>	Memory	string	Subsystem device ID.
<b>SubsystemId</b>	Endpoint (ConnectedEntities > EntityPcid), Endpoint (Pcid), PCleFunction	string	The Subsystem ID of this PCIe function.
<b>SubsystemVendorId</b>	Endpoint (ConnectedEntities > EntityPcid), Endpoint (Pcid), PCleFunction	string	The Subsystem Vendor ID of this PCIe function.
<b>SubsystemVendorID</b>	Memory	string	SubSystem vendor ID.
<b>SupplyingComputerSystems</b>	ComputerSystem (Links)	array	An array of links to ComputerSystems that contribute, in whole or in part, to the implementation of this ComputerSystem.
<b>SupportedCollectionFunctions</b>	TelemetryService	array	The functions that can be performed over each metric.
<b>SupportedControllerProtocols</b>	Storage (StorageControllers)	array	The supported set of protocols for communicating to this storage controller.
<b>SupportedDeviceProtocols</b>	Storage (StorageControllers)	array	The protocols that the storage controller can use to communicate with attached devices.
<b>SupportedEthernetCapabilities</b>	NetworkPort	array	The set of Ethernet capabilities that this port supports.
<b>SupportedLinkCapabilities</b>	NetworkPort	array	The link capabilities of this port.
<b>SupportedProtocols</b>	Switch	array	The protocols this switch supports.
<b>SupportedRAIDTypes</b>	Storage (StorageControllers)	array	The set of RAID types supported by the storage controller.
<b>SupportedSystems</b>	AttributeRegistry	array	An array of systems that this Attribute Registry supports.
<b>SuppressRepeatedMetricValue</b>	MetricReportDefinition	boolean	An indication of whether any metrics

			are suppressed from the generated metric report. If `true`, any metric that equals the same metric in the previously generated metric report is suppressed from the current report. Also, duplicate metrics are suppressed. If `false`, no metrics are suppressed from the current report. The current report may contain no metrics if all metrics equal the values of the same metrics in the previously generated metric report.
<b>Surname</b>	CertificateService (Actions > GenerateCSR (Action))	string	The surname of the user making the request.
<b>SuspendReplication (Action)</b>	Volume (Actions)	object	This action is used to suspend active data synchronization between a source and target volume, without otherwise altering the replication relationship.
<b>Switches</b>	Chassis (Links)	array	An array of links to the Switches located in this chassis.
	Fabric	object	The collection of links to the switches that this fabric contains.
<b>Switchgear</b>	Facility (Links)	array	An array of links to the switchgear in this facility.
	PowerDomain (Links)	array	An array of links to the switchgear in this power domain.
	PowerEquipment	object	A link to a collection of switchgear.
<b>SwitchType</b>	Switch	string (enum)	The protocol being sent over this switch.
<b>SystemId</b>	AttributeRegistry (SupportedSystems)	string	The ID of the systems to which this Attribute Registry applies.
<b>Systems</b>	ServiceRoot	object	The link to a collection of systems.
<b>SystemType</b>	ComputerSystem	string (enum)	The type of computer system that this Resource represents.
<b>TargetInfoViaDHCP</b>	NetworkDeviceFunction (iSCSIBoot)	boolean	An indication of whether the iSCSI boot target name, LUN, IP address, and netmask should be obtained from DHCP.
<b>Targets</b>	UpdateService (Actions > SimpleUpdate (Action))	array	An array of URIs that indicate where to apply the update image.
	PrivilegeRegistry (Mappings > PropertyOverrides), PrivilegeRegistry (Mappings > ResourceURIOverrides), PrivilegeRegistry (Mappings > SubordinateOverrides)	array	The set of URIs, Resource types, or properties.
<b>TargetStoragePool</b>	Volume (Actions > CreateReplicaTarget (Action))	string	The Uri to the existing target Storage Pool.
<b>TargetUri</b>	Job (Payload), Task (Payload)	string	The URI of the target for this job or task.



<b>TargetVolume</b>	Volume (Actions > AssignReplicaTarget (Action)), Volume (Actions > RemoveReplicaRelationship (Action)), Volume (Actions > ResumeReplication (Action)), Volume (Actions > ReverseReplicationRelationship (Action)), Volume (Actions > SplitReplication (Action)), Volume (Actions > SuspendReplication (Action))	string	The Uri to the existing target volume.
<b>TaskMonitor</b>	Task	string	The URI of the Task Monitor for this task.
<b>Tasks</b>	ServiceRoot	object	The link to the Task Service.
	TaskService	object	The links to the Tasks collection.
<b>TaskState</b>	Task	string (enum)	The state of the task.
<b>TaskStatus</b>	Task	string (enum)	The completion status of the task.
<b>TDPWatts</b>	Processor	integer (Watts)	The nominal Thermal Design Power (TDP) in watts.
<b>TelemetryService</b>	ServiceRoot	object	The link to the Telemetry Service.
<b>Telnet</b>	ManagerNetworkProtocol	object	The settings for this manager's Telnet protocol support.
<b>Temperature</b>	MemoryMetrics (HealthData > AlarmTrips)	boolean	An indication of whether a temperature threshold alarm trip was detected.
<b>TemperatureCelsius</b>	ProcessorMetrics	number (Celsius)	The temperature of the processor.
<b>Temperatures</b>	Thermal	array	The set of temperature sensors for this chassis.
<b>THDPercent</b>	<i>various</i> (Circuit (CurrentAmps), Circuit (PolyPhaseCurrentAmps > Line1) ... )	number	The total harmonic distortion (THD).
<b>Thermal</b>	Chassis	object	The link to the thermal properties, such as fans, cooling, and sensors, for this chassis.
<b>Threshold</b>	VCATEntry (VCEntries)	string	The configured threshold.
<b>Thresholds</b>	Sensor	object	The set of thresholds defined for this sensor.
<b>ThrottlingCelsius</b>	ProcessorMetrics	number (Celsius)	The CPU margin to throttle (temperature offset in degree Celsius).
<b>TimeoutAction</b>	ComputerSystem (HostWatchdogTimer)	string (enum)	The action to perform when the watchdog timer reaches its timeout value.

<b>Timestamp</b>	MetricReport	string	The date and time when the metric report was generated. The timestamp of the metric report may be relevant when the timestamp of individual metrics are minimally different.
	MetricReport (MetricValues)	string	The date and time when the metric was obtained. A management application can get metrics and sort them by timestamp.
	TelemetryService (Actions > SubmitTestMetricReport (Action) > GeneratedMetricReportValues)	string	The time when the metric value is obtained. A management application may establish a time series of metric data by retrieving the instances of metric value and sorting them according to their Timestamp.
<b>TimestampAccuracy</b>	MetricDefinition	string	The accuracy of the timestamp.
<b>Token</b>	AccountService (ActiveDirectory > Authentication), AccountService (LDAP > Authentication), ExternalAccountProvider (Authentication)	string	The token for this Service. A PATCH or PUT operation writes the token. This property is `null` in responses.
<b>TotalCacheSizeMiB</b>	Storage (StorageControllers > CacheSummary)	integer (mebibytes)	The total configured cache memory, measured in MiB.
<b>TotalCores</b>	Processor	integer	The total number of cores that this processor contains.
<b>TotalEnabledCores</b>	Processor	integer	The total number of enabled cores that this processor contains.
<b>TotalSwitchWidth</b>	Switch	integer	The total number of lanes, phys, or other physical transport links that this switch contains.
<b>TotalSystemMemoryGiB</b>	ComputerSystem (MemorySummary)	number (GiBy)	The total configured operating system-accessible memory (RAM), measured in GiB.
<b>TotalSystemPersistentMemoryGiB</b>	ComputerSystem (MemorySummary)	number (GiBy)	The total configured, system-accessible persistent memory, measured in GiB.
<b>TotalThreads</b>	Processor	integer	The total number of execution threads that this processor supports.
<b>TransferConfiguration</b>	PowerDistribution	object	The configuration settings for an automatic transfer switch.
<b>TransferControl (Action)</b>	PowerDistribution (Actions)	object	This action transfers control to the alternative input circuit.
<b>TransferCriteria</b>	PowerDistribution	object	The criteria used to initiate a transfer for an automatic transfer switch.
<b>TransferDelaySeconds</b>	PowerDistribution (TransferConfiguration)	integer	The time in seconds to delay the automatic transfer from the preferred mains circuit to the alternate mains circuit when the preferred mains circuit is disqualified.
<b>TransferInhibit</b>	PowerDistribution	boolean	Indicates if any transfer is inhibited.

	(TransferConfiguration)		
<b>TransferMethod</b>	VirtualMedia (Actions > InsertMedia (Action)), VirtualMedia	string (enum)	The transfer method to use with the Image.
<b>TransferProtocol</b>	UpdateService (Actions > SimpleUpdate (Action))	string (enum)	The network protocol that the Update Service uses to retrieve the software image file located at the URI provided in ImageURI, if the URI does not contain a scheme.
<b>TransferProtocolType</b>	VirtualMedia (Actions > InsertMedia (Action)), VirtualMedia	string (enum)	The network protocol to use with the image.
<b>TransferSensitivity</b>	PowerDistribution (TransferCriteria)	string (enum)	The sensitivity to voltage waveform quality to satisfy the criterion for initiating a transfer.
<b>TransferSwitches</b>	Facility (Links)	array	An array of links to the transfer switches in this facility.
	PowerDomain (Links)	array	An array of links to the transfer switches in this power domain.
	PowerEquipment	object	A link to a collection of transfer switches.
<b>TransformationRatePercent</b>	Storage (StorageControllers > ControllerRates)	integer	The percentage of controller Resources used for transforming volumes from one configuration to another.
<b>TransportProtocol</b>	Endpoint (IPTransportDetails)	string (enum)	The protocol used by the connection entity.
<b>TrapCommunity</b>	EventDestination (SNMP)	string	The SNMP trap community string.
<b>TriggerActionEnum</b>	Triggers (TriggerActions)	string (enum)	The actions to perform when a trigger condition is met.
<b>TriggerActions</b>	Triggers	array	The actions that the trigger initiates.
<b>Triggers</b>	MetricReportDefinition (Links)	array	The triggers that cause this metric report definition to generate a new metric report upon a trigger occurrence when the TriggerActions property contains 'RedfishMetricReport'.
	TelemetryService	object	The link to the collection of triggers, which apply to metrics.
<b>TrustedModules</b>	ComputerSystem	array	An array of trusted modules in the system.
<b>TXStompedECRC</b>	PortMetrics (GenZ)	integer	The total number of packets that this interface stomped the ECRC field.
<b>Type</b>	AttributeRegistry (RegistryEntries > Attributes)	string (enum)	The attribute type.
	AttributeRegistry (RegistryEntries > Dependencies)	string (enum)	The type of the dependency structure.
<b>UefiDevicePath</b>	AttributeRegistry	string	The UEFI device path to this

	(RegistryEntries > Attributes), BootOption, EthernetInterface, SimpleStorage		interface, attribute, boot option, or storage controller.
<b>UefiDevicePaths</b>	SoftwareInventory	array	The list of UEFI device paths of the components associated with this software inventory item.
<b>UefiKeywordName</b>	AttributeRegistry (RegistryEntries > Attributes)	string	The UEFI keyword string for this attribute.
<b>UefiNamespaceId</b>	AttributeRegistry (RegistryEntries > Attributes)	string	The UEFI namespace ID for the attribute.
<b>UefiTargetBootSourceOverride</b>	ComputerSystem (Boot)	string	The UEFI device path of the device from which to boot when BootSourceOverrideTarget is 'UefiTarget'.
<b>UncorrectableECCErrors</b>	MemoryMetrics (HealthData > AlarmTrips)	boolean	An indication of whether the uncorrectable error threshold alarm trip was detected.
<b>UnderNominalFrequencyHz</b>	PowerDistribution (TransferCriteria)	number (Hz)	The frequency in Hertz under the nominal value that satisfies a criterion for transfer.
<b>UnderVoltageRMSPercentage</b>	PowerDistribution (TransferCriteria)	number (%)	The negative percentage of voltage RMS under the nominal value that satisfies a criterion for transfer.
<b>UnhaltedCycles</b>	ProcessorMetrics (CoreMetrics)	number	The unhalted cycles count of this core.
<b>Units</b>	MetricDefinition	string	The units of measure for this metric.
<b>UnlockUnit (Action)</b>	Memory (Actions)	object	This contains the action for unlocking given regions.
<b>UnstructuredName</b>	CertificateService (Actions > GenerateCSR (Action))	string	The unstructured name of the subject.
<b>Updateable</b>	SoftwareInventory	boolean	An indication of whether the Update Service can update this software.
<b>UpdateService</b>	ServiceRoot	object	The link to the Update Service.
<b>UpperBound</b>	AttributeRegistry (RegistryEntries > Attributes)	integer	The upper limit for an integer attribute.
<b>UpperCaution</b>	Sensor (Thresholds)	object	The value at which the reading is above normal range.
<b>UpperCritical</b>	Sensor (Thresholds), Triggers (NumericThresholds)	object	Above normal range but not fatal. Requires attention.
<b>UpperFatal</b>	Sensor (Thresholds)	object	The value at which the reading is above normal range and fatal.
<b>UpperThresholdCritical</b>	Thermal (Fans)	integer	The value at which the reading is above normal range but not yet fatal.
	Thermal (Temperatures)	number (Celsius)	The value at which the reading is above normal range but not yet fatal.
	Power (Voltages)	number (Volts)	The value at which the reading is above normal range but not yet fatal.

<b>UpperThresholdFatal</b>	Thermal (Fans) <small>redfish.dmtf.org</small>	integer	The value at which the reading is above normal range and fatal. <small>Redfish Property Guide</small>
	Thermal (Temperatures)	number (Celsius)	The value at which the reading is above normal range and fatal.
	Power (Voltages)	number (Volts)	The value at which the reading is above normal range and fatal.
<b>UpperThresholdNonCritical</b>	Thermal (Fans)	integer	The value at which the reading is above normal range.
	Thermal (Temperatures)	number (Celsius)	The value at which the reading is above normal range.
	Power (Voltages)	number (Volts)	The value at which the reading is above normal range.
<b>UpperThresholdUser</b>	Thermal (Temperatures)	integer (Celsius)	The value at which the reading is above the user-defined range.
<b>UpperWarning</b>	Triggers (NumericThresholds)	object	The value at which the reading is above normal range.
<b>Uri</b>	JsonSchemaFile (Location)	string	The link to locally available URI for schema.
	MessageRegistryFile (Location)	string	The link to locally available URI for the Message Registry.
<b>UseDNSServers</b>	EthernetInterface (DHCPv4), EthernetInterface (DHCPv6)	boolean	An indication of whether the interface uses the DHCP protocol-supplied DNS servers.
<b>UseDomainName</b>	EthernetInterface (DHCPv4), EthernetInterface (DHCPv6)	boolean	An indication of whether the interface uses the the DHCP protocol-supplied domain name.
<b>UseGateway</b>	EthernetInterface (DHCPv4)	boolean	An indication of whether this interface uses a DHCP v4-supplied gateway.
<b>UseNTPServers</b>	EthernetInterface (DHCPv4), EthernetInterface (DHCPv6)	boolean	An indication of whether the interface uses the DHCP protocol-supplied NTP servers.
<b>UseRapidCommit</b>	EthernetInterface (DHCPv6)	boolean	An indication of whether the interface uses DHCP v6 rapid commit mode for stateful mode address assignments. Do not enable this option in networks where more than one DHCP v6 server is configured to provide address assignments.
<b>Username</b>	AccountService (ActiveDirectory > Authentication), AccountService (LDAP > Authentication), ExternalAccountProvider (Authentication)	string	The user name for the Service.
	UpdateService (Actions > SimpleUpdate (Action))	string	The user name to access the URI specified by the ImageURI parameter.
	EventService (SMTP)	string	The username for authentication with the SMTP server.
<b>UserName</b>	ManagerAccount,	string	The user name to access the account

	Session, VirtualMedia		or the account for this session, or the Image parameter-specified URI.
	VirtualMedia (Actions > InsertMedia (Action))	string	The user name to access the Image parameter-specified URI.
<b>UsernameAttribute</b>	AccountService (ActiveDirectory > LDAPService > SearchSettings), AccountService (LDAP > LDAPService > SearchSettings), ExternalAccountProvider (LDAPService > SearchSettings)	string	The attribute name that contains the LDAP user name entry.
<b>UserPercent</b>	ProcessorMetrics	number (%)	The percentage of time spent in user mode.
<b>UseStaticRoutes</b>	EthernetInterface (DHCPv4)	boolean	An indication of whether the interface uses DHCP v4-supplied static routes.
<b>UUID</b>	AccelerationFunction, Chassis, ComputerSystem, Manager, Processor (FPGA > ReconfigurationSlots), Processor, ServiceRoot	string	The Universal Unique Identifier (UUID) for this device.
	PowerDistribution	string	The UUID for this equipment.
	FabricAdapter	string	The UUID for this fabric adapter.
	Switch	string	The UUID for this switch.
<b>Valid</b>	RouteSetEntry	boolean	An indication of whether the entry is valid.
<b>ValidNotAfter</b>	Certificate	string	The date when the certificate is no longer valid.
<b>ValidNotBefore</b>	Certificate	string	The date when the certificate becomes valid.
<b>Value</b>	AttributeRegistry (RegistryEntries > Attributes)	array	An array of the possible values for enumerated attribute values.
	Triggers (DiscreteTriggers)	string	The discrete metric value that constitutes a trigger event.
<b>ValueDisplayName</b>	AttributeRegistry (RegistryEntries > Attributes > Value)	string	A user-readable display string of the value for the attribute in the defined language.
<b>ValueExpression</b>	AttributeRegistry (RegistryEntries > Attributes)	string	A valid regular expression, according to the Perl regular expression dialect, that validates the attribute value. Applies to only string and integer attributes.
<b>ValueName</b>	AttributeRegistry (RegistryEntries > Attributes > Value)	string	The unique value name for the attribute.
<b>Values</b>	MetricDefinition (Wildcards), MetricReportDefinition	array	An array of values to substitute for the wildcard.

	(Wildcards), Triggers (Wildcards)		
<b>VCAction</b>	RouteSetEntry	integer	The Virtual Channel Action index.
<b>VCAT</b>	Port (GenZ)	object	the Virtual Channel Action Table for the port.
<b>VCEntries</b>	VCATEntry	array	An array of entries of the Virtual Channel Action Table.
<b>VCMask</b>	VCATEntry (VCEntries)	string	The bits corresponding to the supported Virtual Channel.
<b>Vendor</b>	Assembly (Assemblies), ServiceRoot	string	The vendor or manufacturer of this assembly or that is associated with the Redfish Service.
<b>VendorId</b>	Endpoint (ConnectedEntities > EntityPcild), Endpoint (Pcild), NetworkPort, PCleFunction, Processor (ProcessorId)	string	The vendor ID of this PCIe function, port, or processor.
<b>VendorID</b>	Memory	string	Vendor ID.
<b>Version</b>	Processor	string	The hardware version of the processor.
	PowerDistribution	string	The hardware version of this equipment.
	AccelerationFunction, Assembly (Assemblies), SoftwareInventory	string	The version of this Resource.
<b>VirtualFunction</b>	NetworkAdapter (Controllers > ControllerCapabilities > VirtualizationOffload)	object	The virtual function of the controller.
<b>VirtualFunctionsEnabled</b>	NetworkDeviceFunction	boolean	An indication of whether single root input/output virtualization (SR-IOV) virtual functions are enabled for this network device function.
<b>VirtualizationOffload</b>	NetworkAdapter (Controllers > ControllerCapabilities)	object	Virtualization offload for this controller.
<b>VirtualMedia</b>	Manager	object	The link to the Virtual Media services for this particular manager.
	ManagerNetworkProtocol	object	The settings for this manager's virtual media support.
<b>VLAN</b>	EthernetInterface	object	If this network interface supports more than one VLAN, this property is absent. VLAN collections appear in the Link section of this Resource.
	NetworkDeviceFunction (Ethernet)	object	If this network interface supports more than one VLAN, this property is not present. VLANs collections appear in the Link section of this Resource.
<b>VLANEnable</b>	VlanNetworkInterface	boolean	An indication of whether this VLAN is enabled for this interface.

<b>VLANId</b>	VLANNetworkInterface	integer	The ID for this VLAN.
<b>VLANs</b>	EthernetInterface	object	The link to a collection of VLANs, which applies only if the interface supports more than one VLAN. If this property applies, the VLANEnabled and VLANId properties do not apply.
	NetworkDeviceFunction (Ethernet)	object	The link to a collection of VLANs. This property is used only if the interface supports more than one VLAN.
<b>VolatileRegionNumberLimit</b>	Memory	integer	Total number of volatile regions this memory can support.
<b>VolatileRegionSizeLimitMiB</b>	Memory	integer (mebibytes)	Total size of volatile regions in mebibytes (MiB).
<b>VolatileRegionSizeMaxMiB</b>	Memory	integer (mebibytes)	Maximum size of a single volatile region in mebibytes (MiB).
<b>VolatileSizeMiB</b>	Memory	integer (mebibytes)	Total size of the volatile portion memory in MiB.
<b>Voltage</b>	Circuit	object	The voltage reading for this single phase circuit.
	Outlet	object	The voltage reading for this single phase outlet.
<b>Voltages</b>	Power	array	The set of voltage sensors for this chassis.
<b>VoltageType</b>	Circuit	string (enum)	The type of voltage applied to the circuit.
	Outlet	string (enum)	The type of voltage applied to the outlet.
	Sensor	string (enum)	The voltage type for this sensor.
<b>VolumeName</b>	Volume (Actions > CreateReplicaTarget (Action))	string	The Name for the new target volume.
<b>Volumes</b>	Drive (Links)	array	An array of links to the volumes that this drive either wholly or only partially contains.
	Storage	object	The set of volumes that the storage controllers produce.
<b>VolumeType</b>	Volume	string (enum)	The type of this volume.
<b>VolumeUsage</b>	Volume	string (enum)	Indicates the Volume usage type setting for the Volume.
<b>WakeOnLANEnabled</b>	NetworkPort	boolean	An indication of whether Wake on LAN (WoL) is enabled for this network port.
<b>WarningAction</b>	ComputerSystem (HostWatchdogTimer)	string (enum)	The action to perform when the watchdog timer is close to reaching its timeout value. This action typically occurs from three to ten seconds before to the timeout value, but the exact timing is dependent on the



			implementation.
<b>WarningText</b>	AttributeRegistry (RegistryEntries > Attributes)	string	The warning text for the attribute.
<b>WeightKg</b>	Chassis	number (kg)	The weight of the chassis.
<b>Width</b>	Port	integer	The number of lanes, phys, or other physical transport links that this port contains.
<b>WidthMm</b>	Chassis	number (mm)	The width of the chassis.
<b>Wildcards</b>	MetricReportDefinition	array	The set of wildcards and their substitution values for the entries in the MetricProperties property.
	MetricDefinition, Triggers	array	The wildcards and their substitution values for the entries in the MetricProperties array property.
<b>WriteCacheEnabled</b>	Drive	boolean	An indication of whether the drive write cache is enabled.
<b>WriteCachePolicy</b>	Volume	string (enum)	Indicates the write cache policy setting for the Volume.
<b>WriteCacheState</b>	Volume	string (enum)	Indicates the WriteCacheState policy setting for the Volume.
<b>WriteHoleProtectionPolicy</b>	Volume	string (enum)	The policy that the RAID volume is using to address the write hole issue.
<b>WriteOnly</b>	AttributeRegistry (RegistryEntries > Attributes)	boolean	An indication of whether this attribute is write-only. A write-only attribute reverts to its initial value after settings are applied.
<b>WriteProtected</b>	VirtualMedia	boolean	An indication of whether the media is write-protected.
	VirtualMedia (Actions > InsertMedia (Action))	boolean	An indication of whether the remote media is treated as write-protected. The default is `true`.
<b>WWNN</b>	NetworkDeviceFunction (FibreChannel)	string	The currently configured World Wide Node Name (WWNN) address of this function.
<b>WWNSource</b>	NetworkDeviceFunction (FibreChannel)	string (enum)	The configuration source of the World Wide Names (WWN) for this World Wide Node Name (WWNN) and World Wide Port Name (WWPN) connection.
<b>WWPN</b>	NetworkDeviceFunction (FibreChannel > BootTargets), NetworkDeviceFunction (FibreChannel)	string	The World Wide Port Name (WWPN) of the network device, or physical, function from which to boot.
<b>Zones</b>	ResourceBlock (Links)	array	An array of links to the Zones in which this Resource Block is bound.
	AddressPool (Links)	array	An array of links to the zones that this address pool contains.

	Fabric	object	The collection of links to the zones that this fabric contains.
<b>ZoneType</b>	Zone	string (enum)	The type of zone.

## Postscript

## Redfish Documentation Generator

The DMTF's [Redfish Documentation Generator](#) automatically generates the bulk of the text from the Redfish Schema files in JSON Schema format and merges that text with supplemental text to build this guide.

The source code for the generator is available for download at the DMTF's GitHub repository at <http://www.github.com/DMTF/Redfish-Tools>.

## ANNEX A

### Change log

Version	Date	Description
2019.4	2019-12-06	Document built from Redfish Schemas in DSP8010 release 2019.4.
2019.3	2019-10-11	Document built from Redfish Schemas in DSP8010 release 2019.3.
2019.2	2019-09-13	Document built from Redfish Schemas in DSP8010 release 2019.2. Editorial corrections.
2019.1	2019-05-03	Document built from Redfish Schemas in DSP8010 release 2019.1.
2018.3	2019-01-15	Initial release. Document built from Redfish Schemas in DSP8010 release 2018.3.